

Stereo VU Meter


Hallo und willkommen zu einem neuen Teil der Reihe "VU-Meter". Die große Resonanz auf den ersten Teil der Reihe ist überwältigend! Der Herausforderung nehmen wir uns natürlich an und erweitern im nächsten Schritt unser VU-Meter um einen weiteren Kanal. Die Anzeige des zweiten Kanals erfolgt dabei negativ auf dem U64 Panel. Schon haben wir ein tolles Stereo-VU Meter mit einem beeindruckenden Gegenlauf Effekt!

Mit an Bord sind natürlich auch ein paar Hardware Erweiterungen und Optimierungen. Wie ich schon im ersten Teil schrieb, ist das U64 Panel ziemlich stromhungrig. Daher ist unsere erste Hardwareänderung ein Tausch des Breadboard Versorgungsmoduls gegen eine stabile 5Volt/2,6 A Stromversorgung. Damit können wir jetzt ohne Stromprobleme prinzipiell einmal die Helligkeit der Led's des Panels von 39% auf 100% erhöhen. Die Anzeige macht damit gleich ein wenig mehr her. Der Code beschränkt diese Helligkeit allerdings erst einmal auf 60% Helligkeit. Diese Beschränkung wird im nächsten Teil der Reihe ohne Änderung der Stromversorgung dann fallen.

Das Breadboard Versorgungsmodul ist natürlich kein Müll, sondern kann für alle weiteren Aufbauten von nachfolgendenden ebenso spannenden Projekten weiterverwendet werden. Die weiteren zusätzlichen Teile, namentlich die beiden 680 Ohm Wiederstände und die zwei 5,1 Volt Zener-Dioden erfüllen schaltungstechnische Schutzfunktionen für den Arduino. Somit ergibt sich für den heutigen Teil der Reihe folgende Teilliste:

- 1x Arduino Nano (mit FTDI)
- > 1x U64 LED Panel
- 2x 10 KOhm Wiederstände 1%
- 2x 680 Ohm Wiederstand 5%
- > 1x 5 Volt, min 2.6 Ampere Stromversorgung
- > 1x 10 uF 64 Volt Elektrolytkondensator
- > 1x Stereo Klinken-Steckverbinder 3.5 mm Buchse
- 2x 5,1 Volt Zener-Diode

Wir verdrahten die Bauteile nachfolgendem Schaltplan:



fritzing

Nachdem wir die Schaltung komplett aufgebaut bzw. aktualisiert haben, können wir nun den aktualisierten und erweiterten Code auf unseren Arduino hochladen:

```
include <Adafruit NeoPixel.h>
// Which pin on the Arduino is connected to the NeoPixels?
// On a Trinket or Gemma we suggest changing this to 1:
#define LED PIN
                   13
// How many NeoPixels are attached to the Arduino?
#define LED COUNT 64
// Declare our NeoPixel strip object:
Adafruit NeoPixel strip(LED COUNT, LED PIN, NEO GRB + NEO KHZ800);
// Argument 1 = Number of pixels in NeoPixel strip
// Argument 2 = Arduino pin number (most are valid)
// Argument 3 = Pixel type flags, add together as needed:
// NEO KHZ800 800 KHz bitstream (most NeoPixel products w/WS2812 LEDs)
// NEO KHZ400 400 KHz (classic 'v1' (not v2) FLORA pixels, WS2811 drivers)
// NEO GRB
                Pixels are wired for GRB bitstream (most NeoPixel products)
// NEO RGB
                Pixels are wired for RGB bitstream (v1 FLORA pixels, not v2)
// NEO RGBW Pixels are wired for RGBW bitstream (NeoPixel RGBW
products)
#define analogPinLeft A5 // Left Audio Channel, connected to analog pin A5
#define analogPinRight A4 // Right Audio Channel, connected to analog pin A4
#define Left Channel Deviation 5
#define Right Channel Deviation 5
int val left old = 0: // variable to store the value read from Channel Left
int Base Left = 0; // 0 Basis
int val right old = 0; // variable to store the value read from Channel Left
int Base Right = 0; // 0 Basis
int leftDropTime, rightDropTime;
int dropDelay = 4;
                                        // hold time before dropping the leds
// NeoPixel brightness, 0 (min) to 255 (max)
byte BRIGHTNESS = 153; // 60% Brightness
float dropFactor = .98;
void setup()
 strip.begin();
                   // INITIALIZE NeoPixel strip object (REQUIRED)
 strip.show();
                   // Turn OFF all pixels ASAP
 strip.setBrightness(BRIGHTNESS); // Set BRIGHTNESS to about 1/5 (max = 255)
 Base Left = analogRead(analogPinLeft);
 Base Left += analogRead(analogPinLeft);
 Base Left += analogRead(analogPinLeft);
 Base Left += analogRead(analogPinLeft);
 Base Left = Base Left / 4;
 Base Right = analogRead(analogPinRight);
 Base Right += analogRead(analogPinRight);
 Base Right += analogRead(analogPinRight);
 Base Right += analogRead(analogPinRight);
```

```
Base Right = Base Right / 4;
 Serial.begin(9600);
 colorWipe(strip.Color(255,0,0), 5); // Red
 colorWipe(strip.Color(255,255,0), 5); // yellow
 colorWipe(strip.Color(0,255,0), 5); // Green
 rainbowFade2White(1, 1, 1);
void loop()
Left VU Meter(LED COUNT / 2,512);
Right VU Meter(LED COUNT / 2,511);
strip.show(); // Update strip to match
void Left VU Meter(byte Level Max Pixels,int sensitivity)
 int val left = 0;
 bool Overload = false;
 uint32 t rgbcolor;
 uint32 thue;
 int Signal Strength = 0;
 byte VU Led Level = 0;
 val left = analogRead(analogPinLeft); // read the input pin
 val left += analogRead(analogPinLeft); // read the input pin
 val left += analogRead(analogPinLeft); // read the input pin
 val left += analogRead(analogPinLeft); // read the input pin
 val left = val left / 4;
 if (!(abs(val left - val left old) > Left Channel_Deviation)) {
 val left = val left old;
 if (val_left < val_left_old)
  leftDropTime++;
  if (leftDropTime > dropDelay)
   val left = val left old * dropFactor;
   leftDropTime = 0;
  }
  else
   val left = val left old;
 }
 val left old = val left;
 Signal Strength = val left - Base Left;
 if (Signal Strength < 0) { Signal Strength = - Signal Strength; }
```

```
VU Led Level = map(Signal Strength, 0, sensitivity, 0, Level Max Pixels);
 if (VU Led Level > Level Max Pixels)
    Overload = true;
    VU Led Level = Level Max Pixels;
  } else { Overload = false; }
 for(int i=0; i<Level Max Pixels; i++) { strip.setPixelColor(i, 0,0,0); } // Clear pixel's
color (in RAM)
 for(int i=0; i<VU Led Level; i++) { // For each pixel in strip...
  hue = map(i, Level Max Pixels -1,0,0,21800);
  if (Overload) { rgbcolor = strip.Color(255,0,0); } else { rgbcolor =
strip.ColorHSV(hue, 255, BRIGHTNESS); } // Hue to RGB Conversation
  strip.setPixelColor(i, rgbcolor);
                                    // Set pixel's color (in RAM)
// strip.show(); // Update strip to match
void colorWipe(uint32 t color, int wait) {
 for(int i=0; i<strip.numPixels(); i++) { // For each pixel in strip...
  strip.setPixelColor(i, color); // Set pixel's color (in RAM)
  strip.show();
                               // Update strip to match
  delay(wait);
                               // Pause for a moment
 }
}
void Right VU Meter(byte Level Max Pixels, int sensitivity)
 int val right = 0;
 bool Overload = false;
 uint32 t rgbcolor;
 uint32 thue;
 int Signal Strength = 0;
 byte VU Led Level = 0;
 val right = analogRead(analogPinRight); // read the input pin
 val right += analogRead(analogPinRight); // read the input pin
 val right += analogRead(analogPinRight); // read the input pin
 val right += analogRead(analogPinRight); // read the input pin
 val right = val right / 4;
 if (!(abs(val right - val right old) > Right Channel Deviation)) {
 val right = val right old;
 if (val right < val right old)
  rightDropTime++;
  if (rightDropTime > dropDelay)
    val right = val right old * dropFactor;
   rightDropTime = 0;
  }
  else
```

```
val right = val right old;
  }
 val right old = val right;
 Signal Strength = val right - Base Right;
 if (Signal Strength < 0) { Signal Strength = - Signal Strength; }
 VU Led Level = map(Signal Strength, 0, sensitivity, 0, Level Max Pixels);
 if (VU Led Level > Level Max Pixels)
    Overload = true;
    VU Led Level = Level Max Pixels;
  } else { Overload = false; }
 int ColorVector = 0;
 for(int i=LED COUNT-Level Max Pixels; i<LED COUNT; i++) {
strip.setPixelColor(i, 0,0,0); } // Clear pixel's color (in RAM)
 int StartVector = LED COUNT - VU Led Level;
 for(int i=LED COUNT-Level Max Pixels; i<LED COUNT; i++) { // For each pixel
in strip...
 hue = map(ColorVector, Level Max Pixels -1,0, 21800, 0);
 ColorVector++;
 if ( i >=StartVector)
  if (Overload) { rgbcolor = strip.Color(255,0,0); } else { rgbcolor =
strip.ColorHSV(hue, 255, BRIGHTNESS); } // Hue to RGB Conversation
  strip.setPixelColor(i, rgbcolor); // Set pixel's color (in RAM)
}
void rainbowFade2White(int wait, int rainbowLoops, int whiteLoops) {
 int fadeVal=0, fadeMax=100;
 // Hue of first pixel runs 'rainbowLoops' complete loops through the color
 // wheel. Color wheel has a range of 65536 but it's OK if we roll over, so
 // just count from 0 to rainbowLoops*65536, using steps of 256 so we
 // advance around the wheel at a decent clip.
 for(uint32 t firstPixelHue = 0; firstPixelHue < rainbowLoops*65536;
  firstPixelHue += 256) {
  for(int i=0; i<strip.numPixels(); i++) { // For each pixel in strip...
   // Offset pixel hue by an amount to make one full revolution of the
   // color wheel (range of 65536) along the length of the strip
   // (strip.numPixels() steps):
   uint32 t pixelHue = firstPixelHue + (i * 65536L / strip.numPixels());
   // strip.ColorHSV() can take 1 or 3 arguments: a hue (0 to 65535) or
   // optionally add saturation and value (brightness) (each 0 to 255).
   // Here we're using just the three-argument variant, though the
   // second value (saturation) is a constant 255.
   strip.setPixelColor(i, strip.gamma32(strip.ColorHSV(pixelHue, 255,
     255 * fadeVal / fadeMax)));
  strip.show();
  delay(wait);
```

```
if(firstPixelHue < 65536) {
                                                 // First loop,
  if(fadeVal < fadeMax) fadeVal++;</pre>
                                                      // fade in
 } else if(firstPixelHue >= ((rainbowLoops-1) * 65536)) { // Last loop,
  if(fadeVal > 0) fadeVal--;
                                                 // fade out
 } else {
  fadeVal = fadeMax; // Interim loop, make sure fade is at max
for(int k=0; k<whiteLoops; k++) {
 for(int j=0; j<256; j++) { // Ramp up 0 to 255
  // Fill entire strip with white at gamma-corrected brightness level 'j':
  strip.fill(strip.Color(0, 0, 0, strip.gamma8(j)));
  strip.show();
 for(int j=255; j>=0; j--) { // Ramp down 255 to 0
  strip.fill(strip.Color(0, 0, 0, strip.gamma8(j)));
  strip.show();
```

Es ist beim Betrieb zu beachten, das während des Einschaltens des VU Meters und dem Abspielen des Intros die virtuelle Nulllinie eingelesen wird. Damit diese Kalibrierung korrekt ablaufen kann, ist es wichtig, während der Einschaltphase noch kein Audio Signal anzulegen. Erst wenn die Startanimationen beendet sind, kann ein Analogsignal angelegt werden.

Ich wünsche viel Spaß beim Nachbauen bis zum nächsten Mal