

Kudos borderless calibration — A5 landscape — the folded-A6 sheet (210 × 148 mm)

Canon PRO-310: print this page on the card stock from Acrobat/Preview at 100% / "Actual size", Borderless ON, media type set as you print cards, Amount of Extension where you normally leave it.

Then read it:

1. Red frame = 0.5 mm from the page edge. Blue frames = 1, 2, 3, 4, 5 mm.
The innermost frame that is fully visible on all four sides is roughly how much each edge loses.
2. The tick rulers count millimetres from each edge (long tick every 5 mm, number every 10 mm).
Hold a ruler against the card edge and read the first visible tick for a precise figure per edge.
3. Repeat once with the driver's borderless expansion set to its minimum and note both results.

Record the loss per edge. Enter the LONG-edge figure (left/right on this landscape sheet) in Admin !' Print setup !' "Borderless overhang". The PDF then draws each card fractionally smaller so the trim lands on the paper edge after the printer's enlargement, and what is cut off is background.



Kudos borderless calibration — A6 (105 × 148 mm)

Canon PRO-310: print this page on the card stock from Acrobat/Preview at 100% / "Actual size", Borderless ON, media type set as you print cards, Amount of Extension where you normally leave it.

Then read it:

1. Red frame = 0.5 mm from the page edge. Blue frames = 1, 2, 3, 4, 5 mm.

The innermost frame that is fully visible on all four sides is roughly how much each edge loses.

2. The tick rulers count millimetres from each edge (long tick every 5 mm, number every 10 mm).

Hold a ruler against the card edge and read the first visible tick for a precise figure per edge.

3. Repeat once with the driver's borderless expansion set to its minimum and note both results.

Record the loss per edge. Enter the LONG-edge figure (left/right on this landscape sheet) in

Admin ! Print setup ! "Borderless overhang". The PDF then draws each card fractionally smaller so the trim lands on the paper edge after the printer's enlargement, and what is cut off is background.

Kudos borderless calibration — A4 landscape — a folded-A5 sheet (297 × 210 mm)

Canon PRO-310: print this page on the card stock from Acrobat/Preview at 100% / "Actual size", Borderless ON, media type set as you print cards, Amount of Extension where you normally leave it.

Then read it:

1. Red frame = 0.5 mm from the page edge. Blue frames = 1, 2, 3, 4, 5 mm.
The innermost frame that is fully visible on all four sides is roughly how much each edge loses.
2. The tick rulers count millimetres from each edge (long tick every 5 mm, number every 10 mm).
Hold a ruler against the card edge and read the first visible tick for a precise figure per edge.
3. Repeat once with the driver's borderless expansion set to its minimum and note both results.

Record the loss per edge. Enter the LONG-edge figure (left/right on this landscape sheet) in Admin !' Print setup !' "Borderless overhang". The PDF then draws each card fractionally smaller so the trim lands on the paper edge after the printer's enlargement, and what is cut off is background.

