REMAINING THICKNESS CALCULATION

CORPOSION MODEL

23 W = K T FACTOR WEIGHT LOSS

OF SPECIMEN

FACTOR PER LENGTH

(07/ft²)

PER THICKNESS.

THIS UNIT

ORIGINAL WEIGHT, WOR = STEEL X INITIAL THICKNESS

REMAINING WETGHT, WREMAIN = WORL - WREMAIN.

REMAINING THICKNESS, TREMAIN = WREMAIN
XCTEEL