# 飞燕SDK的MQTT通道压测指导文档

#### MQTT通道压测要求:

MQTT通道压测问题的分析方法:

日志分析工具

错误码errno的值

# MQTT通道压测要求:

- 1. 设备端log级别必须是DEBUG级别,出现问题方便分析;
- 2. 压测的物模型使用模组认证的标准物模型;
- 同时至少要有两个设备连接同一个路由器进行对比压测,最好还能有一个稳定可靠的陪测设备,用于排除网络环境问题;
- 4. 设备要保存完整压测过程的日志,方便出现问题之后分析定位;

# MQTT通道压测问题的分析方法:

- 1. 查看压测工具后台是否有离线情况;
- 2. 搜索设备端日志,关键字: disconnect 不匹配大小写进行搜索;
- 3. 查看disconnect附件的日志信息,主要三个原因出现disconnect
- 第一种是网络异常,查看errno的值,类似下面的日志信息,可以查看errno.h文件或者查看本文后面的 errno的内容来分析错误码的意思

```
[02-27 10:26:47]mbedtls_net_send 384: net send failed - errno: 11
[02-27 10:26:58]mbedtls_net_send 384: net send failed - errno
[02-27 15:05:12]mbedtls_net_send 384: net send failed - errno: 103
[02-27 17:35:49]mbedtls_net_send 384: net send failed - errno: 11
[02-25 18:45:29]mbedtls net recv 352; net recv failed - errno: 103
[02-25 18:45:29]mbedtls net send 384: net send failed - errno: 103
[02-25 18:45:28]mbedtls_net_recv 352: net recv failed - errno: 103
[02-25 18:45:28]mbedtls_net_send 384: net send failed - errno: 103
[02-27 10:26:48]mbedtls_net_send 384: net send failed - errno: 11
[02-27 10:26:59]mbedtls_net_send 384: net send failed - errno: 11
[02-27 17:23:40]mbedtls net send 384; net send failed - errno: 11
[02-27 17:35:49]mbedtls net send 384: net send failed - errno: 11
[02-25 18:45:31]mbedtls_net_recv 352: net recv failed - errno: 103
[02-25 18:45:31]mbedtls_net_send 384: net send failed - errno: 103
[02-27 18:40:03]mbedtls_net_recv 352: net recv failed - errno: 103
[02-27 18:40:03]mbedtls_net_send 384: net send failed - errno: 103
```

第二种是MQTT Client里面连续两次以上没有收到MQTT的心跳回复(通常30秒一次心跳),SDK会主动断线重连,出现类似下面的日志,这种问题的原因通常是设备端出现了接收数据异常,云端发送的数据上层已经接收不到,原因通常可能是Iwip层异常,可能需要厂家抓包分析:

```
52 [17:11:49.808] [0m[[1;36m[dbg] _iotx_linkkit_event_callback(435): Current Devid: 0
53 [17:11:49.827] [[0mc][1;36m[dbg] _iotx_linkkit_event_callback(436): Current Payload: {"LightSwitch":0} 54 [17:11:49.827] [[0m03-03 17:11:50.103 D/linkk[17:11:49.869] it: Property Set Received, Devid: 0, Request
 55 [17:11:49.869] 03-03 17:11:50.113 D/linkkit: Post Property Message ID: 10021
 56 [17:11:49.869] [17:11:59.979] □[1;33m[inf] _iotx_linkkit_event_callback(235): Receive Message Type: 30
57 [17:11:59.979] [[0m[[1;33m[inf] _iotx_linkkit_event_callback(237): R[17:12:00.007] eceive Message: {"ic 58 [17:12:00.007] [[0m[[1;36m[dbg] _iotx_linkkit_event_callback(525): Current Id: 10021 [17:12:00.007] [[0m[[1;36m[dbg] _iotx_linkkit_event_callback(526): Current Code: 100000 [17:12:00.007] [[0m[[1;36m[dbg] _iotx_linkkit_event_callback(526): Current Code: 100000 [17:12:00.007] [[0m[[1:36m[dbg] _iotx_linkkit_event_callback(527): Current Code: 100000 [17:12:00.007] [[0m[[1:36m[db] _iotx_linkkit_event_callback(527): Current Code: 100000 [17:12:00.007] [[0m[[1:36m[db] _iotx_linkkit_event_callback(527): Current Code: 100000 [[0m[
 60 [17:12:00.007] [[0m[[1;36m[dbg] _iotx_linkkit_event_callback(527): Current Devid: 0 61 [17:12:00.007] [[0m[17:12:00.063] 03-03 17:12:00.285 D/linkkit: Message Post Reply Received, Devid: 0,
 62 [17:12:00.063] [17:12:05.940] \Box[1;36m[dbg] MQTTKeepalive(396): len = MQTTSerialize pingreq() = 2
 63 [17:12:05.940] [0m[[1;33m[inf] iotx_mc_keepalive_sub(3033): send MQTT ping...
 66 [17]:12:36.120] □[0m[17:13:06.287] □[\overline{1};3\overline{0}m[dbg] MQ\overline{1}TKeepalive(396): len = MQ\overline{1}TSerialize pingreq() = 2
 67[17:13:06.287] □[0m□[1;33m[inf] iotx_mc_keepalive_sub(3033): send MQTT ping...
 70 [17:13:06.582] □[0m□[1:33m[inf] iotx cloud conn mqtt event handle(87): disconnected,fd = 0
73 [17:13:06.582] [[0m[17:13:06.658] [[1;31m[err] IOT_MQTT_Yield(3249): error occur rc=-27
 74 [17:13:06.658] □[0m[17:13:06.754] □[1;33m[inf] _iotx_linkkit_event_callback(235): Receive Message Type:
 75 [17:13:06.754] [0m03-03 17:13:07.028 D/linkkit: Cloud Disconnected
```

• 第三种是网络驱动层异常,不同的模组厂家有不同的错误日志

# 日志分析工具

参考tools文件夹里面的log\_extract.sh日志提取脚本

# 错误码errno的值

```
1
                          1 /* Operation not permitted */
2 #define EPERM
3 #define
           ENOENT
                          2
                            /* No such file or directory */
4 #define
                            /* No such process */
           ESRCH
                          3
5 #define
           EINTR
                          4
                            /* Interrupted system call */
6 #define
           EI0
                          5
                            /* I/O error */
                             /* No such device or address */
7 #define
           ENXI0
8 #define E2BIG
                          7
                             /* Arg list too long */
9 #define ENOEXEC
                          8
                             /* Exec format error */
10 #define EBADF
                          9
                             /* Bad file number */
11 #define
           ECHILD
                         10
                             /* No child processes */
12 #define
           EAGAIN
                         11
                             /* Try again */
13 #define
           ENOMEM
                         12
                            /* Out of memory */
14 #define EACCES
                         13
                             /* Permission denied */
15 #define EFAULT
                         14
                            /* Bad address */
16 #define ENOTBLK
                         15
                            /* Block device required */
17 #define EBUSY
                            /* Device or resource busy */
                         16
18 #define EEXIST
                         17
                            /* File exists */
```

```
19 #define EXDEV
                           /* Cross-device link */
20 #define ENODEV
                        19
                           /* No such device */
21 #define
           ENOTDIR
                        20
                           /* Not a directory */
22 #define EISDIR
                           /* Is a directory */
                        21
23 #define EINVAL
                        22
                           /* Invalid argument */
24 #define ENFILE
                        23
                           /* File table overflow */
25 #define EMFILE
                            /* Too many open files */
                        24
26 #define ENOTTY
                        25
                           /* Not a typewriter */
27 #define ETXTBSY
                        26
                           /* Text file busy */
28 #define
                            /* File too large */
           EFBIG
                        27
29 #define
           ENOSPC
                        28
                           /* No space left on device */
30 #define ESPIPE
                            /* Illegal seek */
                        29
31 #define EROFS
                           /* Read-only file system */
                        30
32 #define EMLINK
                           /* Too many links */
                        31
33 #define EPIPE
                        32
                           /* Broken pipe */
34 #define EDOM
                        33
                            /* Math argument out of domain of func */
35 #define ERANGE
                            /* Math result not representable */
                        34
36 #define EDEADLK
                        35
                           /* Resource deadlock would occur */
37 #define ENAMETOOLONG 36
                           /* File name too long */
38 #define ENOLCK
                           /* No record locks available */
                        37
39 #define ENOSYS
                        38
                           /* Function not implemented */
40 #define ENOTEMPTY
                        39
                            /* Directory not empty */
41 #define ELOOP
                            /* Too many symbolic links encountered */
                        40
42 #define EWOULDBLOCK EAGAIN /* Operation would block */
43 #define ENOMSG
                        42
                           /* No message of desired type */
44 #define EIDRM
                           /* Identifier removed */
                        43
45 #define ECHRNG
                           /* Channel number out of range */
                        44
46 #define EL2NSYNC
                           /* Level 2 not synchronized */
                        45
47 #define EL3HLT
                           /* Level 3 halted */
                        46
48 #define
                        47
                           /* Level 3 reset */
           EL3RST
49 #define ELNRNG
                        48
                           /* Link number out of range */
50 #define EUNATCH
                           /* Protocol driver not attached */
                        49
51 #define ENOCSI
                        50
                           /* No CSI structure available */
                           /* Level 2 halted */
52 #define EL2HLT
                        51
53 #define EBADE
                           /* Invalid exchange */
                        52
                            /* Invalid request descriptor */
54 #define EBADR
                        53
55 #define EXFULL
                        54
                           /* Exchange full */
56 #define ENOANO
                           /* No anode */
                        55
57 #define EBADRQC
                           /* Invalid request code */
                        56
58 #define
           EBADSLT
                        57 /* Invalid slot */
```

```
59
60 #define EDEADLOCK
                        EDEADLK
61
                            /* Bad font file format */
62 #define
           EBFONT
                        59
63 #define ENOSTR
                            /* Device not a stream */
                        60
64 #define ENODATA
                        61
                           /* No data available */
65 #define ETIME
                        62
                            /* Timer expired */
66 #define ENOSR
                            /* Out of streams resources */
                        63
67 #define ENONET
                            /* Machine is not on the network */
                        64
68 #define
                            /* Package not installed */
           ENOPKG
                        65
69 #define
           EREMOTE
                        66
                            /* Object is remote */
70 #define ENOLINK
                            /* Link has been severed */
                        67
71 #define EADV
                            /* Advertise error */
                        68
72 #define ESRMNT
                           /* Srmount error */
                        69
73 #define ECOMM
                            /* Communication error on send */
                        70
74 #define EPROTO
                        71
                           /* Protocol error */
75 #define EMULTIHOP
                            /* Multihop attempted */
                        72
76 #define EDOTDOT
                            /* RFS specific error */
                        73
77 #define EBADMSG
                        74
                            /* Not a data message */
78 #define EOVERFLOW
                            /* Value too large for defined data type
                        75
   */
79 #define ENOTUNIQ
                        76
                           /* Name not unique on network */
80 #define
                            /* File descriptor in bad state */
           EBADFD
                        77
81 #define EREMCHG
                            /* Remote address changed */
                        78
82 #define ELIBACC
                        79
                            /* Can not access a needed shared library
  */
83 #define ELIBBAD
                            /* Accessing a corrupted shared library
                        80
   */
84 #define ELIBSCN
                        81
                            /* .lib section in a.out corrupted */
85 #define ELIBMAX
                            /* Attempting to link in too many shared
                        82
   libraries */
86 #define ELIBEXEC
                            /* Cannot exec a shared library directly
                        83
   */
87 #define EILSEQ
                            /* Illegal byte sequence */
                        84
88 #define ERESTART
                            /* Interrupted system call should be rest
                        85
  arted */
89 #define ESTRPIPE
                        86
                           /* Streams pipe error */
90 #define EUSERS
                            /* Too many users */
                        87
91 #define ENOTSOCK
                        88
                            /* Socket operation on non-socket */
92 #define EDESTADDRREQ 89 /* Destination address required */
```

```
93 #define EMSGSIZE 90 /* Message too long */
 94 #define EPROTOTYPE
                         91 /* Protocol wrong type for socket */
 95 #define ENOPROTOOPT 92 /* Protocol not available */
 96 #define EPROTONOSUPPORT 93 /* Protocol not supported */
 97 #define ESOCKTNOSUPPORT 94 /* Socket type not supported */
 98 #define EOPNOTSUPP
                            95 /* Operation not supported on transpor
   t endpoint */
 99 #define EPFNOSUPPORT
                            96 /* Protocol family not supported */
                            97 /* Address family not supported by pro
100 #define EAFNOSUPPORT
   tocol */
101 #define EADDRINUSE
                            98 /* Address already in use */
102 #define EADDRNOTAVAIL
                          99 /* Cannot assign requested address */
103 #define ENETDOWN
                           100 /* Network is down */
104 #define ENETUNREACH
                           101 /* Network is unreachable */
105 #define ENETRESET
                           102 /* Network dropped connection because
    of reset */
106 #define ECONNABORTED
                           103 /* Software caused connection abort */
107 #define ECONNRESET
                           104 /* Connection reset by peer */
108 #define ENOBUFS
                           105 /* No buffer space available */
109 #define EISCONN
                           106 /* Transport endpoint is already conne
   cted */
110 #define ENOTCONN
                           107 /* Transport endpoint is not connected
   */
                           108 /* Cannot send after transport endpoin
111 #define ESHUTDOWN
   t shutdown */
112 #define ETOOMANYREFS
                           109 /* Too many references: cannot splice
    */
113 #define ETIMEDOUT
                           110 /* Connection timed out */
114 #define ECONNREFUSED
                           111 /* Connection refused */
115 #define EHOSTDOWN
                           112 /* Host is down */
116 #define EHOSTUNREACH
                           113 /* No route to host */
117 #define EALREADY
                           114 /* Operation already in progress */
118 #define EINPROGRESS
                           115 /* Operation now in progress */
                           116 /* Stale NFS file handle */
119 #define ESTALE
120 #define EUCLEAN
                           117 /* Structure needs cleaning */
121 #define ENOTNAM
                           118 /* Not a XENIX named type file */
122 #define ENAVAIL
                           119 /* No XENIX semaphores available */
123 #define EISNAM
                           120 /* Is a named type file */
124 #define EREMOTEIO
                           121 /* Remote I/O error */
125 #define ED0U0T
                           122 /* Quota exceeded */
```

```
126
127 #define ENOMEDIUM 123 /* No medium found */
128 #define EMEDIUMTYPE 124 /* Wrong medium type */
129
130
131 #define ENSROK
                                   0 /* DNS server returned answer w
   ith no data */
132 #define ENSRNODATA
                                 160 /* DNS server returned answer w
   ith no data */
133 #define ENSRFORMERR
                                161 /* DNS server claims query was
    misformatted */
134 #define ENSRSERVFAIL
                                 162 /* DNS server returned general
    failure */
135 #define ENSRNOTFOUND
                                 163 /* Domain name not found */
136 #define ENSRNOTIMP
                                 164 /* DNS server does not implemen
  t requested operation */
137 #define ENSRREFUSED
                                  165 /* DNS server refused query */
138 #define ENSRBADOUERY
                                 166 /* Misformatted DNS query */
139 #define ENSRBADNAME
                                  167 /* Misformatted domain name */
140 #define ENSRBADFAMILY
                                  168 /* Unsupported address family
    */
141 #define ENSRBADRESP
                                 169 /* Misformatted DNS reply */
142 #define ENSRCONNREFUSED
                                 170 /* Could not contact DNS server
   s */
143 #define ENSRTIMEOUT
                                 171 /* Timeout while contacting DNS
   servers */
144 #define ENSROF
                                  172 /* End of file */
145 #define ENSRFILE
                                 173 /* Error reading file */
146 #define ENSRNOMEM
                                  174 /* Out of memory */
147 #define ENSRDESTRUCTION
                                 175 /* Application terminated looku
   p */
148 #define ENSRQUERYDOMAINTOOLONG 176 /* Domain name is too long */
149 #define ENSRCNAMELOOP
                                  177 /* Domain name is too long */
```