



COSMO INSTRUMENTS (I) PVT. LTD.

SPECIALIST IN AIR LEAK AND FLOW TEST



MOVELET INLINE TESTER

MODEL MV-6000B

ERROR AND TROUBLESHOOTING MANUAL

1 Logs and Messages

1.1 Details of Logs

Log no.	Explanation	Countermeasure
00	Normally processed	—
1E	Failure in creating the window	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
35	Failure of securing a buffer during memory management	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
36	Failure of releasing a buffer during memory management	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
55	Failure of securing a buffer during sampling	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
57	Destination folder name error	There may be a problem in the setting of the destination. Correct the folder name. Check that the USB storage device has been inserted.
5E	Access error during sampling, Error in saving the .wav file	There may be an incorrect parameter setting. Check the parameter settings (filter setting, waveform saving definition). Check that the USB storage device has been inserted.
5F	Parameter inspection error	There may be an incorrect parameter setting. Check the parameter settings (item setting, channel setting, filter setting).
63	Read error during analysis processing	There may be an incorrect parameter setting. Check the parameter setting (filter setting).
65	Failure of securing a buffer during analysis processing	If this log number is repeatedly displayed even during re-inspection, reboot the system.
6B	Other errors during analysis processing	There may be an incorrect parameter setting. Check the parameter setting (filter setting).
6F	Analysis error during analysis processing	There may be an incorrect parameter setting. Check the parameter setting (filter setting).
8F	Digital output error during virtual input	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
91	Failure of opening the device during serial communication	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
92	Failure of closing the device during serial communication	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
93	Read error during serial communication processing	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
95	Failure of securing a buffer during serial communication processing	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
9A	Range over during serial communication processing	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
9B	Other errors during serial communication processing	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
A1	Failure in opening the device handle of the AD	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
A2	Failure in closing the device handle of the AD	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
A3	Read error in the AD device	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.

Log no.	Explanation	Countermeasure
A5	Failure of securing a buffer in the AD	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
AA	Range over during sampling from the AD	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
AB	Other errors in the AD	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
C5	Failure of securing a buffer during setting	If this log number is repeatedly displayed even during re-inspection, reboot the system.
C3	Read error during setting	A parameter setting may not yet have been made, or it may be broken. Check the parameter settings (item setting, channel setting, filter setting).
CA	Range over of the read value during setting	A parameter setting may not yet have been made, or it may be broken. Check the parameter settings (item setting, channel setting, filter setting).
D1	Failure of opening the device in the DIO	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
D2	Failure of closing the device in the DIO	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
D3	Read error in the DIO device	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
D4	Write error in the DIO device	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
DA	Range over of the read value in the DIO	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
DB	Other errors in the DIO	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
E1	Digital output error in the AD	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
F1	Failure in initializing WatchDog	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
F2	Failure in setting WatchDog	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
F4	Failure in resetting WatchDog	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.
F8	Failure in disabling WatchDog	If these log numbers are repeatedly displayed even during re-inspection, reboot the system.

NOTE: The log no. is “00” when the process is normally completed. If a log no. other than “00” is displayed even after a countermeasure is executed, contact COSMO.

2 MV-6000B Messages

No.	Displayed message	Details
1	The item number or parameter is not correct.	Displayed when the entered parameter value is not correct. Check the set parameter value.
2	Signal input cannot be started.	Displayed when there is an abnormality in signal input and measurement cannot be started. Check the connection of the sensor cable and the gain setting.
3	The analysis or judgment could not be executed.	Displayed when there is an abnormality in the analysis or judgment and the analysis or judgment cannot be executed. Check the connection of the sensor cable and the gain setting.
4	There is an abnormality in the input signal. Check the connection and the gain setting.	Displayed when there is an abnormality in the input signal. Check the connection of the sensor cable and the gain setting.
5	The .wav file cannot be saved.	Displayed when the .wav file cannot be saved. There may be a problem in the setting of the save destination folder.
6	Check the setting of the save destination folder.	Check the setting of the save destination folder.
7	Remove the device.	Displayed when the process for the safe removal of the USB device is complete; it is OK to remove the device.
8	There is no removable device.	Displayed when no removable device is connected.
9	There is no waveform data.	No .wav file is saved.
10	There is a range error in the input value.	Displayed when the entered parameter value is out of range.
11	The data file for the specified item does not exist.	Parameters for the specified item are not set.
12	The entered data is out of the settable range.	Displayed when the entered parameter value is not correct. Check the set parameter value.

3 MvPrEdit Messages

No.	Displayed message	Displayed button	Details
1	The entered data is not correct.	OK	The entered parameter value is not correct.
2	The entered data is out of the settable range.	OK	A parameter input range error has occurred.
3	The specified item number has been already registered.	OK	The item number specified when adding/modifying the item information has been already registered.
4	Select an item number.	OK	No item is selected for CSV output.
5	An error occurred when reading the item management file.	OK	Reading the item management file failed.
6	An error occurred when reading the parameter file.	OK	Reading the parameter file failed or the specified file is not a parameter file.
7	The item management file does not exist.	OK	The item management file does not exist in the specified folder.
8	The filter management file does not exist.	OK	The filter management file does not exist in the specified folder.
9	The parameter file does not exist.	OK	The parameter file does not exist in the specified folder.
10	An error occurred when writing to the item management file.	OK	An error occurred during the saving operation when writing to the item management file.
11	An error occurred when writing to the filter file for the CH.	OK	An error occurred during the saving operation when writing to the filter file.
12	An error occurred when writing to the parameter file.	OK	An error occurred during the saving operation when writing to the parameter file.
13	An error occurred when writing to the waveform data saving environment file.	OK	An error occurred during the saving operation when writing to the waveform data saving environment file.
14	An error occurred when deleting the item management file.	OK	A deletion error occurred when cleaning up the management folder.
15	Memory cannot be secured.	OK	Memory supplied by the OS is lacking.
17	The specified path name is invalid or you do not have the access rights.	OK	The user who started the program does not have the access rights to the folder.
18	Item parameters are updated. Save the current parameters?	Yes / No / Cancel	New, Open, or Exit is selected during editing.
19	An item management file already exists in the specified folder. Would you like to overwrite it?	Yes / No / Cancel	An item management file already exists in the folder where you are going to save the file.
20	An item management file already exists in the specified folder. Would you like to delete it?	Yes / No / Cancel	An item management file already exists in the folder specified for New.
21	Would you like to delete the selected item?	OK / Cancel	This is a confirmation in the item information "Delete" operation.
22	Would you like to delete the selected filter parameters?	OK / Cancel	This is a confirmation in the filter information "Delete" operation.
23	There is no parameter to be set.	OK	There is no parameter to be set for the selected criterion for judgment.
24	No judgment condition is selected.	OK	No NG judgment condition is selected.
25	The data acquisition time was changed. A CH-info. (data time) is also changed.	OK	This is a confirmation that the data acquisition time in the item information has been changed.

No.	Displayed message	Displayed button	Details
26	An error occurred during the output of the .csv file. Error No. = ##### XXXXXXXXXXXXXXXXXXXXXXXXXXXX	OK	File write error (such as, it is being used by another application, etc.)
27	No judgment item number is specified in the judgment formula.	OK	No judgment item number for the filter is specified in the judgment formula.
28	There is an error in the use of parentheses in the judgment formula.	OK	There is no parenthesis of the block end corresponding to the parenthesis of the block start.
29	There is an error in the structure of the judgment formula.	OK	There is an exception in the description format in the judgment formula.
30	An invalid judgment item number is specified in the judgment formula.	OK	A number other than 1 through 8 is specified as the judgment item number.
31	The system will be rebooted in order to reflect the updated parameters.	OK	This message is displayed when MvPrEdit is shutdown.
32	Quitting processes are in progress. Please wait for a while.	-	This message is displayed when MvPrEdit is shutdown.
33	The item number has not been input.	OK	The item number has not been input.
34	The same item number exists.	OK	The same item number exists.
35	The entered data is out of the settable range.	OK	The entered data is out of the settable range.
36	Copying has been completed.	OK	Copying the specified item number has been completed.