

Here's a general procedure for drawing contour maps in AutoCAD using Google Earth Pro, TCX Converter, QuikGrid, Surfer, and AutoCAD:

1. ****Obtain Data****:
 - Use Google Earth Pro to identify the area you want to map.
 - Use the tools in Google Earth Pro to capture the desired area and export it as a KML or KMZ file.
2. ****Convert KML/KMZ to TCX****:
 - Use TCX Converter to convert the KML/KMZ file to a TCX file format, which is compatible with QuikGrid.
3. ****Create Grid File****:
 - Open QuikGrid and import the TCX file.
 - Generate a grid file from the imported data.
4. ****Generate Contour Lines****:
 - Use QuikGrid to generate contour lines from the grid file.
 - Adjust contour intervals and other parameters as needed.
5. ****Export Contour Data****:
 - Export the contour lines as a DXF file format, which can be imported into Surfer and AutoCAD.
6. ****Visualize in Surfer****:
 - Open Surfer and import the DXF file containing the contour lines.
 - Customize the appearance of the contour map in Surfer, including colors, line styles, and labels.
7. ****Export Contour Map****:
 - Export the contour map from Surfer as a DXF or another compatible file format.
8. ****Import into AutoCAD****:
 - Open AutoCAD and import the contour map file.
 - Adjust the scale, orientation, and position of the contour map within your AutoCAD drawing.
9. ****Finalize Drawing****:
 - Overlay additional features, annotations, or other relevant information onto the contour map within AutoCAD.
 - Verify the accuracy and completeness of the contour map before finalizing the drawing.
10. ****Save and Share****:
 - Save your AutoCAD drawing containing the contour map.
 - Share the completed contour map drawing as needed with stakeholders or collaborators.

Remember, each software may have specific steps and options that may vary slightly. Be sure to refer to the respective software's documentation for detailed instructions.