

```
File Edit Tabs Help
pi@raspberrypi:~$ sudo i2cdetect -y 1
    0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
10:  --  --  --  --  --  --  --  --  --  --  --  1c  --  --  --
20:  --  --  --  --  --  --  --  --  29  --  --  --  --  --  --
30:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
40:  --  --  --  --  --  UU  --  --  --  --  --  --  --  --  --
50:  --  --  --  --  --  --  --  --  --  --  --  5c  --  --  5f
60:  --  --  --  --  --  --  --  --  --  6a  --  --  --  --  --
70:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
pi@raspberrypi:~$
```

```
File Edit Tabs Help
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 1 mm
Distance: 0 mm
Distance: 2 mm
Distance: 2 mm
Distance: 1 mm
Distance: 1 mm
Distance: 2 mm
Distance: 2 mm
Distance: 1 mm
Distance: 1 mm
Distance: 2 mm
Distance: 2 mm
Distance: 4 mm
Distance: 4 mm
Distance: 4 mm
Distance: 4 mm
Distance: 9 mm
Distance: 10 mm
Distance: 10 mm
Distance: 0 mm
Distance: 0 mm
Distance: 3 mm
Distance: 3 mm
Distance: 3 mm
```

Name:-Kush Patel
Sensor: VL53L1X
Distance Sensor
I²C Address: 0x29
VL53L1X Mounted
to Hardware Case

