

National Access Point SOAP Client User Manual

Version: 1.0

Date: 15-4-2026

Introduction

The National Access Point (NAP) SOAP Client is a desktop application used to submit electronic Certificates of Conformity (eCoCs) in the InitialVehicleInformation XML format to a national access point. This document provides step-by-step instructions for using the tool.

Installation

The file can be downloaded as a .zip file. Store the file on your system and unzip the .zipfile. Start NapClient.exe

Application Overview

Below is a screenshot of the main interface of the NAP SOAP Client:

The screenshot shows the main interface of the 'National Access Point SOAP Client' application. The window title is 'NAP Client - National Access Point SOAP Client'. The interface includes the following elements:

- SOAP Endpoint URL:** A text field containing 'https://ecocproxy.otrdw.nl/InitialVehicleInformation.svc' with a dropdown arrow and a settings icon.
- XML File to Send:** A text field containing 'C:\NAP\EUCAR1SMULT1VERS1-St1V1.xml' with a file selection icon.
- Client Certificate (for authentication):** A text field containing 'RDW Diensten - (Expires: 2027-11-11)' with a 'BROWSE' button.
- Signing Certificate (for XML signing):** A text field containing 'lviSigning.rdw.nl (Expires: 2029-10-28)' with a 'BROWSE' button.
- Enable XML signing:** A checkbox that is checked.
- VIEW SIGNED XML:** A blue button.
- SUBMIT TO SOAP ENDPOINT:** A large blue button.
- Success - Status: 200:** A green checkmark indicating a successful submission.
- Response:** A text area displaying the XML response, with 'EXPORT XML' and 'EXPORT RESPONSE' buttons above it.

The XML response is as follows:

```
<s:Envelope xmlns:s="http://schemas.xmlsoap.org/soap/envelope/">
  <s:Body>
    <UploadIviDataResponse xmlns="http://ecoc.eucaris.net/">
      <IsValid>true</IsValid>
      <CorrelationId>NLa29530a7-99c2-42b9-a007-03bffe5ff71d</CorrelationId>
    </UploadIviDataResponse>
  </s:Body>
</s:Envelope>
```

SOAP Endpoint URL

Enter the SOAP endpoint used to submit the signed eCoC XML file.

Environment	Endpoint
Acceptance	to be determined by NAP member state
Production	to be determined by NAP member state

eCoC File to Send

Use the green folder button to browse and select an InitialVehicleInformation XML file. Please note that the selected file does not include a soap envelope, this will be added by the tool.

Client Certificate (Authentication)

Select the authentication certificate required by the NAP SOAP service.

Signing Certificate (XML Signing)

Choose the certificate used to digitally sign the XML before submission.

Option:

☒ Enable XML signing

When enabled, the XML document is cryptographically signed before submission. Do not choose this option if the xml to be uploaded already contains a digital signature.

View (Signed) XML

Optionally, click the 'View (Signed) XML' button to preview the XML document.

Submit to SOAP Endpoint

Press the 'Submit to SOAP Endpoint' button to send the XML to the configured webservice.

Response Panel

The response panel displays the SOAP reply from the server. You can export both the XML request and the response using the provided buttons.