

JONES SPORT

ACCESSPORT MOUNT FITTING INSTRUCTIONS®

- 1. Remove existing mounting bracket from the backing plate and slot the mount into place. The fit should be firm but not require excessive pressure. If it is tight, lightly sand/deburr the slots get the best fit. This is more common on newer Cobb/Mountune APs',
- **2.** Push mount into the top 3rd of the upper aircon vent until it pops into place. Then lightly press down complete the fit.
- **3.** AP Cable should be routed down to the OBD Access door and through the door latch (Accessport end of cable fed from the inside out). The inner compartment can be removed to stow excess cable. The cable will naturally sit in the aircon vent and this aids with stability and adjustment.

You are now good to go. Enjoy!

If you have any feedback regarding the design and how to modify/improve it. Feel free to PM me via Facebook or shoot us an email at sambenjaminjones@outlook.com. Keep an eye out for more specialty parts for the focus and fiesta lines. This part is subject to copyright, Jones Sports Australia









