JONES SPORT

35 mm THROTTLE SPACER KIT FITTING INSTRUCTIONS



Thanks for ordering the Jones Sport 35 mm Throttle spacer kit. You will receive a spacer body, 2 stainless bushes and M6 washers and hardware. The installation will require the following tools:

TOOLS REQUIRED

- 10 mm Socket and ratchet
- Shifting spanner or appropriately size open-ended spanner
- 5 mm Allen Key
- Light for visibility

HOW TO INSTALL

- **1.** Begin by disconnecting the throttle from the car. The connector is located/hanging above the throttle pedal assembly under the dash.
- 2. Undo and remove the two M6 nuts holding the throttle pedal assembly to the firewall.
- **3.** Remove the throttle pedal and put to one side.
- **4.** Take the two provided stainless bushes and wind them by hand onto the studs in the firewall. Use the shifting spanner or spanner to wind them until they bottom out on the stud/base plate. Make sure they are firm with the spanner but not overtightened.
- 5. Take the main throttle spacer block and press onto the stainless bushes. Make sure the JS logo is facing towards the floor. Note there may be some slight misalignment of the studs and it may be fiddly to get started.
- **6.** Once slipped over the bushes, press down till the block is bottomed out on the firewall bracket and the top of the studs are flush with the top face of the spacer block.
- **7.** Hold the throttle pedal assembly up against the spacer block and take the first washer and M6 socket head and start winding it into the upper bush. Note that the OBD port door can be opened to visually see the upper threaded hole.
- **8.** Once the pedal is hanging off the upper socket head. Align the lower hole with the bush and add the second washer and cap head.
- 9. Tighten both down till firm.
- **10.** Reconnect the TPS wire/connector to complete the installation! The position usual takes a week or so to adapt to. But you will forget it is there until you need that heel toe action!

If you have any feedback regarding the design and how to modify/improve it. Feel free to PM me via Facebook or shoot us an email at sambenjaminjones@outlook.com. Keep an eye out for more specialty parts for the focus and fiesta lines. This part is subject to copyright, Jones Sports Australia