

Steering sine test — Full recording


1 Steering position command · observed C2 targets




2 Steering position feedback · A3



3 Steering velocity feedback · A2



4 Steering torque feedback · A1 current × B0 constant



Position reference: collector startup A3 zero; positive = right. Grey = outside recorded C2 interval. Torque is current-based, not a shaft-torque sensor.