PLAMABIOTICS
PlasmaTYPHOON Compatibility Table

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Fujifilm	EB-270P	Fg5 B70	301086	PED	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	EB-270S	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	EB-270T	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	EB-470P	Fg5 B70	301086	PED	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	EB-470S	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	EB-470T	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	EB-530H	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	EB-530P	Fg5W B-Bp	301098	PED	B01-034_3_302	Fg5W B-Bp	301098	BR-TC	B01-034_3_302
Fujifilm	EB-530S	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	EB-530T	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	EB-530US	Fg5W EB	301099	BRO	B01-035_3_302	Fg5W EB	301099	BR-EBUS	B01-035_3_302
Fujifilm	EB-530XT	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	EB-580S	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	EB-580T	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	EB-710P	F700 B-Bp	301100	BRO	B01-040_3_302	F700 B-Bp	301100	BR-SC	B01-040_3_302
Fujifilm	EB-710P	F700 B-Bp	301100	BRO	B01-040_3_302	F700 B-Bp	301100	BR-SC	B01-040_3_302
Fujifilm	EB-710XT	F700 B-Bp	301100	BRO	B01-040_3_302	F700 B-Bp	301100	BR-SC	B01-040_3_302
Fujifilm	EC-530DL	Fg5W 2C-G-D	301052	ECH	B01-028_3_302	Fg5W 2C-G-D	301052	GI-DOCWJ	B01-028_3_302
Fujifilm	EC-530DM	Fg5W 2C-G-D	301052	ECH	B01-028_3_302	Fg5W 2C-G-D	301052	GI-DOCWJ	B01-028_3_302
Fujifilm	EC-530FI	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-530FL	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-530LP	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EC-530MP	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EC-530WI3	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-530WL3	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-530WM	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-WJ	B01-001_3_303
Fujifilm	EC-530WM3	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-580RD L	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-580RD M	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-580RDL	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590MP	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590WI4	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590WL4	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590WM4	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590ZW/M	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590ZW3 L	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-590ZW3 M	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-600W-I	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-600WL	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-600WM	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-600ZWL	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-600ZW-M	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EC-720RI	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-720RL	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-720RM	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-740TL	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-740TM	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760P-VL	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760P-VM	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760R-VI	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760R-VL	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760R-VM	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760S-G/L	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760ZP-VL	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760ZP-VM	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-760ZV	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EC-L600ZP7	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	ED-530XT8	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	ED-580T	F700 C-G-D	301008	DIG	B01-002_3_304	F700 C-G-D	301008	GI-NWJ	B01-002_3_304
Fujifilm	ED-580XT	F700 C-G-D	301008	DIG	B01-002_3_304	F700 C-G-D	301008	GI-NWJ	B01-002_3_304
Fujifilm	EG-250WM	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EG-530CT	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EG-530D	Fg5W 2C-G-D	301052	ECH	B01-028_3_302	Fg5W 2C-G-D	301052	GI-DOCWJ	B01-028_3_302
Fujifilm	EG-530FP	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-530NP	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-530NW	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-530UR	Fg5 E530	301011	ECH	B01-005_3_302	Fg5 E530	301011	EUS-NEC	B01-005_3_302
Fujifilm	EG-530UR2	Fg5 E530	301011	ECH	B01-005_3_302	Fg5 E530	301011	EUS-NEC	B01-005_3_302
Fujifilm	EG-530UT	Fg5 E530	301011	ECH	B01-005_3_302	Fg5 E530	301011	EUS-NEC	B01-005_3_302
Fujifilm	EG-530UT2	Fg5 E530	301011	ECH	B01-005_3_302	Fg5 E530	301011	EUS-NEC	B01-005_3_302
Fujifilm	EG-530WR	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-580NWZ	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-580RD	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EG-580UR	Fg5 E580	301012	ECH	B01-006_3_302	Fg5 E580	301012	EUS-NEC	B01-006_3_302
Fujifilm	EG-580UT	Fg5 E580	301012	ECH	B01-006_3_302	Fg5 E580	301012	EUS-NEC	B01-006_3_302
Fujifilm	EG-590WR	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-590ZW	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-600WR	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EG-600ZW	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	EG-720R	F700 C-G-D	301008	DIG	B01-002_3_303	F700 C-G-D	301008	GI-NWJ	B01-002_3_303
Fujifilm	EG-740N	F700 C-G-D	301008	DIG	B01-002_3_303	F700 C-G-D	301008	GI-NWJ	B01-002_3_303
Fujifilm	EG-740UT	Fg5 E580	301012	ECH	B01-006_3_302	Fg5 E580	301012	EUS-NEC	B01-006_3_302
Fujifilm	EG-760CT	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EG-760R	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EG-760Z	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EG-840TP	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EG-L580NW7	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EG-L600ZW7	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	EI-580BT	F700 C-G-D	301008	ECH	B01-002_3_305	F700 C-G-D	301008	GI-WJ	B01-002_3_305
Fujifilm	EI-740 D/S	F700 2C-G-D	301037	ECH	B01-036_3_302	F700 2C-G-D	301037	GI-DOCWJ	B01-036_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Fujifilm	EN-450T5	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EN-450T5-20	Fg5W C-G-D	301007	DIG	B01-001_3_303	Fg5W C-G-D	301007	GI-NWJ	B01-001_3_303
Fujifilm	EN-580T	Fg5W C-G-D	301007	ECH	B01-001_3_304	Fg5W C-G-D	301007	GI-WJ	B01-001_3_304
Fujifilm	EN-580XP	Fg5W C-G-D	301007	ECH	B01-001_3_304	Fg5W C-G-D	301007	GI-WJ	B01-001_3_304
Fujifilm	EN-840T	F800 EN	301122	ECH	B01-042_3_302	F800 EN	301122	EUS-EC	B01-042_3_302
Fujifilm	ER-270FP	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-LC	B01-032_3_302
Fujifilm	ER-270T	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-LC	B01-032_3_302
Fujifilm	ER-530S2	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Fujifilm	ER-530T	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	ES-530WE	Fg5W C-G-D	301007	DIG	B01-001_3_302	Fg5W C-G-D	301007	GI-WJ	B01-001_3_302
Fujifilm	FB-120MP	Fg5W B-Bp	301098	BRO	B01-034_3_302	Fg5W B-Bp	301098	BR-LC	B01-034_3_302
Fujifilm	FB-120P	Fg5 B70	301086	PED	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	FB-120S	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	FB-120T	Fg5 B70	301086	BRO	B01-032_3_302	Fg5 B70	301086	BR-SC	B01-032_3_302
Fujifilm	FR-120F	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Fujifilm	G-EYE 760R(-I)	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	G-EYE 760R(-L)	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
Fujifilm	G-EYE 760R(-M)	F700 C-G-D	301008	DIG	B01-002_3_302	F700 C-G-D	301008	GI-WJ	B01-002_3_302
ION	490206	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
ION	490105E	OO LF	301020	BRO	B01-014_3_302	OO LF	301020	BR-LC	B01-014_3_302
Olympus	BF-1T180	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1T190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1T260	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1T60	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1TH1100	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1TH1200	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1TH190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-1TQ290	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-260	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-3C160	OO P	301017	PED	B01-011_3_302	OO P	301017	BR-TC	B01-011_3_302
Olympus	BF-3C30	OO P	301017	PED	B01-011_3_302	OO P	301017	BR-TC	B01-011_3_302
Olympus	BF-3C40	OO P	301017	PED	B01-011_3_302	OO P	301017	BR-TC	B01-011_3_302
Olympus	BF-F260	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-H1100	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-H1200	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-H190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-H290	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-MP190F	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-MP290F	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-MP60	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-N20	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Olympus	BF-P180	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-P190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-P260F	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-P290	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-P60	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-PE2	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-Q180	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-Q180-AC	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-Q190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-Q290	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-TE2	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-TH1100	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-TH190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-UC180F	OO P EB	301018	BRO	B01-012_3_302	OO P EB	301018	BR-EBUS	B01-012_3_302
Olympus	BF-UC190F	OO P EB	301018	BRO	B01-012_3_302	OO P EB	301018	BR-EBUS	B01-012_3_302
Olympus	BF-UC260FW	OO P EB	301018	BRO	B01-012_3_302	OO P EB	301018	BR-EBUS	B01-012_3_302
Olympus	BF-UC290F	OO P EB	301018	BRO	B01-012_3_302	OO P EB	301018	BR-EBUS	B01-012_3_302
Olympus	BF-XP190	OO P	301017	PED	B01-011_3_302	OO P	301017	BR-TC	B01-011_3_302
Olympus	BF-XP260F	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	BF-XP290	OO P	301017	PED	B01-011_3_302	OO P	301017	BR-TC	B01-011_3_302
Olympus	BF-XP60	OO P	301017	PED	B01-011_3_302	OO P	301017	BR-TC	B01-011_3_302
Olympus	BF-XT190	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	CF-185I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-240I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-2T160I	OW 2C-G-D	301014	ECH	B01-008_3_302	OW 2C-G-D	301014	GI-DOCWJ	B01-008_3_302
Olympus	CF-2T160L	OW 2C-G-D	301014	ECH	B01-008_3_302	OW 2C-G-D	301014	GI-DOCWJ	B01-008_3_302
Olympus	CF-E3I	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	CF-E3L	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	CF-EZ1500DI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-EZ1500DL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-FH260AZI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-FH260AZL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H180AI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H180AL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H185I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H185L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H190I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H190L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H260AI	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	CF-H260AL	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	CF-H260AZI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-H290ECI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	-580	B01-007_3_302
Olympus	CF-HQ1100DI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-HQ1100DL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-HQ190I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-HQ190L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-HQ290I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-HQ290L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-HQ290ZI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Olympus	CF-HQ290ZL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-Q160L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-Q180	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-Q180AI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-Q260AI	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	CF-Q260AL	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	CF-Q260DI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	CF-XZ1200I	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-WJ	B01-007_3_303
Olympus	CF-XZ1200L	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-WJ	B01-007_3_303
Olympus	CHF-B260	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	CHF-B290	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	CHF-CB30L	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	CHF-CB30S	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	CHF-V	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	CU-LC	B01-030_3_302
Olympus	CHF-XP20	OP B-Bp	301019	PED	B01-013_3_302	Wol C	301029	CU-SC	B01-023_3_302
Olympus	CYF-240	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	CYF-240A	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	CU-LC	B01-030_3_302
Olympus	CYF-4	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	CYF-4A	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	CU-LC	B01-030_3_302
Olympus	CYF-5	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	CYF-5A	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	CU-LC	B01-030_3_302
Olympus	CYF-V	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	CYF-V2	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	CYF-VA2	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	CU-LC	B01-030_3_302
Olympus	CYF-VH	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	CYF-VHA	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	CU-LC	B01-030_3_302
Olympus	CYF-VHR	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	ENF 200	N/A	N/A	N/A	N/A	N/A	N/A	NCH	N/A
Olympus	ENF TYPE GP	N/A	N/A	N/A	N/A	N/A	N/A	NCH	N/A
Olympus	ENF TYPE P4	N/A	N/A	N/A	N/A	N/A	N/A	NCH	N/A
Olympus	ENF-GP	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-GP2	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-P4	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-T3	OO LF	301020	BRO	B01-014_3_302	OO LF	301020	BR-LC	B01-014_3_302
Olympus	ENF-V2	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-V3	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-V4	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-VH	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-VH2	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-VQ	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	ENF-VT	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	ENF-VT2	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	ENF-VT3	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	ENF-XP	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	GF-UCT140	OW E UCT	301016	ECH	B01-010_3_302	OW E UCT	301016	EUS-EC	B01-010_3_302
Olympus	GF-UCT180	OW E UCT	301016	ECH	B01-010_3_302	OW E UCT	301016	EUS-EC	B01-010_3_302
Olympus	GF-UCT260	OW E UCT	301016	ECH	B01-010_3_302	OW E UCT	301016	EUS-EC	B01-010_3_302
Olympus	GF-UE160-AL5	OW E	301015	ECH	B01-009_3_302	OW E	301015	EUS-NEC	B01-009_3_302
Olympus	GF-UE190	OW E	301015	ECH	B01-009_3_302	OW E	301015	EUS-NEC	B01-009_3_302
Olympus	GF-UE260-AL5	OW E	301015	ECH	B01-009_3_302	OW E	301015	EUS-NEC	B01-009_3_302
Olympus	GF-UE290	OW E	301015	ECH	B01-009_3_302	OW E	301015	EUS-NEC	B01-009_3_302
Olympus	GF-UM160	OW E	301015	ECH	B01-009_3_302	OW E	301015	EUS-NEC	B01-009_3_302
Olympus	GF-XQ240	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-1100	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-1200N	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-1TH190	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-1TQ160	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-2T160	OW 2C-G-D	301014	ECH	B01-008_3_302	OW 2C-G-D	301014	GI-DOCWJ	B01-008_3_302
Olympus	GIF-2T240	OW 2C-G-D	301014	ECH	B01-008_3_302	OW 2C-G-D	301014	GI-DOCWJ	B01-008_3_302
Olympus	GIF-2TH180	OW 2C-G-D	301014	ECH	B01-008_3_302	OW 2C-G-D	301014	GI-DOCWJ	B01-008_3_302
Olympus	GIF-2TQ260M	OW 2C-G-D	301014	ECH	B01-008_3_302	OW 2C-G-D	301014	GI-DOCWJ	B01-008_3_302
Olympus	GIF-E	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-NWJ	B01-007_3_302
Olympus	GIF-E3	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-EZ1500	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-FQ260Z	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-H180	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-H180J	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-WJ	B01-007_3_303
Olympus	GIF-H185	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-H190	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-H190N	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-H260	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-H260Z	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-H290	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-H290EC	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-H290T	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-H290Z	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-HQ190	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-HQ290	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-KH260	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-N180	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-PQ260	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-Q160	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-Q165	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-Q180	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-Q240X	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-Q260J	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-XP160	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-XP190N	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-XP240	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-XP260NS	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Olympus	GIF-XP290N	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-XTQ160	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	GIF-XZ1200	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	GIF-XZ1200	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	HYF-1T	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Olympus	HYF-V	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	HYF-XP	Wol C	301029	PED	B01-023_3_302	Wol C	301029	BR-TC	B01-023_3_302
Olympus	JF-260V	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	LF-2	OO LF	301020	BRO	B01-014_3_302	OO LF	301020	BR-LC	B01-014_3_302
Olympus	LF-DP	OO LF	301020	PED	B01-014_3_302	OO LF	301020	BR-TC	B01-014_3_302
Olympus	LF-GP	OO LF	301020	BRO	B01-014_3_302	OO LF	301020	BR-LC	B01-014_3_302
Olympus	LF-P	Without channel	N/A	N/A	None	Without channel	N/A	NCH	None
Olympus	LF-TP	OO LF	301020	BRO	B01-014_3_302	OO LF	301020	BR-LC	B01-014_3_302
Olympus	LF-V	Oly C	301054	PED	B01-030_3_302	Oly C	301054	BR-TC	B01-030_3_302
Olympus	LTF-160	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	LTF-260	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	LTF-H290	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	MAF-DM	Oly C	301054	PED	B01-030_3_302	Oly C	301054	BR-TC	B01-030_3_302
Olympus	MAF-DM2	Oly C	301054	PED	B01-030_3_302	Oly C	301054	BR-TC	B01-030_3_302
Olympus	MAF-GM	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	BR-LC	B01-030_3_302
Olympus	MAF-GM2	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	BR-LC	B01-030_3_302
Olympus	MAF-TM	OO P	301017	BRO	B01-011_3_302	OO P	301017	BR-LC	B01-011_3_302
Olympus	MAF-TM2	Wol C	301029	BRO	B01-030_3_302	Wol C	301029	BR-LC	B01-030_3_302
Olympus	PCF-240I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H180AI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H180AL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H190DI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H190DL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H190I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H190L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H190TI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H190TL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H290I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H290L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H290TI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H290TL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H290ZI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-H290ZL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-HQ190I	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-HQ190L	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-P240AI	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-P240AL	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-PH190I	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-PH190L	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-PQ260I	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-PQ260L	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-Q180AI	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-WJ	B01-007_3_303
Olympus	PCF-Q180AL	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-WJ	B01-007_3_303
Olympus	PCF-Q260AI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-NWJ	B01-007_3_302
Olympus	PCF-Q260AL	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	PCF-Q260AZI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-Q260JI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-Q260JI	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PCF-Q260JL	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	PSF-1	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-WJ	B01-007_3_303
Olympus	SIF-H190	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	SIF-H290S	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	SIF-Q180	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	SIF-Q260	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	TGF-UC180J	OW E UCT	301016	ECH	B01-010_3_302	OW E UCT	301016	EUS-EC	B01-010_3_302
Olympus	TGF-UC260J	OW E UCT	301016	ECH	B01-010_3_302	OW E UCT	301016	EUS-EC	B01-010_3_302
Olympus	TJF-160VR	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	TJF-260V	OW C-G-D	301013	DIG	B01-007_3_302	OW C-G-D	301013	GI-WJ	B01-007_3_302
Olympus	TJF-Q160VF	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	TJF-Q180V	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	TJF-Q190V	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	TJF-Q290V	OW C-G-D	301013	DIG	B01-007_3_303	OW C-G-D	301013	GI-NWJ	B01-007_3_303
Olympus	URF-P5	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	URF-P6	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	URF-P7	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	URF-V	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	URF-V2	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Olympus	URF-V3	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Pentax	EB-1170K	OP B-Bp	301019	PED	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB11-J10	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1570AK	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1570K	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1572K	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1575K	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB15-J10	PP EB J10	301027	BRO	B01-021_3_302	PP EB J10	301027	BR-LC	B01-021_3_302
Pentax	EB-1970AK	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1970K	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1970TK	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1970UK	PP EEB	301026	BRO	B01-020_3_302	PP+ EEB	301120	BR-EBUS	B05-037_3_302
Pentax	EB-1972K	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1975K	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB-1990i	OP B-Bp	301019	PED	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	EB19-J10	PP EB J10	301027	BRO	B01-021_3_302	PP EB J10	301027	BR-LC	B01-021_3_302
Pentax	EB19-J10U	PP EEB-J10	301051	BRO	B01-027_3_302	PP EEB-J10	301051	BR-EBUS	B01-027_3_302
Pentax	EC-2990Fi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Pentax	EC-2990Li	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-2990Mi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3485F	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3485FK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3485LK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3490Fi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490FK	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490Li	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490LK	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490MK	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490TFi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490TLi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3490TMi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10cF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10cL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10cM	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10F	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10L	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10M	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10NF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10NL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10TF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10TL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i10TM	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC34-i20cF	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC34-i20cF	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC34-i20cL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC34-i20cL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC34-i20cM	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC34-i20cM	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC-380FK2p	PW C-G-D 40	301023	DIG	B01-017_3_303	PW C-G-D 40	301023	GI-NWJ	B01-017_3_303
Pentax	EC-380FKp	PW C-G-D 40	301023	DIG	B01-017_3_303	PW C-G-D 40	301023	GI-NWJ	B01-017_3_303
Pentax	EC-380LKp	PW C-G-D 40	301023	DIG	B01-017_3_303	PW C-G-D 40	301023	GI-NWJ	B01-017_3_303
Pentax	EC-380Mk2P	PW C-G-D 40	301023	DIG	B01-017_3_303	PW C-G-D 40	301023	GI-NWJ	B01-017_3_303
Pentax	EC-381FC	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC-381MC	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC-3840TL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC-3870CIFK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870CIFK2	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870CIK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870CILK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870CIMK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870FK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870FK2	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870FZK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870LZK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870M	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870MK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3870MK2	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3880FK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885F	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885F2	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885FK	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EC-3885FK2	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EC-3885L	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885LK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885M	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885M2	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EC-3885MK	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EC-3885MK2	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EC-3885TFK	PW90 2C-G-D	301077	ECH	B01-031_3_302	PW90 2C-G-D	301077	GI-DOCWJ	B01-031_3_302
Pentax	EC-3890Fi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890Fi2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890FK	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890FK2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890FZi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890Li	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890LK	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890LZi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890Mi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890Mi2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890MK	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890MK2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890MZi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC-3890TFK	PW90 2C-G-D	301077	ECH	B01-031_3_302	PW90 2C-G-D	301077	GI-DOCWJ	B01-031_3_302
Pentax	EC-3890TLK	PW90 2C-G-D	301077	ECH	B01-031_3_302	PW90 2C-G-D	301077	GI-DOCWJ	B01-031_3_302
Pentax	EC38-i10cF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10CF2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10cL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10cM	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10F	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10F2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10L	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10M	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10M2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10NF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i10NL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EC38-i20cF	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cF	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Pentax	EC38-i20cL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cM	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cM	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cWF	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cWF	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cWL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cWL	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cWM	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EC38-i20cWM	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	ECY-150s	OP B-BP	301019	BRO	B01-013_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	ECY-1570	OP B-BP	301019	BRO	B01-013_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	ECY-1570K	Wol U	301030	BRO	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	ECY-1575K	Wol U	301030	BRO	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	ED32-i10	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED-3480TK	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	ED-3485T	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	ED-3490TK	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED34-i10cT	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED34-i10cT	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED34-i10cT2	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED34-i10cT2	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED34-i10T	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED34-i10T2	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	ED-3680TK	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EE-1580K	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EE17-J10	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	EG-1580K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EG-1690K	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-NWJ	B01-016_3_302
Pentax	EG16-K10	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-NWJ	B01-016_3_302
Pentax	EG17-J10	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-NWJ	B01-016_3_302
Pentax	EG-1870K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-NWJ	B01-015_3_302
Pentax	EG-2470K	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EG-2490K	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	EG-2540	PW C-G-D 40	301023	DIG	B01-017_3_303	PW C-G-D 40	301023	GI-NWJ	B01-017_3_303
Pentax	EG-2770K	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EG-2790i	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	EG-2790K	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	EG27-i10	PW C-G-D 90	301022	DIG	B01-016_3_303	PW C-G-D 90	301022	GI-NWJ	B01-016_3_303
Pentax	EG27-i20c	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EG27-i20c	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EG-290Kp	PW C-G-D 40	301023	DIG	B01-017_3_303	PW C-G-D 40	301023	GI-NWJ	B01-017_3_303
Pentax	EG-2970K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EG-2980K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EG-2985	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-NWJ	B01-015_3_302
Pentax	EG-2985K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EG-2990i	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG-2990K	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG-2990Zi	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG29-i10	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG29-i10c	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG29-i10N	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG29-i20c	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EG29-i20c	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-WJ	B01-017_3_302
Pentax	EG-3270UK	PW Enew	301025	ECH	B01-019_3_302	PW Enew	301025	EUS-EC	B01-019_3_302
Pentax	EG-3485K	PW C-G-D	301021	DIG	B01-015_3_303	PW C-G-D	301021	GI-NWJ	B01-015_3_303
Pentax	EG-3490K	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG34-i10	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	EG34-J10U	PW Enew	301025	ECH	B01-019_3_302	PW Enew	301025	EUS-NEC	B01-019_3_302
Pentax	EG-3630U	PW Eold	301024	ECH	Missing	PW Eold	301024	EUS-NEC	Missing
Pentax	EG-3630UR	PW Eold	301024	ECH	Missing	PW Eold	301024	EUS-NEC	Missing
Pentax	EG-3670URK	PW Enew	301025	ECH	B01-019_3_302	PW Enew	301025	EUS-NEC	B01-019_3_302
Pentax	EG36-J10UR	PW Enew	301025	ECH	B01-019_3_302	PW Enew	301025	EUS-NEC	B01-019_3_302
Pentax	EG-3830UT	PW Eold	301024	ECH	Missing	PW Eold	301024	EUS-EC	Missing
Pentax	EG-3870CIK	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	EG-3870UTK	PW Enew	301025	ECH	B01-019_3_302	PW Enew	301025	EUS-EC	B01-019_3_302
Pentax	EG-3885TK	PW90 2C-G-D	301077	ECH	B01-031_3_302	PW90 2C-G-D	301077	GI-DOCWJ	B01-031_3_302
Pentax	EG-3890TK	PW90 2C-G-D	301077	ECH	B01-031_3_302	PW90 2C-G-D	301077	GI-DOCWJ	B01-031_3_302
Pentax	EG38-J10UT	PW Enew	301025	ECH	B01-019_3_302	PW Enew	301025	EUS-NEC	B01-019_3_302
Pentax	ES-3870K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	ES-3885K	PW C-G-D	301021	DIG	B01-015_3_302	PW C-G-D	301021	GI-WJ	B01-015_3_302
Pentax	FB-10FI	OP B-Bp	301019	PED	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-10V	OP B-Bp	301019	PED	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-15BS	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-15FI	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-15P	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-15RBS	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-15V	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-18BS	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-18FI	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-18P	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-18RBS	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-18V	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-19TV	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-7P	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FB-8V	OP B-Bp	301019	PED	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FCN-15X	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FCP-8P	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FCP-9P	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FCY-15P2	Wol U	301030	BRO	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	FCY-15RBS	Wol U	301030	BRO	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Pentax	FG-34UX	PW Eold	301024	ECH	Missing	PW Eold	301024	EUS-NEC	Missing
Pentax	FG-36UX	PW Eold	301024	ECH	Missing	PW Eold	301024	EUS-NEC	Missing
Pentax	FG-38UX	PW Eold	301024	ECH	Missing	PW Eold	301024	EUS-NEC	Missing
Pentax	FHY-10RBS	Wol U	301030	PED	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	FHY-15RBS	Wol U	301030	BRO	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	FI-10BS	OP B-Bp	301019	PED	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-10RBS	OP B-Bp	301019	PED	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-13BS	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-13P	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-13RBS	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-16BS	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-16RBS	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-7BS	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FI-7P	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FI-7RBS	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FI-9BS	OP B-Bp	301019	PED	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FI-9RBS	OP B-Bp	301019	PED	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FNL-10BS	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FNL-10RBS	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FNL-10RP2	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FNL-10RP3	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FNL-15RBS	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FNL-15RP3	OP B-Bp	301019	BRO	B01-013_3_303	Wol C	301029	BR-SC	B01-023_3_302
Pentax	FNL-7RBS	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FNL-7RP3	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FP-7RBS	N/A	N/A	N/A	N/A	N/A	N/A	NCH	N/A
Pentax	FP-7RBS2	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	FUR-9RBS	Wol U	301030	PED	B01-024_3_302	Wol C	301029	CU-SC	B01-023_3_302
Pentax	G-EYE34-i10cF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE34-i10cL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE34-i10F	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE34-i10L	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10cF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10cF2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10cL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10cM	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10F	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10F2	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10L	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10NF	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	G-EYE38-i10NL	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-WJ	B01-016_3_302
Pentax	VLS-1070STK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VLS-1190STK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VLS-1590STi	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-1070STK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-110s	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-110STs	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-1170	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-1170K	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-1190STK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL11-J10	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL-1570	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	VNL-1570STK	OP B-Bp	301019	BRO	B01-013_3_302	Wol C	301029	BR-SC	B01-023_3_302
Pentax	VNL-1590STi	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL15-J10	PP EB J10	301027	BRO	B01-021_3_302	PP EB J10	301027	BR-LC	B01-021_3_302
Pentax	VNL8-J10	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VNL9-CP	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Pentax	VSB-2990i	PW C-G-D 90	301022	DIG	B01-016_3_302	PW C-G-D 90	301022	GI-NWJ	B01-016_3_302
Pentax	VSB-3430K	PW C-G-D 40	301023	DIG	B01-017_3_302	PW C-G-D 40	301023	GI-NWJ	B01-017_3_302
Storz	091251-06	Wol C	301029	PED	B01-023_3_302	Wol C	301029	BR-TC	B01-023_3_302
Storz	091261-06	Wol C	301029	PED	B01-023_3_302	Wol C	301029	BR-TC	B01-023_3_302
Storz	091361-06	Wol C	301029	PED	B01-023_3_302	Wol C	301029	BR-TC	B01-023_3_302
Storz	11001 BI	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11001 BN	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11001 BN1	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11001 RD	Wol U	301030	PED	B01-024_3_302	Wol U	301030	BR-TC	B01-024_3_302
Storz	11001 UD	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	BR-LC	B01-024_3_302
Storz	11002 BD	OP B-Bp	301019	PED	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11003 BC	OP B-Bp	301019	PED	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11004 BC	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11004 BI	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11005 BC	OP B-Bp	301019	PED	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11009 BC	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11009 BC1	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11009 BI	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11101 CM	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101 CMK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101 P	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101 SK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101 VP	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101RP	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101SK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11101SP	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11264 BB	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Storz	11272 C	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 C1	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 CU	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VK	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VN	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VNI	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Storz	11272 VNIU	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VNU	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VP	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VPI	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272 VUK	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11272VH	Stz CU	301097	BRO	B01-033_3_302	Wol U	301030	CU-SC	B01-033_3_302 / B01-024_3_302
Storz	11272VHK	Stz CU	301097	BRO	B01-033_3_302	Wol U	301030	CU-SC	B01-033_3_302 / B01-024_3_302
Storz	11272VHUK	Stz CU	301097	BRO	B01-033_3_302	Wol U	301030	CU-SC	B01-033_3_302 / B01-024_3_302
Storz	11278 A	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 AU	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 V	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 VK	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 VS	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 VSK	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 VSUK	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11278 VUK	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11292 AD1	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11292 DE1	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11292 VP	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11292 VPU	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Storz	11292 VSEK	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11292 VSUEK	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Storz	11301 AA1	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11301 AAK1	OP B-Bp	301019	PED	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11301 ABXK	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11301 BN1	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11301 BNK1	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11301 BNX	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11302 BD2	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11302 BDK2	OP B-Bp	301019	PED	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11302 BDXK	OP B-Bp	301019	PED	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11303 BNXK	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11304 BCXK	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11572 A	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11576 A	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11577 A	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11581 A	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	11900 AN	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11900 AP	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11900 BN	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11900 BP	OP B-Bp	301019	BRO	B01-013_3_304	Wol C	301029	BR-SC	B01-023_3_302
Storz	11910D	OP B-Bp	301019	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Storz	11910DK	OP B-Bp	301019	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Storz	11910T	OP B-Bp	301019	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Storz	11910TK	OP B-Bp	301019	BRO	B01-023_3_302	Wol C	301029	BR-SC	B01-023_3_302
Storz	13304CS	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Storz	13700 CKS	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	BR-LC	B01-023_3_302
Storz	13820 NKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13820 PKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13821 NKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13821 PKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13885 FNKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13885 FPKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13885 NKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13885 PKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13912 NKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13912 PKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13920 NKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13920 PKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13924 HNKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13924 HPKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13924 NKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13924 PKS	SW C-G-D	301028	DIG	B01-022_3_303	SW C-G-D	301028	GI-NWJ	B01-022_3_303
Storz	13925 HNKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13925 HPKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13925 NKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13925 PKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13926 NKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13926 PKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13927 NKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	13927 PKS	SW C-G-D	301028	DIG	B01-022_3_302	SW C-G-D	301028	GI-WJ	B01-022_3_302
Storz	8402 ZX	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Wolf	7223.001	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Wolf	7224.001	Without channel	N/A	NA	None	Without channel	N/A	NCH	None
Wolf	7265.001	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7265.006	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7268.001	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7268.061	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7269.001	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7269.061	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7270.001	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7270.061	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7305.001	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7305.006	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.001	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.0014	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.006	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302

Brand	Endoscope Model	PlasmaTYPHOON				PlasmaTYPHOON+			
		PlasmaTYPHOON Connection set Ref. PlasmaBiotics	PlasmaTYPHOON Connection Set PENTAX Item N°	PlasmaTYPHOON Cycle code	PlasmaTYPHOON Connection card	PlasmaTYPHOON+ Connection set Ref. PlasmaBiotics	PlasmaTYPHOON+ Connection set PENTAX Item N°	PlasmaTYPHOON+ Cycle code	PlasmaTYPHOON+ Connection card
Wolf	7308.0064	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.061	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.0614	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.066	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7308.0664	Wol C	301029	BRO	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7315.001	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Wolf	7315.006	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Wolf	7315.1001	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Wolf	7315.1006	Wol U	301030	BRO	B01-024_3_302	Wol U	301030	CU-LC	B01-024_3_302
Wolf	7325.122	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Wolf	7325.152	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Wolf	7325.172	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-TC	B01-023_3_302
Wolf	7330.052	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7330.072	Wol C	301029	PED	B01-023_3_302	Wol C	301029	CU-LC	B01-023_3_302
Wolf	7355.071	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Wolf	7355.076	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Wolf	7355.1071	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Wolf	7355.1076	Wol U	301030	PED	B01-024_3_302	Wol U	301030	CU-TC	B01-024_3_302
Wolf	7356.071	Wol U2c	301031	PED	B01-025_3_302	Wol U2c	301031	CU-TC	B01-025_3_302
Wolf	7356.076	Wol U2c	301031	PED	B01-025_3_302	Wol U2c	301031	CU-TC	B01-025_3_302
Wolf	7356.1071	Wol U2c	301031	PED	B01-025_3_302	Wol U2c	301031	CU-TC	B01-025_3_302
Wolf	7356.1076	Wol U2c	301031	PED	B01-025_3_302	Wol U2c	301031	CU-TC	B01-025_3_302
Wolf	7326.076	Wol U2c	301031	PED	B01-025_3_302	Wol U2c	301031	CU-TC	B01-025_3_302