१९ master र tortoise / nodejs /

raspberrytorte revised drive timings following beta testing ...

...

...

...

...

README.md

10 years ago

10 years ago

∃ README.md

RaspberryTortoise WebControl

node.js is used to provide the web interface for the control of the raspberryTortoise.

Installation

sudo apt-get nodejs git
cd ~
git clone https://github.com/raspberrytorte/tortoise.git

Run Manually

sudo node ~/tortoise/nodejs/raspberryTortoise.js ServerIP ServerPort drivePath

where:

serverIP: default 192.168.0.10, is the address of the webserver, this should be the same address used by the server in motion.

serverPort: default 8080, is the port of the webserver.

drivePath: default "../drive", the path to the folder containing the motor drive code. If you use a relative path it should be routed from the directory where you manually call node. If you run node automatically, use the full path.

Run at Startup

to run the server automatically when you power up the RPi

sudo nano /etc/rc.local

add the line

nano <pathToTortoise>/nodejs/raspberryTortoise.js ServerIP ServerPort drivePath

Security Note

In order to execute motor drive commands the node needs to run with SUDO privilges.

This is very nasty and has security implications.

Be very careful if you deploy this on an RPi that is web connected.

Webserver

Using your browser navigate to http://ServerIP:ServerPort

example:

http://192.168.0.10:8080