
Nama : Sevtika Ichitia

NIM : L200180158

# Modul 6

# Kegiatan 1



Tugas 1A

Pertama kita beri 3 Switch 2950-24 lalu kita beri masing-masing PC per Switch dan sambungkan antar peripheral dengan media transmisi kabel.

### Tugas 2A

Switch>en

Switch#conf t

Enter configuration commands, one per line. End with CNTL/Z.

Switch(config)#hostname SW1

SW1(config)#end

Switch>en

Switch#conf t

Enter configuration commands, one per line. End with CNTL/Z.

Switch(config)#hostname SW2

SW2(config)#end

Switch>en


Switch#conf t


Enter configuration commands, one per line. End with CNTL/Z.


Switch(config)#hostname SW3

SW3(config)#end


Konfigurasi masing-masing PC









### Mode privileged







# Tugas 4B

# SW1

No.	Varaibel	Nilai
1	Root ID	0002.4A2E.C7A8
2	Priority	32769
3	MAC Adrress	0002.4A2E.C7A8
4	Bridge ID	0002.4A2E.C7A8
5	Cost(0/1;0/2;0/3)	19;19;19
6	Hello Time	2 sec
7	MaxAge	20 sec
8	Forward Delay	15 sec

## SW2

No.	Varaibel	Nilai
1	Root ID	0002.4A2E.C7A8
2	Priority	32769
3	MAC Adrress	0009.21B1.5DDE
4	Bridge ID	0009.21B1.5DDE
5	Cost(0/1;0/2;0/3)	19;19;19
6	Hello Time	2 sec
7	MaxAge	20 sec
8	Forward Delay	15 sec

## SW3

No.	Varaibel	Nilai
1	Root ID	0002.4A2E.C7A8
2	Priority	32769
3	MAC Adrress	00D0.FF22.93D1
4	Bridge ID	00D0.FF22.93D1
5	Cost(0/1;0/2;0/3)	19;19;19
6	Hello Time	2 sec
7	MaxAge	20 sec
8	Forward Delay	15 sec

## **Tugas 4C**

Root bridge: SW3

Designated bridge: SW2


Root port : SW1 (Fa0/2), SW2(Fa0/2)

Designated port: SW1(Fa0/1), SW2(Fa0/1;Fa0/3), SW3(Fa0/1;Fa0/2;Fa0/3)

### **Tugas 4D**

Forwarding: SW1(Fa0/1;Fa0/2), SW2(Fa0/1;Fa0/2;Fa0/3), SW3 Fa0/1;Fa0/2;Fa0/3)

Blocking: SW1(Fa0/3)



#### Tugas 5A

Masuk ke PC leo >> Desktop >> Command Prompt Lalu ketik "ping 172.21.1.3"

#### Tugas 6A

#### SW1

SW1>en

SW1#write

Building configuration...

[OK]

SW2

SW2>en

SW2#write

Building configuration...

[OK]

SW3


SW3>en


SW3#write


Building configuration...

[OK]

### Kegiatan 2







#### SW1

No.	Varaibel	Nilai
1	Root ID	0001.4343.7E33
2	Priority	32769
3	MAC Adrress	00E0.A3B4.2064
4	Bridge ID	00E0.A3B4.2064
5	Cost(0/1;0/2)	19;19
6	Hello Time	2 sec
7	MaxAge	20 sec
8	Forward Delay	15 sec

## SW2

No.	Varaibel	Nilai
1	Root ID	0001.4343.7E33
2	Priority	32769
3	MAC Adrress	0001.4343.7E33
4	Bridge ID	0001.4343.7E33
5	Cost(0/1;0/2)	19;19
6	Hello Time	2 sec
7	MaxAge	20 sec
8	Forward Delay	15 sec

### SW3

No.	Varaibel	Nilai
1	Root ID	0001.4343.7E33
2	Priority	32769
3	MAC Adrress	0001.C77D.3A4B
4	Bridge ID	0001.C77D.3A4B
5	Cost(0/1;0/2)	19;19;19
6	Hello Time	2 sec
7	MaxAge	20 sec
8	Forward Delay	15 sec

Menentukan:

Root bridge: SW3

Designated bridge: SW2

Root port : SW1 (Fa0/2), SW2(Fa0/2)


Designated port: SW1(Fa0/1), SW2(Fa0/1), SW3(Fa0/1;Fa0/2;Fa0/3)

Menentukan:

Forwarding: SW1(Fa0/1;Fa0/2), SW2(Fa0/1;Fa0/2),SW3(Fa0/1;Fa0/2;Fa0/3)

Blocking: None

Ping PC aries ke PC virgo



Masuk ke PC aries >> Desktop >> Command Prompt

Lalu ketik "ping 172.21.1.3"

#### Langkah untuk menyimpan konfigurasi jaringan

SW1

SW1>en

SW1#write

Building configuration...

[OK]

SW2

SW2>en

SW2#write

Building configuration
[OK]
SW3
SW3>en
SW3#write
Building configuration
[OK]