Example: Data Hazard and Stall Delay


• Rewrite the code assuming a machine without forwarding (by inserting nops).

ADD R4, R5, R2 LW R2, 0(R4) SW R15, 4(R2)


NOTE:

- 1. Without forwarding, dependent instruction reads the source operands from the register file at ID stage.
- 2. Register file can be written and read at the same cycle.

Solution Templete



Solution Templete



Solution Templete – putting together



