Demo Protocol

- 1. Get lab materials
 - a. Set up 96 Well Plate
 - b. Set up reservoir
- 2. Get supplies for procedure
 - a. 12 channel pipette
 - b. Tips for pipette
 - c. Trash receptacle
- 3. Pipette sample from reservoir into 96 well plate
 - a. Watch the video and follow the example.
 - b. Pipette Sample Material from wells A1-A12
 - c. Pipette Sample Material from wells B1-B12
 - d. Pipette Sample Material from wells C1-C12
 - e. Pipette Sample Material from wells D1-D12
 - f. Pipette Sample Material from wells E1-E12
 - g. Pipette Sample Material from wells F1-F12
 - h. Pipette Sample Material from wells G1-G12
 - i. Pipette Sample Material from wells H1-H12