# PSERC Tutorial: High Altitude Electromagnetic Pulse (HEMP) Impacts on the Grid



Thomas J. Overbye
University of Illinois at Urbana-Champaign
overbye@illinois.edu
June 8, 2016

This presentation is based in part on research funded by PSERC, DOE, NSF, EPRI, BPA, the State of Illinois DCEO, and ARPA-E; their support is gratefully appreciated.





#### **Introduction: HILFs**



- The grid reliability is high, but there are some events that could cause large-scale, long duration blackouts
  - These include what the North American Electric Reliability Corporation (NERC) calls High-Impact, Low-Frequency Events (HILFs); others call them black swan events or black sky days
  - HILFs identified by NERC were 1) a coordinated cyber, physical or blended attacks, 2) pandemics, 3) geomagnetic disturbances (GMDs), and 4) high altitude electromagnetic pulses (HEMPs)
  - Another could be volcanic eruptions
- Presentation focuses on HEMPs



#### **A Few Initial Thoughts**



- "Ignorance is not always bliss"
- "All models are wrong but some are useful,"
   George Box, Empirical Model-Building and Response Surfaces, (1987, p. 424)
- "The use of nondisclosure agreements or NDA's to obtain data, while useful in many instances, is not useful if the world community is to engage in research that adheres to the scientific principle of reproducibility of results by other qualified researchers and to use important findings to advance their own work"

PSERC Founding Director Bob Thomas, 2015



#### **Eletromagnetic Pulses (EMPs) Introduction**



- Broadly defined, an electromagnetic pulse is any transient burst of electromagnet energy
- Characterized by their magnitude, frequencies, footprint, and type of energy
- There are many different types, such as static electricity sparks, interference from gasoline engine sparks, lightning, electric switching, geomagnetic disturbances (GMDs) cause by solar corona mass ejections (CMEs), nuclear electromagnetic pulses, and non-nuclear EMP weapons
- Talk focuses primarily on the impact of nuclear EMPs on the grid, mostly caused by high altitude explosions



#### **Nuclear EMPs**




- Much of the information on nuclear EMPs is classified
- Various public documents exist, including IEC 1000-2-9 (from 1996); some of the information presented here comes from this standard
- The primary concern about nuclear EMPS is the impacts caused by high altitude EMPs (HEMPs)
  - From 30 to 100's of km in altitude
  - For a high altitude explosion the other common nuclear impacts (blast, thermal, radiation) do not occur at the ground
  - Scope of HEMP impact can be almost continental
- More localized EMPs can be created by surface blasts; known as source region EMP (SREMP)



#### **HEMP Time Frames**



- The impacts of an HEMP are typically divided into three time frames: E1, E2 and E3
- The quickest, E1 with maximum electric fields of 10's of kV per meter, can impact unshielded electronics



- E2, with electric fields

  10-11 10-9 10-7 10-5 10-3 10-1


  of up to 100 volts per meter, is similar to lightning
- Much of talk is on E3, which is similar to GMDs

Image Source: IEC 1000-2-9 Figure



#### **Nuclear EMP History**

- The presence of EMPs was theorized by Enrico Fermi prior to the first explosion in July 1945
  - Many wires were shielded, but still data was lost due to EMP
- British called it "radioflash" in their tests in early 1950's due to the presence of "clicks" heard on radios



Trinity Explosion, July 16, 1945, 20 kilotons of TNT source: Los Alamos Lab

 Hardtack tests in 1958 (up to 80 km) further demonstrated HEMP impacts



#### **Nuclear EMP History: Starfish Prime**



- Starfish Prime was an explosion of a 1.44 megaton nuclear weapon at an altitude of 400 km over the Pacific Ocean in July 1962
  - Part of series of tests known as Operation Fishbowl
  - The EMPs were much larger than expected, driving instruments off scale
  - Impacts seen in Honolulu (1445 km Starfish Prime flash seen away), including knocking in Honolulu;
     out about 300 street lights, source: Wikipedia setting off alarms, and damaging a microwave link
  - Some low earth orbit satellites were also damaged



#### **Nuclear EMP History**



- Soviet HEMP tests in the early 1960's were reported to have damaged power equipment
- Nuclear tests in the atmosphere, space and under water were banned in 1963
  - There is a United Nations underground test ban from 1996, though not all countries have agreed to it
- Various countries have optimized nuclear weapons for HEMP impacts
  - Russian military writings claim to have a super EMP weapon that can generate 200 kV/m\*


\*Source: Congressional Research Service, Clay Wilson, High Altitude Electromagnetic Pulse (HEMP) and High Power Microwave (HPM) Devices: Threat Assessments," July 2008




#### **HEMP Impacts versus Size and Altitude**

1

- EMP impacts do not scale linearly with weapon size
  - Even quite small weapons (such as 10 kilotons) can produce large EMPs





Low altitude EMPs can still have large footprints

Image Sources: en.wikipedia.org/wiki/Nuclear\_electromagnetic\_pulse




#### EMP E1 and E2 Mechanisms



 In a nuclear explosion, the E1 pulse is produced by the gamma radiation stripping electrons from atoms

in the upper atmosphere

- Known as the Compton effect;
   explained by Conrad Longmire
   at Los Alamos in 1963
- Electron flow is diverted by earth's magnetic field
- Mostly line of sight impacts;
   highest impacts south of detonation in Northern Hemisphere



ELECTRON

 The E2 pulse is created by scattered gamma rays and neutron gamma rays

Source: "The Early-Time (E1) High-Altitude Electromagnetic Pulse (HEMP) and Its Impact on the U.S. Power Grid, MetaTech-R-320, January 2010



#### **EMP E1 Protection**



- Because of large footprint, small energy density in the E1, so devices can be protected by Faraday cages
  - The allowable size of apertures depends on the wavelength and hence the frequency ( $\lambda$ =c/f); a ballpark figure is no larger than 1/10 the wavelength; for 1 GHz this is about 3 cm
  - Incoming wires are also an issue
- Military Standard 188-125-1 ("HIGH-ALTITUDE ELECTROMAGNETIC PULSE (HEMP) PROTECTION FOR GROUND-BASED C41 FACILITIES PERFORMING CRITICAL, TIME-URGENT MISSIONS PART 1 FIXED FACILITIES") provides useful guidance
- Another useful reference is MetaTech Report R-320, "The Early-Time (E1) High-Altitude Electromagnetic Pulse (HEMP) and Its Impact on the U.S. Power Grid"



#### Non-Nuclear EMP (NNEMP) Generators




- E1 EMPs can be generated by non-nuclear sources
  - It is easy to find "how to" manuals on-line
- The magnitude of the pulses produced by NNEMPs can exceed that of nuclear EMPs
- However, the range is greatly reduced perhaps up to several dozen meters for nonmilitary, mobile systems
  - Can be used for stopping many types of automobiles, and destroying electronics

PSE

#### HEMP E3



- The earth's magnetic field is disturbed by 1) the fireball generated by the blast and 2) energized metallic debris
- E3 causes a geoelectric field induced by the earth's changing magnetic field
- E3 is very similar to CME caused GMD s except faster rise times and larger magnitudes
  - Time frames range from seconds to several minutes
  - A useful reference is Metatech report R-321, "The Late-Time (E3) HEMP and Its Impact on the US Power Grid," January 2010





### **Amplitude Spectrum of Each HEMP Component**







Image Source: IEC 1000-2-9, Figure 11




#### **HEMP E3A and E3B**



- The E3 is usually broken into two components
  - the E3A "Blast Wave" (seconds) caused by the expansion of the nuclear fireball, expelling the Earth's magnetic field
  - the E3B "Heave" as bomb debris and air ions follow geomagnetic lines at about 130 km, making the air rise, which gives rise to a current and an induced electric field





Left Image: IEC 1000-2-9, Figure 9, Right Image: ORNL "Study to Assess the Effects of Magnetohydrodynamic Electromagnetic Pulse on Electric Power Systems Phase I Final Report," May 1985, Figure 8



### E3 Assumed Electric Field Magnitude and Direction for a Uniform Earth Model






Fig 9: Electric Field Magnitude

Fig 10: Electric Field Direction

The 1985 ORNL suggests modeling the electric field as the product of a spatially independent time function (fig 8), and time independent spatial magnitude and directions (fig 9 and 10)



#### Measured Change in B During Fishbowl Tests






Image: ORNL 1985 Report, Figure 1

Checkmate and Kingfish were nuclear tests that were part of Operation Fishbowl. Checkmate was at 147 km, with a classified yield (less than 20 kilotons). The Kingfish yield is classified, but believed to be about 400 kiloton at 97 km.


A gamma is one nT.

For reference the Quebec GMD had 500 nT/minute and the 1859 Carrington is estimated to be 5000 nT/minute



#### E3B Electric Field Magnitude and Direction





The assumed time duration and footprint is larger than in the 1985 ORNL report

Image Source: Left is Figure 2-11 from R-321, Right is Figure 2-8 form R-321




### **Analysis is Then Similar to Solar GMDs: Brief GMD Review**



 Solar corona mass ejections (CMEs) can cause changes in the earth's magnetic field (i.e., dB/dt).
 These changes in turn produce a non-uniform electric

field at the surface

 Changes in the magnetic flux are usually expressed in nT/minute; from a 60 Hz perspective they produce an almost dc electric field



- 1989 North America storm produced a change of 500 nT/minute, while a stronger storm, such as the ones in 1859 or 1921, could produce 5000 nT/minute variation
- Storm "footprint" can be continental in scale
- Earth's magnetic field is normally between 25,000 and 65,000 nT, with higher values near the poles Image source: J. Kappenman, "A Perfect Storm of Planetary Proportions," *IEEE Spectrum*, Feb 2012, page 29



### **Electric Fields and Geomagnetically Induced Currents (GICs)**




- The induced electric field (whether from a CME or HEMP) at the surface is dependent on deep earth (hundreds of km) conductivity
  - Electric fields are vectors (magnitude and angle); values expressed in units of volts/mile (or volts/km);
  - A 2400 nT/minute storm could produce 5 to 10 volts/mile.
- The electric fields cause GICs to flow in the high voltage transmission grid
- The induced voltages that drive the GICs can be modeled as dc voltages in the transmission lines.
  - The magnitude of the dc voltage is determined by integrating the electric field variation over the line length
  - Both magnitude and direction of electric field is important



#### Geomagnetically Induced Currents (GICs



- GMDs cause slowly varying electric fields
- Along length of a high voltage transmission line, electric fields can be modeled as a dc voltage source superimposed on the lines
- These voltage sources produce quasi-dc geomagnetically induced currents (GICs) that are superimposed on the ac (60 Hz) flows







#### **Transformer Impacts of GICs**

- The superimposed dc GICs can push transformers into saturation for part of the ac cycle
- This can cause large harmonics; in the positive sequence (e.g., power flow and transient stability) these harmonics can be represented by increased reactive power losses in the transformer

Images: Craig Stiegemeier and Ed Schweitzer, JASON Presentations, June 2011





#### **GMD** Enhanced Power Analysis Software




- By integrating GIC calculations directly within power flow and transient stability engineers can see the impact of GICs on their systems, and consider mitigation options
  - Models can provide assumed scenarios, either from a solar event or HEMP
- GIC calculations use many of the existing model parameters such as line resistance. Some nonstandard values are also needed; either provided or estimated
  - Substation grounding resistance
  - transformer grounding configuration, transformer coil resistance, auto-transformer, three-winding transformer



#### Overview of GMD Assessments



#### In is a quite interdisciplinary problem



The two key concerns from a big storm or an HEMP are


- 1) large-scale blackout due to voltage collapse,
- 2) permanent transformer damage due to overheating



#### Four Bus Example



$$I_{GIC,3Phase} = \frac{150 \text{ volts}}{(1+0.1+0.1+0.2+0.2)\Omega} = 93.75 \text{ amps or } 31.25 \text{ amps/phase}$$



The line and transformer resistance and current values are per phase so the total current is three times this value. Substation grounding values are total resistance. Brown arrows show GIC flow.



#### Power Flow Embedded GIC Calculations: The G Matrix



 With knowledge of the pertinent transmission system parameters and the induced dc line voltages, the dc bus voltages and flows are found by solving a linear equation

I = GV

- The G matrix is similar to the Y<sub>bus</sub> except 1) it is augmented to include substation neutrals, and 2) it is just resistive values (conductances)
- The current vector contains the Norton injections associated with the GMD-induced line voltages
- Factoring the sparse G matrix and doing the forward/backward substitution takes about 1 second for the 60,000 bus Eastern Interconnect Model



#### **Input Electric Field Considerations**



- The current vector (I) depends upon the assumed electric field along each transmission line
- With a uniform electric field determination of the transmission line's GMD-induced voltage is path independent
  - Just requires geographic knowledge of the transmission line's terminal substations
- With nonuniform fields, such as during an HEMP, an exact calculation would be path dependent, but just a assuming a straight line path is probably sufficient (given all the other uncertainties!)



### Impact of Earth Models: Background on Relationship Between dB/dT and E



- The magnitude of the induced electric field depends upon the rate of change in the magnetic field, and the deep earth (potentially 100's of km) conductivity
- The relationship between changing magnetic fields and electric fields are given by the Maxwell-Faraday Equation

$$\nabla \times \mathbf{E} = -\frac{\partial \mathbf{B}}{\partial t}$$
 (the  $\nabla \times$  is the curl operator)

$$\iint_{\partial \Sigma} \mathbf{E} \cdot d\ell = -\frac{d}{dt} \iint_{\Sigma} \mathbf{B} \cdot d\mathbf{S} \quad \text{Faraday's law is V} = -\frac{d\lambda}{dt}$$



#### Background on Relationship Between dB/dT and E



- The magnetic field variation in the atmosphere induces currents in the earth that somewhat cancel the magnetic field variation
  - Lenz's law says the direction of any induced current is always such that it will oppose the change that produced it

$$\delta = \sqrt{\frac{1}{\pi f \, \mu \sigma}}$$

where f is the B field variation in Hz  $\mu$  is the magnetic permeability  $(4\pi \times 10^{-7} \text{ H/m here})$   $\sigma$  is the conductity in S/m

As an example, at 0.01 Hz and conductivity of 0.01 S/m the skin depth is 50.3 km



### Frequency Domain Analysis With Uniform Conductance



If the earth is assumed to have a single conductance,
 σ, then

$$Z(\omega) = \frac{j\omega\mu_0}{\sqrt{j\omega\mu_0\sigma}} = \sqrt{\frac{j\omega\mu_0}{\sigma}}$$

 $\frac{u_0}{u_0\sigma} = \sqrt{\frac{j\omega\mu_0}{\sigma}}$ This was the assumption in the 1985 tionship is then ORNL report

The magnitude relationship is then

Recalling 
$$B(\omega) = -\mu_0 H(\omega)$$
  
 $|E(\omega)| = |Z(w)H(\omega)|$   
 $= \left| \sqrt{\frac{j\omega\mu_0}{\sigma}} \frac{B(\omega)}{\mu_0} \right|$ 

For example, assume

$$\sigma$$
 of 0.001 S/m and

variation at 0.002 Hz.

Then B(
$$\omega$$
) =660×10<sup>-9</sup> T and

$$E(\omega) = \sqrt{\frac{2\pi \times 0.002 \times \mu_0}{0.001}} \frac{660 \times 10^{-9} \text{ T}}{\mu_0}$$

$$E(\omega) = 0.00397 \times 0.525 = 2.1 \text{ V/km}$$



#### 1-D Earth Models



- With a 1-D model the earth is model as a series of conductivity layers of varying thickness
- The impedance at a particular frequency is calculated using a recursive approach, starting at the bottom, with each layer m having a propagation constant

$$k_{m} = \sqrt{j\omega\mu_{0}\sigma_{m}}$$

• At the bottom level n  $Z_n = \frac{j\omega\mu_0}{k_n}$ 

$\sigma_1$	$d_1$
σ <sub>2</sub>	$d_2$
σ <sub>3</sub>	$d_3$
σ <sub>4</sub>	$d_4$
σ <sub>5</sub>	d <sub>5</sub>
σ <sub>6</sub>	$d_6$
$\sigma_n$	$d_n$
	<b>\</b>
$\infty$	

1-D Layers



#### 1-D Earth Models



 Above the bottom layer, each layer m, has a reflection coefficient associated with the layer below

$$r_{m} = \frac{\left(1 - k_{m}\right) \frac{Z_{m+1}}{j\omega\mu_{0}}}{\left(1 + k_{m}\right) \frac{Z_{m+1}}{j\omega\mu_{0}}}$$

With the impedance at the top of layer m given as

$$Z_{m} = j\omega\mu_{0} \left( \frac{1 - r_{m}e^{-2k_{m}d_{m}}}{k_{m} \left( 1 + r_{m}e^{-2k_{m}d_{m}} \right)} \right)$$


Recursion is applied up to the surface layer



#### **USGS 1-D Conductivity Regions**



 The USGS has broken the continental US into about 20 conductivity (resistivity) regions



These region scalings are now being used for power flow GMD analysis

Image from the NERC report; data is available at http://geomag.usgs.gov/conductivity/



#### 1-D Earth Models



 Image on left shows an example 1-D model, whereas image on right shows the Z(ω) variation for two models

Model IP-4 0.1 2. Sedimentary Basin 1. Overburden (overall 2.5 km) (alluvium, eolian colluvium, residual) 2a. sandstone (0.1-0.6 km) 2b. Pierre Shale (0.6-1.6 km) 2c. sandstone, limestone (1.6-2.5 km) Depth (km) 3. Upper Crust 2.5 ~ 19 km 4. Middle Crust 19 ~ 28 km 5. Lower Crust 28 - 47 km higher resistivy range - - - -6. Upper Mantle 47 - 100 km 100 lower resistivy range ----7. Upper Mantle 100 - 250 km 8. Upper Mantle 250 - 410 km 9, 10. Transition Zones 410-520, 520-670 km 11, 12. Lower Mantle 670-900, 900-1000 km 1000

100


Resistivity (ohm-m)

1000

10000

1D Resistivity Model for Interior Plains (Great Plains province)

Figure 9: Frequency response of two layered Earth conductivity models.




Resistivity values and depths have been interpreted from published geological reports and maps, and may differ from actual conditions measured by a geophysical survey and/or borehole.



#### 3-D Models and EarthScope





The magnetotelluric (MT) component of USArray, an NSF Earthscope project, consists of 7 permanent MT stations and a mobile array of 20 MT stations that will each be deployed for a period of about one month in regions of identified interest with a spacing of approximately 70 km. These MT measurements consist of magnetic and electric field data that can be used to calculate 3D conductivity deep in the Earth. The MT stations are maintained by Oregon State University's National Geoelectromagnetic Facility, PI Adam Schultz. (www.earthscope.org)



#### 3-D Models and EarthScope



- Earthscope data is processed into magnetotelluric transfer functions that:
  - Define the frequency dependent linear relationship between EM components at a single site.

$$\frac{E_x(\omega)}{B_y(\omega)} = \xi_{xy}$$
 (simplified for the 1D case)

 Can be used to relate a magnetic field input to and electric field output at a single site

$$\begin{bmatrix} Ex \\ Ey \end{bmatrix} = \begin{bmatrix} \xi_{xx} & \xi_{xy} \\ \xi_{yx} & \xi_{yy} \end{bmatrix} \cdot \begin{bmatrix} Bx \\ By \end{bmatrix}$$


Are provided in 2x2 impedance tensors by USArray

Reference: Kelbert et al., IRIS DMC Data Services Products, 2011.


#### **Example 3-D Earthscope Model Results**




 Image provides a snapshot visualization of the timevarying surface electric fields using Earthscope data



#### Large-Scale Studies Require Geo-mapped Buses



## Example EMP Results: 2000 Bus Synthetic Texas Footprint Model



The next few slides illustrate the impact of an EMP on an entirely synthetic (fictitious) 2000 bus model located on the Texas footprint. The ORNL scenario is used with an impact over lat 32.5N, long 97.5W



## Example EMP Results: 2000 Bus Synthetic Texas Footprint Model





Image shows the assumed electric field 60 seconds after the attack; the below graph shows the assumed time variation in the electric field






## Example EMP Results: 2000 Bus Synthetic Texas Footprint Model



 This movie and graph show the variation in the bus voltages for the first 80 seconds using a transient stability solution with PowerWorld Simulator





#### **Power Flow Convergence Issues**



- Integrated GIC modeling can impact power flow convergence since the GIC induced reactive power losses simultaneously add lots of reactive power.
- Several techniques can help prevent divergence
  - Just calculating the GICs without solving the power flow
  - Gradually increasing the assumed electric fields to avoid simultaneously adding too much reactive power
  - Only calculating the GIC transformer reactive power losses for specified areas; reactive power doesn't travel far
  - Freezing reactive control devices such as LTC taps
- Transient stability solutions can avoid many issues and are useful especially for HEMP analysis



#### **GIC Mitigation**



- Engineers need tools to determine mitigation strategies
  - Cost-benefit analysis
- GIC flows can be reduced both through operational
  - strategies such as opening lines, and through longer term approaches such as installing blocking devices
- Redispatching the system can change transformer loadings, providing margins for GICs
- Algorithms are needed to provide power engineers with techniques that go beyond trial-and-error



#### **Conclusions**



- Building on the modeling work done for GMD, tools exist for doing HEMP assessment on large-scale power systems
  - There is certainly lots of uncertainty in this analysis
- Getting started with GIC assessment (either GMD of HEMP) can be relatively straightforward, consisting of doing GIC enhanced power flow studies
  - Can be used to determine mitigation strategies and locations for monitoring equipment
- Integration into transient stability is straightforward, and can be leveraged HEMP studies
- Lots of research opportunities!!



#### Thank You!



### Questions?

