




PELCAS A3 Microneedling Pen

Before using this device, please read the following instructions carefully and keep this manual for future reference.

Product Detail



Operating Instructions



Disinfect the liquid adjustable cartridge with 75% alcohol for 5-10 minutes and cover it with the cartridge cap.



Remove the soft plug, securely fasten the cartridge cap onto the cartridge to prevent leakage, add the essence, and then seal the cartridge with the soft plug.



Invert the cartridge and remove the cartridge cap

Power

- 1. To turn on the device, press and hold the power button for 3 seconds, and the digital display will show the speed level "1"
- 2. Press and hold the power button for 3 seconds to turn off the device
- in contact with the skin, the activated device remains in standby mode.



5

The device is equipped with a built-in battery and supports AC power, allowing it to function while charging.

Insert the cartridge into the

place.

microneedling pen, adjust the liquid

output level using the control dial, and install the retaining ring to lock the cartridge and microneedling pen in

Press and hold the power/speed switch

for 3 seconds to activate the device

The device will only begin operation

when it comes into contact with the

After use, turn off the microneedling

pen, remove the cartridge, and store the device upside down to prevent any residual liquid from flowing back and potentially damaging the device

- 1. Plug the DC adapter into the designated jack on the
- 2. Connect the DC power plug of the adapter to an AC outlet.
- 3. To initiate the charging process, insert the other end of the adapter into an outlet and connect it to the charger.

3. The activated device will only start vibrating and operating when it comes into contact with the skin. If not

5 Speeds Level Control

In the power-on state, press the power switch once to cycle through the speed levels. Each press will switch to the next speed level, starting from the lowest speed and gradually increasing up to 5-speed levels. The digital display will show the corresponding speed level number as you change the speed settings.



- - - Power/Speed Switch

Power-On State

 During charging, the display screen will show three horizontal lines, representing the battery level. Throughout the charging process, these lines will blink to indicate the current charging progress.

After the battery is fully charged, the three horizontal lines on the display screen will stop blinking and remain continuously illuminated.



The device features an automatic recognition function and will only start operating when in contact with the skin after activation.

Maintenance

- 1. Always turn off the power when the device is not in use. Clean the surface with a dry cloth to remove any dust or debris.
- 2. Store the device away from direct sunlight, and avoid exposing it to high-temperature and high-humidity environments.
- 3. Never allow non-professional personnel to perform measurements, repairs, or alterations on the device.
- 4. Before each use, carefully inspect both the device and the adapter for any signs of damage or malfunction.
- 5. If the device has not been used for an extended period, ensure to check its proper functioning and safety before use.

Not Suitable For The Following Individuals

- 1. People with high internal body heat
- People with acute diseases or having a body temperature of 38°C or higher.
- 3. People who frequently visit hospitals.
- 4. People with allergies or hemophilia
- 5. People who take long-term medication.
- 6. People with excessive melanin on the face.
- 7 People under the age of 18

Warranty Instructions

The PELCAS A3 Microneedling Pen comes with a 12-month warranty period from the date of purchase. During this warranty period, we provide free repairs for any damage or natural failure that may occur.

However, please note that the following issues are not covered under the warranty, and repair charges will apply even during the warranty period:

- 1. Troubles caused by careless treatment, voluntary repair, or unauthorized alteration by the user.
- Troubles resulting from repairs conducted by technicians not affiliated with an authorized dealer shop or customer center appointed by the manufacturer.
- 3. Troubles arising from the use of accessories not approved or appointed by the manufacturer

Precautions

- 1. Do not use the device with a power supply other than AC 220V to prevent the risk of fires or malfunctions
- 2. Do not attempt to repair, disassemble, or modify the controller or body without permission, as it may result in malfunctions.
- Avoid touching the device or detaching power cords with wet hands to prevent the risk of electric shock.
 Do not use damaged or frayed power cords, as they may lead to fires. Always replace them with new ones.
- 5. Unplug the device from the outlet when not in use for an extended period.
- 6. If you encounter any issues, refrain from disassembling or repairing the device yourself. For maintenance, contact the store where you purchased the product.
- 7. Only authorized operators should handle the device to avoid accidents or malfunctions.
- 8. Keep the device away from high-temperature, dusty, or humid environments (e.g., humidifiers) to prevent malfunctions.

Product Specification

Product name:	Microneedling Pen	
Model number:	A3	
Weight:	80g	
Size:	150mm*23mm	
Battery:	500mAh	

Packing List

Item	Quantity
Power Cable	1
Cartridge	6
A3 Microneedling Pen	1
User Manual	1



DISPOSAL & RECYCLING:

You must properly dispose of the A3 Dermapen according to local laws and regulations. Since this machine contains electronic components, it should be discarded and separated from household waste. When it reaches the end of its life, contact local authorities to learn about disposal and recycling options. You can help protect the environment! Please remember to respect local regulations and dispose of non-working electrical equipment at an appropriate waste disposal center.