
DIAZ6-01


Stop Light Switch Circuit

CIRCUIT DESCRIPTION

This circuit sends a stop light switch ON or OFF signal to ECU.

WIRING DIAGRAM





INSPECTION PROCEDURE

1 Check stop light switch.

NG

Replace stop light switch.

ΟK

2 Check wire harness between stop light switch and wiper control ECU (See page IN-38).

NG

Repair or replace wire harness.

ОК

Proceed next circuit inspection shown on problem symptom table. (See page DI-930)