WATER TEMPERATURE SENSOR
## COMPONENTS

FI0EE–01

Europe

V–Bank Cover

Fuel Return Hose

PS Air Hose

Vacuum Sensing Hose

PCV Hose

Throttle Body

Intake Air Connector

Accelerator Cable

18 (185, 13)

◆ Gasket

Water Temperature Sensor Connector

Water Temperature Sensor

◆ Gasket

| N·m (kgf·cm, ft·lbf) | : Specified torque

◆ Non–reusable part

B05239