## **INSTALLATION**

1. INSTALL SPIRAL CABLE (See page SR-24)

- 2. INSTALL UPPER AND LOWER COLUMN COVERS (See page SR-24)
- 3. INSTALL STEERING WHEEL (See page SR-24)
- 4. INSTALL STEERING WHEEL PAD (See page SR-24)

RS0D1-01