EXHAUST GAS RECIRCULATION (EGR) SYSTEM (European Spec.) COMPONENTS

EGR Cooler Pipe 19.6 (200, 14) No.1 Intake Pipe and Gasket 39.2 (400, 29) Intake Heater Assembly 19.6 (200, 14) Gasket 19.6 (200, 14) No.2 Intake Pipe EGR Valve Gasket Vacuum Hose Gasket Intake Pipe Stay 19.6 (200, 14) EGR Cut VSV E-VRV for EGR N·m (kgf·cm, ft·lbf) : Specified torque ◆ Non-reusable part B14806