
ENGINE (European Spec.) HOW TO PROCEED WITH TROUBLESHOOTING

DI21H 10

When using hand -held tester, troubleshoot in accordance with the procedure on the following pages.



When not using hand -held tester, troubleshoot in accordance with the procedure on the following pages.

