DI1HC–07

# Check for Fluid Leakage

Check for fluid leakage from actuator or hydraulic lines.