

<u>P</u>inout

used for internal hardware
can be used for JTAG debugging hardware
can be used for SPI

can be used for analog signals

pins remain usable in deep slee

recommended for I2C



