


GlowCore Mini v2.0 Quick Start Guide

Learn how to get started with your GlowCore Mini dev board.





Step 1:

Solder your LED strip to GlowCore Mini. Check out the pinout overview (PDF available via bit.ly/3P6df0i) for more details.



Step 2:

Power GlowCore Mini via USB-C or connect an external 5V source to the **5V IN** pin.



Step 3:

Connect to Wi-Fi:



GlowCore Mini

Control GlowCore Mini via your web browser or the WLED app, using the IP 4.3.2.1