# GlowLight/GlowTower
Main PCB
v2.0

Pinout

Legend:
- 🟠 recommended for SPI **
- 🟡 recommended for I2C **
- 🟣 recommended for I2S **
- 🔵 can be used for analog input signals
- 🔵 can be used for touch inputs
- 🟢 can be used for USB Serial, USB OTG, JTAG
- 🟤 can be used for UART
- 🟠 pins remain usable in deep sleep
- 🟢 outputs 5V data signal

Left side labels:
- 5V IN/OUT
- 3.3V IN/OUT
- GND
- VBUS

- GPIO 14 | SD | ADC2 | TOUCH 14 | RTC GPIO 14
- GPIO 13 | SCK | ADC2 | TOUCH 13 | RTC GPIO 13
- GPIO 12 | WS | ADC2 | TOUCH 12 | RTC GPIO 12
- GPIO 35 | MOSI
- GPIO 37 | MISO
- GPIO 36 | SCK
- GPIO 9 | SCL | ADC1 | TOUCH 9 | RTC GPIO 9
- GPIO 8 | SDA | ADC1 | TOUCH 8 | RTC GPIO 8
- GND

Right side labels:
- GND
- GPIO 42 | LED 1 DATA OUT
- 5V OUT
- GPIO 41 | LED 2 DATA OUT
- POWER BUTTON EXTERNAL
- GPIO 20 | USB D+ | ADC2 | RTC GPIO 20
- GPIO 19 | USB D- | ADC2 | RTC GPIO 19
- GPIO 44 | RX
- GPIO 43 | TX
- GPIO 1 | POWER BUTTON
- GPIO 3 | ACTION BUTTON
- EN/RESET
- ACTION BUTTON EXTERNAL
- GPIO 4 | LED 3 DATA OUT
- GPIO 5 | LED 4 DATA OUT

PCB silkscreen text:
GlowLight/GlowTower v2.0
Main PCB

GND, LED1/IO42, 5V, 5V, 5V, 3.3V, 3.3V, GND, GND, LED2/IO41, 5V, GND, POWERBUTTON, GND, 5V, GND, 5V, VBUS

Documents:
Gik9H
IO 0/USB D+
IO 9, USB D-
RX
TX
IO1/PB
IO3/AB
EN
ACTIONBUTTON
GND
LED3/IO4
5V
GND
LED4/IO5
5V

GPIO 1 | POWER BUTTON *

[Press]
- ⏻ Standby Mode *

[Press] [Press]
- 📶 Turn off/on WiFi

GPIO 3 | ACTION BUTTON *

[Press]
- ▶ Next LED preset

[Press] [Hold]
- ✦ Change brightness
  While holding the button, the brightness first decreases and once the minimum is reached, it increases again.

---

* ⏻ To turn on again, press the **POWER BUTTON** once.
** Every GPIO pin can be used for: I2C, SPI, I2S
*** Pull to GND, to trigger button (For your code, keep in mind: LOW signal will be inverted to HIGH on pcb)

Button presets require GlowOS 0.15 or newer installed on GlowLight/GlowTower Main PCB.

---

glowlight.glowingkitty.com
glowtower.glowingkitty.com

open source hardware

Download PDF:
bit.ly/3EQ7grZ