
## $1\_2.\ X-Axis Wheel Assembly$

Materials			
Electronic Parts	Frame Parts	Hardware Parts	Fasteners Parts
	x-carriage*1	Wheel*8	M5-65mm-Screw *4
	x-carriage_back *1	Eccentric-Column *4	M5-Nyloc-Nut *4
		Spacer-6mm*8	M5- Washer *32




[Step1] M5-65mm screw\*4 pass through the front of the x-carriage aluminum



LEKN TECH Store: <a href="https://lekn.aliexpress.com/">https://lekn.aliexpress.com/</a>


[Step2] The two screws on the upper end are installed from left to right:



[Step3] Two screws at the lower end are installed from left to right:

Eccentric Column -Washer\*2- Wheel-Washer\*2- Spacer \* 2-Wheel-Washer \* 2- Eccentric Column





LEKN(C1) Assembly Manual V2.0 BY LEKN

[Step4] M5-65mm screw\*4 are inserted into the x-carriage\_back aluminum part and fixed with M5-Nyloc-Nut (Note: x-carriage\_back aluminum parts have left and right direction, with M5 threaded holes on the right)



