## **STM32F103** 机智

### 云

# 开发手册 V1.0

移植部分再来看本教程

#### 4.3.3 移植

#### 1)添加文件

我们把之前下载的通用平台 SDK 下"Gizwits"文件夹复制到我们的工程下,如图 4.3.3.1 所示。






图 4.3.3.1 添加 Gizwits 文件

由于 WIFI 的通讯是插在 ATK MODULE 的接口上,而 ATK MODULE 接口是连接到板子的串口 3 上,在 HARDWARE 文件夹中我们创建 USART3 文件夹,并且在文件夹内创建 usart3.c 和 usart3.h 文件 如图 4.3.3.2 所示。

前面步骤完成后,需要将其添加到工程分组中,添加完成以后如图 4.3.3.4 所示。



#### 然后就是区分内容了



将 Utils 文件夹下内容添加至工程 库函数也要包含

2.gitwits\_product.c 首先注释开头几行 如果使用可写类型 include 相应.h 文件 添加 extern u8 wifi\_sta; extern dataPoint\_t currentDataPoint;

```
12
                              链接 | 增值 | 升放 | 甲立 | 安全 | 目有 | 目出 | 生念
      13
                              www.gizwits.com
      14
           ****************
      15
      16
      17
           #include <stdio.h>
      18
           #include <string.h>
      19
          #include "gizwits_product.h"
#include "common.h"
#include "usart3.h"
#include "led.h"
      20
      21
      22
      23
      24
      25
          static uint32_t timerMsCount;
      26
           uint8_t aRxBuffer;
          extern u8 wifi_sta;
      27
          /** User area the current device state structure*/
      28
          extern dataPoint_t currentDataPoint;
      29
      30 //extern keysTypedef_t keys;
      31
          //extern TIM_HandleTypeDef htim2;
      32
      33
          //extern UART_HandleTypeDef huart1;
          //extern UART_HandleTypeDef huart2;
      34
      35
     36 /**@} */
可写内容的修改
  66
        moduleInfo t *ptModuleInfo = (moduleInfo t *)gizdata;
  67
  68
  69
         if((NULL == info) || (NULL == gizdata))
  70 自
  71
          return -1;
  72
  73
74
        for(i=0; i<info->num; i++)
  75 卓
  76 T
77 =
78
79
           switch(info->event[i])
             case EVENT_LEDonoff:
               currentDataPoint.valueLEDonoff = dataPointPtr->valueLEDonoff;
GIZWITS_LOG("Evt: EVENT_LEDonoff %d \n", currentDataPoint.valueLEDonoff);
if(0x01 == currentDataPoint.valueLEDonoff)
  80
  81
  82 🖨
  83
                LED1=0: //user handle
  84
  85
               else
  86 🖨
  87
                 //user handle
  88
               LED1=1;
  89
  90
               break;
  91
  92
  93
  94
            case WIFI_SOFTAP:
  95
  96
               break
  97
             case WIFI_AIRLINK:
  98
              break
             case WIFI_STATION:
  99
 100
              break
             case WIFI_CON_ROUTER:
 101
 102
             break;
 103
注释掉 userHandle()和 PUTCHAR_PROTOTYPE 和 uartInit()、HAL_TIM_PeriodElapsedCallback、
```

timerInit () \ HAL\_UART\_RxCpltCallback ();

```
168 -*/
       169 void userHandle (void)
       170 □ {
       171 申 /*
       172
       173
       174
               }
       175
       176
  237
238
             * @retval None
             */
  239
          //void HAL_TIM_PeriodElapsedCallback(TIM_HandleTypeDef *htim)
         //voi/
//{
// i:
// {
// //
// }
  240
                  if (htim==&htim2)
  241
  242
  243
                        keyHandle((keysTypedef_t *)&keys);
                        gizTimerMs();
  244
  245
  246
  247
   224 L */
225 //PU
226 //{
          // /* Place your in
// /* Place your in
// /* e.g. write a
// HAL_UART_Transmi
                 /* Place your implementation of fputc here */
/* e.g. write a character to the USART1 and Loop until the end of transmission
HAL_UART_Transmit(&huart1, (uint8_t *)&ch, 1, 0xFFFF);
   227
   228
   229
   230
   231
232
           1//
                  return ch;
   233
   234 □/**
              * @brief Period elapsed callback in non blocking mode

* @param_htim : TIM handle
   235
236
237
238
239
240
241
              * @retval None
          L */
          //void HAL_TIM_PeriodElapsedCallback(TIM_HandleTypeDef *htim)
//{
    if (htim==&htim2)
// {
        keyHandle((keysTypedef_t *)&keys);
        gizTimerMs();
    }
/// }
   242
   243
   244
   245
   246
   247
   248 □/**
   249
           * @brief Timer TIM3 init function
   250
   251
           * @param none
   252 //* @return none
253 -//*/
255
      NAME OF STREET OF STREET (ADTRIA)
      //{
//}
//}
             HAL_TIM_Base_Start_IT(&htim2);
256
258
259 戸/**
260 * @brief This function handles USART IDLE interrupt.
261 */
262 //void HAL_UART_RxCpltCallback(UART_HandleTypeDef*UartH
      //void HAL_UART_RxCpltCallback(UART_HandleTypeDef*UartHandle)
//{ |
    if (UartHandle->Instance == USART2)
//    {
        gizPutData((uint8_t *)&aRxBuffer, 1);
}
263
264
265
267
       //
//}
                      HAL_UART_Receive_IT(&huart2, (uint8_t *)&aRxBuffer, 1);//开启下一次接收中断
268
269
270
271
                 }
272 日/**
```

NVIC\_SystemReset();

#### 修改 uartWrite()函数

215

216 217 }

010 /wwml w/

```
291 -*/
292 int32_t uartWrite (uint8_t *buf, uint32_t len)
293 👨 {
               uint8_t crc[1] = {0x55};
uint32_t i = 0;
294
295
296
297
298 🖻
               if (NULL == buf)
299
300
301
                     return -1;
               }
302
303 p
304
305
306
307
308
309
310
311
312
313
314
315 p
316
317
               for (i=0; i<len; i++)
                        HAL_UART_Transmit_IT(&huart2, (uint8_t *)&buf[i], 1);
while (huart2.gState != HAL_UART_STATE_READY)://Loop until the end of transmission
        11
                         if(i >=2 && buf[i] == 0xFF)
        11/11/11
                              HAL_UART_Transmit_IT(&huart2, (uint8_t *)&crc, 1);
while (huart2.gState != HAL_UART_STATE_READY)://Loop until the end of transmission
                  USART_SendData(USART3, buf[i]);
while(USART_GetFlagStatus(USART3, USART_FLAG_TC)==RESET); //循环发送,直到发送完毕if(i >=2 && buf[i] == 0xFF)
                  USART_SendData(USART3, 0x55);
while(USART_GetFlagStatus(USART3, USART_FLAG_TC)==RESET); //循环发送, 直到发送完毕
}
318
319
              }
```

#### 3.product.h

改开始几行即可

#### 4. gizwits\_protocol.h

```
275
276 /** User Area Device State Structure */
277 - typedef struct {
278    bool valueLEDonoff;
279  } dataPoint_t;
280 -
```

#### 5.main 函数

定义 userHandle() 初始化各外设和协议

```
11 /* 用尸区自削设备状念结构体*/
   dataPoint_t currentDataPoint;
13
   //协议初始化
15 void Gizwits_Init(void)
16 □ {
   TIM3_Int_Init(9,7199)://1MS系统定时
usart3_init(9600)://WIFI初始化
memset((uint8_t*)&currentDataPoint, 0, sizeof(dataPoint_t))://设备状态结构体初始化
gizwitsInit()://缓冲区初始化
18
19
20
21
22
23
   //数据采集
25 void userHandle(void)
26 ⊟ {
27
28
       //判断当前LED1开关量
29
         if (LED1==0)
currentDataPoint.valueLEDonoff = 1;
          currentDataPoint.valueLEDonoff = 0;
     41
42
43
44
45
46
47
     while(1)
48
49 申
         userHandle()://用户采集
50
51
52
           giguitsHandle((dataPoint t *)&currentDataPoint)://协议协理
```

#### 6.下载验证

同原文档

作者: yyc

特别鸣谢: 爱吃栗子饼