Controller-to-stack cable type key: AFF and FAS platforms with onboard storage (except FAS25AA)	
Cable Type	Description
	Connects controller 0b or 0b1 port to the logical last disk shelf in the stack The primary path from a controller to the stack The internal storage connection
	Connects controller 0a port to the logical first disk shelf in the stack The secondary path from a controller to the stack The internal HBA connection

Controller to stack cable type key: AFE and EAS platforms with enheard storage (except EAS2EVY)