



POS Troubleshooting Guide

Quick fixes for the register, card reader and printer

Effective	Owner	Version
January 15, 2026	Jordan Lee, Assistant Manager	1.4

Try the fixes below in order. Never turn a customer away because of a technical problem — there is always a backup way to take payment.

Card reader not connecting

1. Unplug the reader's USB cable, wait 10 seconds, plug it back in.
2. If it still says "offline", restart the iPad.
3. Take cash or e-transfer and call the POS support line on the sticker under the counter.

Receipt printer jammed

1. Open the lid and pull the paper roll out.
2. Tear off the crumpled section.
3. Reload the roll with the paper feeding from the bottom.

Price won't scan

Key in the SKU from the tag manually. If the item isn't in the system, ask a manager before selling it.

Problem	Backup payment	Who to call
Card reader offline	Cash or e-transfer	POS support line
iPad won't start	Cash only, handwritten receipt	Store manager
Internet down	Card reader offline mode (up to \$500)	Store manager

Offline card payments

In offline mode the reader stores up to \$500 of card payments and sends them once the internet is back. Keep the iPad plugged in until they've gone through.

