

LOT Pager API Connector

LOT® API Connector — Device Contract (v0.1, proposal)

None of this exists in `src/server` yet. Existing relevant pieces: Fastify routes in `src/server/routes/api.ts`, `GET /api/logs` (allow-list of displayable events at ~line 1082), SSE endpoint.

1. Data model (Prisma, new)

`Device { id, userId, name, tokenHash, fwVersion, lastSeenAt, batteryPct, createdAt, revokedAt }.`
`DeviceNotification { id, deviceId, text, level, createdAt, expiresAt, deliveredAt, ackedAt }.`

2. Pairing

1. Site (Settings) → “Add Pager” → shows a 6-char claim code (10 min TTL).
2. Device in pairing mode: `POST /api/device/claim {code, hw, fw} → {deviceId, token}.`
3. Token stored in NVS; sent as `Authorization: Bearer`. Revoke from site.

3. Endpoints

Method	Path	Purpose
GET	<code>/api/device/poll?wait=25&since=<id></code>	long-poll; returns pending notifications + config
POST	<code>/api/device/event</code>	<code>{type: "copy" "ack" "boot", notificationId?, ts}</code>
POST	<code>/api/device/telemetry</code>	<code>{temp, rh, pressure, gasIAQ, lux, battery, charging}</code> batched
POST	<code>/api/device/capture</code>	multipart JPEG, only after on-device approval
GET	<code>/api/device/ota</code>	signed firmware manifest

3.1 Notification creation (server side)

The AI engine / scheduled jobs call `createDeviceNotification(userId, text, level)`; rate-limit and quiet-hour checks happen here. ### 3.2 Log integration Every event writes a log row. Add to the displayable allow-list in `/api/logs`: `device_copy`, `device_ack`, `device_notify`. ### 3.3 “Copy” button `POST /api/device/event {type:"copy", notificationId}` → log event `device_copy` with the notification text → visible in the Log tab.

4. Errors & limits

401 revoked token (device wipes and returns to pairing), 429 backoff, max payload 128 KB, telemetry ≤ 1 per minute.

5. Host tooling (hardware/tools/lotdev, planned)

Python CLI: `lotdev flash`, `lotdev provision --wifi`, `lotdev monitor`, `lotdev send "Coffee time!"` (calls notification creation for test), `lotdev selftest` (sensors/button/screen).