

LOT® Computer

QUICKSTART — v1 (pre-production, text-only edition)

This is a text-only placeholder quickstart, generated from the pre-hardware specification (docs/corporate/LOT-COMPUTER-HARDWARE-v1.md). No unit has been fabricated yet — this PDF documents the intended unboxing flow ahead of Proto 0, so the manual structure is proven before real product photography exists to fill it in.

1 PLACE

Set the 40mm × 40mm silver charging base on a flat, level surface — a desk edge within reach of where you work.

2 REST

Rest LOT® Computer on the base, polished stainless steel face down. The device has no charging port and no cable — wireless charging begins automatically.

3 WAKE

The front screen shows a short pairing code the first time the device powers on. This code is unique to your physical unit.

4 PAIR

On any device, sign in at lot-systems.com/pair and enter the code shown on the screen. Pairing requires an active Usership-tier account.

5 LIVE

Once paired, the screen stays blank until LOT® AI has something worth saying — a single short line, at most once every 20 minutes. Press COPY under any message to send it to your Log tab.

WHAT THE SCREEN DOES NOT DO

No scrolling feed. No unread-count badge. No sound, no vibration, no animation. One short line, redrawn once, then silence — by design, per the Ambient AI™ principle: present, never loud.

THE CAMERA

The front-facing camera is used only for pairing confirmation and stays powered off otherwise. No image leaves the device by default. Full detail:

docs/corporate/LOT-COMPUTER-HARDWARE-v1.md, Section 09.

LOT® Founded 7 April 2016 · COSMO® Founded 1 July 2024 · Made in the USA · brand.lot-systems.com
Generated from LOT-COMPUTER-HARDWARE-v1.md — pre-production edition, superseded once Proto 0 photography exists.