

COSMO® Cube

QUICK START GUIDE · DOCUMENT COSMO-CUBE-QUICK-START-v1

A physical extension of the LOT operating system. 40×40×5mm. 316L stainless steel. Connected to lot-systems.com.

What This Is

COSMO® Cube is a personal ambient intelligence device. It sits on a desk or pocket, receives autonomous notifications from the AI-powered LOT site, and logs behavioral snapshots back to your account through a single physical button. It is not a smartphone and has no app of its own — it is a companion terminal for your existing LOT account.

In The Box

Item	Qty
COSMO® Cube device	1
Qi wireless charging pad	1
Quick Start Guide (this document)	1

Device Layout

Side A (back) — mirror-polished #8 finish stainless steel. LOT® wordmark engraved center. No cutouts, no ports. The Qi charging coil sits behind this surface.

Side B (front) — satin-finish stainless steel. Holds the 1” grayscale display, the camera, the Copy button, and a status LED.

First Charge

1. Place the device Side A (mirror side) down, centered on the Qi charging pad.
2. The status LED pulses while charging. A full charge from empty takes approximately 2.5 hours.
3. There is no USB port on this device by design — wireless charging only. This keeps the stainless steel enclosure sealed and unbroken.

Connect To lot-systems.com

1. Power on: hold the Copy button for 3 seconds. The display shows a pairing QR code.
2. On lot-systems.com, open Settings → My Devices → Add Device, and scan the code shown on the Cube's display with your phone or webcam.
3. The device joins your 2.4GHz WiFi network and is provisioned with a unique, encrypted API key tied to your account. This key never leaves the device.
4. Once paired, the display returns to the default clock screen.

The Copy Button

The Copy button is the device's one deliberate gesture. Press it, and the Cube captures your current environmental context — temperature, humidity, pressure, light, and orientation — and sends it to your account.

1. Press the Copy button once.
2. The Cube packages a snapshot of its sensors and posts it to your account.
3. The entry appears on lot-systems.com under the **Log** tab, tagged [COSMO® Cube].
4. The status LED pulses green on success, or red if the send failed (it retries automatically, up to three times).

There is no undo and no draft. A press is a press — intentional, timestamped, logged.

Notifications

The Cube checks lot-systems.com for new notifications from your AI on a short interval. When one arrives, it appears on the display as short text — for example, “Coffee time!” — for up to 30 seconds, then the screen returns to the default clock view. Up to 10 notifications queue if they arrive close together.

Care

- Body: 316L stainless steel. Wipe with a soft, slightly damp cloth. Avoid abrasive cleaners on the mirror-polished back — they will dull the finish.
- Water resistance: IP54 (splash and dust resistant). Do not submerge. Do not charge while wet.
- Operating range: 0°C to +45°C. Storage range: -20°C to +60°C.
- The display, camera, and button openings on the front face are sealed at assembly. Do not attempt to open the enclosure — there are no user-serviceable parts inside.

Specifications At A Glance

Dimensions	40 × 40 × 5 mm, ~28g
Body	316L stainless steel, 2-part CNC
Display	1.0" grayscale OLED, 128×128
Camera	2MP, fixed focus, flush-mounted
Connectivity	WiFi 802.11n 2.4GHz, BLE 5.0
Charging	Qi wireless, 5W, ~2.5h full charge
Battery life	~18h active use, ~4 days standby
Water resistance	IP54

Full technical reference: COSMO-DEVICE-SPEC-v1.md · COSMO-SOFTWARE-API-v1.md · docs/hardware/ in the LOT-Computer repository.