```
srsran::e2sm_control
_action_executor
```

```
+ ~e2sm_control_action
  _executor()
+ get_action_id()
+ ric_control_action
  _supported()
+ execute_ric_control
  _action()
```

△
|

```
srsran::e2sm_rc_control
_action_du_executor_base
```

```
# logger
# action_id
# action_name
# action_params
# du_param_configurator
```

```
+ e2sm_rc_control_action
  _du_executor_base()
+ e2sm_rc_control_action
  _du_executor_base()
+ ~e2sm_rc_control_action
  _du_executor_base()
+ fill_ran_function_description()
+ get_action_id()
+ ric_control_action
  _supported()
+ execute_ric_control
  _action()
+ return_ctrl_failure()
```

△
|

```
srsran::e2sm_rc_control
_action_2_6_du_executor
```

```
+ e2sm_rc_control_action
  _2_6_du_executor()
+ ~e2sm_rc_control_action
  _2_6_du_executor()
+ ric_control_action
  _supported()
+ execute_ric_control
  _action()
```