```
srsran::srs_cu_up::
flu_tx_pdu_notifier

+ ~flu_tx_pdu_notifier()
+ on_new_pdu()

srsran::flu_dl_local
```

adapter

+ f1u_dl_local_adapter()
+ attach_du_handler()
+ detach_du_handler()

+ on new pdu()