srsran::srs_cu_up::
e1ap_connection_manager

+ ~e1ap_connection_manager()
+ connect_to_cu_cp()
+ handle_cu_up_e1_setup
  _request()