## **Compost Bin Blueprint**

The first step I take to make a compost bin is scavenge for dumpster wood.

## What to look for:

12 feet of post board, which can be 2x2 or 4x4 or anything squareish.

Enough 1x4 or 1x6 boards to make about 12 boards around 3 feet each.

## Also need:

Screws, a drill, some type of saw **Optional:** 

3-4 1 inch thick boards, at least 8 inches wide Chicken wire

Tinsnips Staple gun

Look for dumpster wood on the curb every trash day. Keep an eye out for those large dumpsters that people rent out, especially.

Now that I have my wood, I cut all post boards & outer boards to the same size, which can range from 2' 6" to 3'.

Now I lay 2 post boards out parallel to eachother, the length of can be wedged in between a uthe outer boards apart.

Then, I place 3-4 outer boards over the 2 post boards, equidistant Another optional part is lining the apart, 1 inch from the top & bottom of the post boards. I screw wire, which requires tin-snips & a the outer boards into the post boards. Repeat with the remaining Guide by @D.I.O.StartAnywhere posts. These will be the 2 opposite Feel free to contact if you want a sides of the bin.

I connect the opposite sides of the bin by screwing in 3-4 boards equidistant apart, 1 inch from the top & bottom, into the rear posts. This is the back side of the bin.

To secure the front side of the bin,

I take the final outer board & screw it 1 inch from the bottom of both of the front posts.

The optional part of the bin is the sliding planks in the front. These shaped post board(seen below) or in between 2 post boards.

inside of the bin with chicken staple gun.

bin made.

