



	Computer ← → Car
	Power
	S11 + T
	U1 15
1	PwrSense C4 - 15
×	Rx U2 Resistors
L43	Tx C6 _ JP1
8	GND ——— CAN
Nucleo L432KC	''' <u>+</u>
1	S 8 8
	Power Status
	Reset + 3.3V - + 9V - + 5V - + 12V -
	- - 124
USB	Sw1