User Instructions:

1. To start the game, press the button located at the bottom of the board
2. The lights, red, yellow, blue, green, and white, will turn on one at a time
3. As the player, you must wait for all the lights to go out
4. Press the button as quickly as possible after the lights go out
5. Results meanings:
    a. 350 ms or less -> “Perfect Timing!”: The player reacted on time
    b. Over 350 ms -> Too Late!”: The player pressed the button after the time margin
6. A false start occurs when the player presses the button before the light goes out; another attempt is allowed
7. The player can start another round without restarting the Pico

Images:



