
n K Malek

[A] Name: 13471 ID: 61090 2011.

1. [20%] Connect simplex, half duplex and full duplex to the correct picture.



2. [20%] Explain the purpose of REN and RB8 in SCON register. EN-1, 太允許接收資料, 获像把信箱打開。

```
3. [30%] Write code to send the mes string.
#include <reg51.h>

code char mes[]="Hello Kitty";
main()
```

```
char *str;
SM0=0;
SM1=1;
TMOD=0x20;
TH1=0xfd;
TL1=0xfd;
TR1=1;
str=mes;
while(*str!='\0')
{
    (SBUF)=*str++;
    while(II==>);
    TI=(_0_);
```

3. [30%] There are two ways to leave the idle mode:

• When any enabled interrupt generates an interrupt request, CPU will automatically set IDL=0, and the CPU will go to execute the interrupt function. After the interrupt function is executed, CPU will jump to

• (<u>Yeset</u>) will also make IDL=0, all registers are reset to their initial values, and the CPU starts to execute the program from ROM address 0000H.