
MATLAB介面



波德圖(Bode plot)

- 轉移函數在不同頻率下的增益以及對應到的角度。
- 查看設計完成的系統穩定性


•
$$T(s) = K * \frac{(s-z_1)*(s-z_2)*(s-z_3)...*(s-z_m)}{(s-p_1)*(s-p_2)*(s-p_3)...*(s-p_n)}$$

•
$$T(s) = K' * \frac{\left(1 - \frac{s}{z_1}\right) * \left(1 - \frac{s}{z_2}\right) * \left(1 - \frac{s}{z_3}\right) ... * \left(1 - \frac{s}{z_m}\right)}{\left(1 - \frac{s}{p_1}\right) * \left(1 - \frac{s}{p_2}\right) * \left(1 - \frac{s}{p_2}\right) ... * \left(1 - \frac{s}{p_n}\right)}$$

波德圖

•
$$T(s) = 1000 * \frac{(s+10^3)}{(s+10^1)*(s+10^2)}$$
,繪製波德圖(Bode plot)

•
$$T(s) = 1000 * \frac{10^3 \left(1 + \frac{s}{10^3}\right)}{10^3 \left(1 + \frac{s}{10^1}\right) * \left(1 + \frac{s}{10^2}\right)} = \frac{1000 * \left(1 + \frac{s}{10^3}\right)}{\left(1 + \frac{s}{10^1}\right) * \left(1 + \frac{s}{10^2}\right)}$$



繪製波德圖

- 指令:bode(T(s))
- 繪製出增益圖及角度圖


•
$$T(s) = 1000 * \frac{(s+10^3)}{(s+10^1)*(s+10^2)}$$


- Matlab 程式
- z=[-1000];p=[-10 -100];k=1000;
- T = zpk(z,p,k); $\Rightarrow z=[-1000]; p=[-10 -100]; k=1000; T=zpk(z,p,k)$

T =

• bode(T)

繪製波德圖





繪製波德圖

- 指令: bode(T(s))
- 繪製出增益圖及角度圖

•
$$T(s) = 10000 * \frac{(s+2)}{(s+10^1)*(s+10^2)}$$

- Matlab 程式
- z=[-2];p=[-10 -100];k=10000;
- T=zpk(z,p,k);
- bode(T)

