Integra7Control Help

Roland Integra-7 Workbench V1.2, October 2026 · Sierra Digital Audio

Introduction

The Roland Integra-7 Workbench V1.2 has two main functions.

- First, the workbench is used to search for and preview Integra-7 tones.
- Second, the workbench is used to build and maintain user defined studio sets.

A studio set is a grouping of up to 16 instruments used in a music session. For example, a 'rock band' set would have drums, bass, organ, rhythm guitar, lead guitar and possibly more instruments.

The Integra-7 has 16 predefined studio sets that are shown at startup. You can define 8 additional 'user' studio sets for your music projects. Each instrument in the studio set is assigned to MIDI part (channel) 1–16.

In your DAW project, you likely have MIDI tracks. When sending your DAW MIDI to the Integra-7, send the MIDI data to MIDI channel (part) 1–16. For example, if the studio set currently loaded on the Integra-7 has bass guitar loaded in Studio Set part 2, your DAW should send MIDI bass to the Integra-7 on DAW MIDI channel 2.

The toolbar

Button	What it does
Single Patch	Preview one tone by Bank (MSB:LSB) and Patch number.
Sound Banks	Preview all tones in an Integra-7 sound bank (loads it into the Search Results List).
Expansion Slots	Identify, or load, the expansions in the Integra-7's four virtual slots (A–D).
User Studio Sets	Set up USER1–USER8: copy a Studio Set into one, name it, rename it or delete it. See User Studio Sets below.
Saved Patches	Your saved patches for quick recall. Blue button = send the patch to the Midi Part; red X = delete it.
Mixer	A 16-part mixer for the current Studio Set: a pan (balance) knob and a volume fader for each part. See Mixer below.
Help	Opens this document.

Search Results List — how the buttons work

Each row has three small buttons right after Row:

Button	Action
● Green – Play	Preview the patch.
● Blue – Send	Select the patch on the Integra-7 without playing it.
● Red – Save	Add the patch to Saved Patches.

● Gray	Not available: the bank needs an expansion that isn't identified in one of your 4 expansion slots (use Expansion Slots).

Hover over any button for a reminder.

When the list shows Studio Sets (bank 85 — e.g. "Integra Preview", "Full Orchestra Set")

At startup the list shows all 64 Studio Sets. Press **Reset to Studio Sets** (Search for Tones panel) to show them again after a search. Names come from Scan Studio Sets and from the user sets you create; Studio Sets 25–64 show "(not scanned)" until you scan.

A Studio Set is the Integra-7's complete 16-part setup. Selecting one replaces all 16 parts. Unsaved changes to the current Studio Set are lost — save them on the Integra-7 first if you want to keep them.

Button	With a Studio Set
Play	Disabled for Studio Sets.
Send	Selects the Studio Set on the Integra-7 (always on channel 16) and fills the Studio Set panel with its 16 parts.
Save	Disabled for Studio Sets.

After Send, the Studio Set panel (titled *Integra-7 Studio Set Maintenance* with the set's number and name) re-reads the parts (about 1 second later) and shows the new Studio Set's name and tones. If it still shows the old set, press **Read Parts**.

Drag and drop is not available for Studio Sets — a Studio Set cannot be put on a single part.

When the list shows tones (a search such as "piano", or a bank from Sound Banks)

Each row is one tone. Only one part changes; the rest of the Studio Set stays as it is.

Button	With a tone
Play	Sets the patch on the Integra-7 and plays it as set in Preview Options. Choose how to preview (up/down scale, sample loop, or your own MIDI loop). The tone is sent to the selected Midi Part (the Midi Part box, or click a part in the Studio Set panel) and the preview plays on it. Click Play again to stop. The tone is also added to Recent Tones Previewed for quick replay.
Send	Only sends the patch change to the Integra-7: the tone goes to the selected Midi Part (the bold row in the Studio Set panel), nothing is played. Click a part in that panel, or set the Midi Part box, to choose the target.
Save	Adds the tone to Saved Patches.

Drag and drop — Search Results tones → Integra-7 Studio Set Maintenance panel

■ **Before dragging:** Make sure individual tones are displayed in the Search Results List (not Studio Sets). If you see Studio Set names such as "Integra Preview" or "Full Orchestra Set", the list is showing Studio Sets — drag and drop is not available from that view. Click **Reset to Studio Sets** first, then perform a tone search (e.g. type "piano" and press Search), or choose a bank from Sound Banks, so the list shows individual tones.

To assign a tone to a specific Studio Set part:

1. In the Search Results List, find the tone you want.
2. Click and hold on the **Row**, **Bank**, **Patch**, **Patch Name** or **PDF List #** cell of that row.
3. Drag it onto the target part row in the Integra-7 Studio Set Maintenance panel on the left.
4. Release — the tone is immediately sent to that part on the Integra-7.
5. The Studio Set panel updates to show the new tone name on that part.
6. To keep the change permanently, WRITE the Studio Set on the Integra-7 front panel.

Note: drag and drop assigns to exactly the part you drop on, even if several parts share the same MIDI channel. Drag and drop is only available when the list shows individual tones — not when it shows Studio Sets.

Play Entire List

Play Entire List plays every row in turn using the Preview Options you choose.

The Preview Options window stays open. The first time you press Play it opens; choose the options and press Play in the window. Leave it open and every later Play uses the options it shows — no need to confirm again. Close hides it (your choices are kept). From the Single Patch window it opens as a normal dialog: Play goes ahead, Close cancels.

Recent Tones Previewed

Each time you press the green Play button in the Search Results List, the tone is automatically added to the **Recent Tones Previewed** combo box. Select a tone from the list and press **Play** to preview it again using the same Preview Options — useful for quickly comparing tones without re-searching. Press **Delete** to remove the selected tone from the list.

Mixer

The Mixer button opens a mixer window with one channel strip for each of the 16 parts of the Studio Set that is loaded on the Integra-7. Each strip shows the part number, its receive channel and tone, a pan (balance) knob and a volume fader (0–127).

- Drag a fader up/down, or a knob up/right or down/left. The mouse wheel and arrow keys also work.
- Double-click a fader to set it to 100 (the Integra-7's default level); double-click a knob to center it.
- Each fader and knob changes exactly its own part, even if several parts share a MIDI channel.
- **Read from Integra-7** reloads the levels and pans. The mixer also updates whenever the Studio Set panel re-reads the parts.
- The mixer stays open beside the main window until you close it (Close just hides it).

The mixer edits the current Studio Set. To keep your mix, WRITE the Studio Set on the Integra-7 (for a user set, to its own number — see User Studio Sets).

User Studio Sets (USER1–USER8)

The Integra-7 has 64 Studio Set memories. Integra7Control reserves 8 of them as your user sets, USER1–USER8. By default they are Studio Sets 17–24 — the ones the sound list calls User1–User8 — so the

factory sets 1–16 are left alone. You can choose a different starting number (17–57) in the User Studio Sets window at any time — if user sets are in use it asks first; nothing on the Integra-7 is changed by moving them.

Studio Sets 1–16 are Roland's factory sets and are protected — user sets can never be written there (you can still copy from them).

Why the Integra-7 front panel is needed

The Integra-7 only saves a Studio Set from its own STUDIO SET WRITE function — its published MIDI implementation has no command to save a Studio Set into a memory number. So Integra7Control prepares everything (copies the set, sets the name), then tells you exactly which number to write to. After you press OK, it selects that number and reads the name back to check the save worked (this check needs a Midi In device).

Writing on the Integra-7 (the window shows these steps with the right number):

1. Hold SHIFT and press EDIT (WRITE MENU).
2. Choose STUDIO SET WRITE and press ENTER.
3. The name is already filled in — press ENTER.
4. Choose the user set's Studio Set number (for example 17 for USER1) and press ENTER.
5. At "Are you sure?" choose OK and press ENTER.

Sets you saved from the Integra-7's front panel

The window only knows a Studio Set's name once it has been read from the Integra-7. If you saved a set into one of the user-set numbers from the Integra-7's own front panel, press **Read Names** in the User Studio Sets window (or **Scan Studio Sets** in the main window). Any user-set number whose name isn't INIT STUDIO or USERn is then shown as *In use* with its real name.

Creating a user set

1. Click **User Studio Sets** on the toolbar and select an empty user set (for example USER1).
2. Type a **Name** (up to 16 characters).
3. In **Copy from**, choose the Studio Set to start from — its 16 parts, effects and settings are copied. (Copy from an INIT STUDIO set to start empty.)
4. Click **Copy to User Set**, then write it on the Integra-7 as shown, and press **OK**.
5. Click **Select for Editing Parts**. The window closes and the user set is selected on the Integra-7.
6. Drag tones from the Search Results List onto the parts in the Studio Set panel.
7. When it sounds right, write it on the Integra-7 again to the same number (the name is kept).

Other actions

Button	What it does
Rename	Selects the user set, gives it the new name, then you write it to the same number. The parts are kept.
Select for Editing Parts	Selects the user set on the Integra-7 and closes the window so you can change its parts by drag and drop.

Delete	Frees the user set. It is reset from a factory INIT STUDIO set (if one is known outside the user range) and named USERn again; then you write it. If no INIT STUDIO set is known, only the name is reset.

Tip: press **Scan Studio Sets** (Studio Set panel) once, so the app knows the real names of all 64 Studio Sets in your Integra-7 — including which ones are INIT STUDIO. Names of user sets you create here are updated automatically, and show in the Search Results List.

Remember: selecting a Studio Set (Copy, Rename, Delete, Select for Editing) replaces the current Studio Set — unsaved edits to it are lost.