Integra7Control Help

Roland Integra-7 Workbench V1.2, October 2026 · Sierra Digital Audio

Introduction

The Roland Integra-7 Workbench V1.2 has two main functions.

- First, the workbench is used to search for and preview Integra-7 tones.
- Second, the workbench is used to build and maintain user defined studio sets.

A studio set is a grouping of up to 16 instruments used in a music session. For example, a 'rock band' set would have drums, bass, organ, rhythm guitar, lead guitar and possibly more instruments.

The Integra-7 has 16 predefined studio sets that are shown at startup. You can define 8 additional 'user' studio sets for your music projects. Each instrument in the studio set is assigned to MIDI part (channel) 1-16.

In your DAW project, you likely have MIDI tracks. When sending your DAW MIDI to the Integra-7, send the MIDI data to MIDI channel (part) 1-16. For example, if the studio set currently loaded on the Integra-7 has bass guitar loaded in Studio Set part 2, your DAW should send MIDI bass to the Integra-7 on DAW MIDI channel 2.

The toolbar

Button	What it does
Single Patch	Preview one tone by Bank (MSB:LSB) and Patch number.
Sound Banks	Preview all tones in an Integra-7 sound bank (loads it into the Search Results List).
Expansion Slots	Identify, or load, the expansions in the Integra-7's four virtual slots (A-D).
User Studio Sets	Set up USER1-USER8: copy a Studio Set into one, name it, rename it or delete it. See *User Studio Sets* below.
Saved Patches	Your saved patches for quick recall. Blue button = send the patch to the Midi Part; red X = delete it.
Mixer	A 16-part mixer for the current Studio Set: a pan (balance) knob and a volume fader for each part. See *Mixer* below.
Help	Opens this document.

Search Results List - how the buttons work

Each row has three small buttons right after **Row**:

Button	Action
● **Green - Play**	Preview the patch.
● **Blue - Send**	Select the patch on the Integra-7 without playing it.
● **Red - Save**	Add the patch to Saved Patches.

● Gray	Not available: the bank needs an expansion that isn't identified in one of your 4 expansion slots (use **Expansion Slots**).

Hover over any button for a reminder.

When the list shows Studio Sets (bank 85 - e.g. "Integra Preview", "Full Orchestra Set")

At startup the list shows all **64 Studio Sets**. Press **Reset to Studio Sets** (Search for Tones panel) to show them again after a search. Names come from **Scan Studio Sets** and from the user sets you create; Studio Sets 25-64 show "(not scanned)" until you scan.

A **Studio Set** is the Integra-7's complete 16-part setup. Selecting one replaces **all 16 parts**. Unsaved changes to the current Studio Set are lost - save them on the Integra-7 first if you want to keep them.

Button	With a Studio Set
Play	Disabled for Studio Sets.
Send	Selects the Studio Set on the Integra-7 (always on channel 16) and fills the Studio Set panel with its 16 parts.
Save	Disabled for Studio Sets.

After Send, the Studio Set panel (titled **Studio Set:** with the set's number and name) re-reads the parts (about 1 second later) and shows the new Studio Set's name and tones. If it still shows the old set, press **Read Parts**.

Drag and drop is not available for Studio Sets - a Studio Set can't be put on a single part.

When the list shows tones (a search such as "piano", or a bank from Sound Banks)

Each row is one tone. Only one part changes; the rest of the Studio Set stays as it is.

Button	With a tone
Play	Sets the patch on the Integra-7 and plays it as set in Preview Options. Choose how to preview (up/down scale, sample loop, or your own MIDI loop). The tone is sent to the selected **Midi Part** (the Midi Part box, or click a part in the Studio Set panel) and the preview plays on it. Click Play again to stop.
Send	Only sends the patch change to the Integra-7: the tone goes to the selected Midi Part (the bold row in the Studio Set panel), nothing is played. Click a part in that panel, or set the Midi Part box, to choose the target.
Save	Adds the tone to Saved Patches.

Drag and drop (tones only): press on a row's Row, Bank, Patch, Patch Name or PDF List # cell and drag it onto a part in the Studio Set panel. The tone is put on exactly that part, even if several parts share a MIDI channel. This edits the *current* Studio Set - save it on the Integra-7 to keep the change.

Play Entire List plays every row in turn using the Preview Options you choose.

The Preview Options window stays open. The first time you press Play it opens; choose the options and press **Play** in the window. Leave it open and every later Play uses the options it shows - no need to confirm again. **Close** hides it (your choices are kept). From the Single Patch window it opens as a normal dialog: Play goes ahead, Close cancels.

Mixer

The **Mixer** button opens a mixer window with one channel strip for each of the 16 parts of the Studio Set that is loaded on the Integra-7. Each strip shows the part number, its receive channel and tone, a **pan (balance) knob** and a **volume fader** (0-127).

- Drag a fader up/down, or a knob up/right or down/left. The mouse wheel and arrow keys also work.
- Double-click a fader to set it to 100 (the Integra-7's default level); double-click a knob to center it.
- Each fader and knob changes exactly its own part, even if several parts share a MIDI channel.
- **Read from Integra-7** reloads the levels and pans. The mixer also updates whenever the Studio Set panel re-reads the parts.
- The mixer stays open beside the main window until you close it (Close just hides it).

The mixer edits the current Studio Set. To keep your mix, WRITE the Studio Set on the Integra-7 (for a user set, to its own number - see *User Studio Sets*).

User Studio Sets (USER1 - USER8)

The Integra-7 has 64 Studio Set memories. Integra7Control reserves 8 of them as your user sets, **USER1-USER8**. By default they are Studio Sets **17-24** - the ones the sound list calls User1-User8 - so the factory sets 1-16 are left alone. You can choose a different starting number (17-57) in the User Studio Sets window at any time - if user sets are in use it asks first; nothing on the Integra-7 is changed by moving them. **Studio Sets 1-16 are Roland's factory sets and are protected** - user sets can never be written there (you can still *copy from* them).

Why the Integra-7 front panel is needed

The Integra-7 only saves a Studio Set from its own **STUDIO SET WRITE** function - its published MIDI implementation has no command to save a Studio Set into a memory number. So Integra7Control prepares everything (copies the set, sets the name), then tells you exactly which number to write to. After you press OK, it selects that number and reads the name back to check the save worked (this check needs a Midi In device).

Writing on the Integra-7 (the window shows these steps with the right number):

1. Hold **SHIFT** and press **EDIT** (WRITE MENU).
2. Choose **STUDIO SET WRITE** and press **ENTER**.
3. The name is already filled in - press **ENTER**.
4. Choose the user set's Studio Set number (for example **17** for USER1) and press **ENTER**.
5. At "Are you sure?" choose **OK** and press **ENTER**.

Sets you saved from the Integra-7's front panel

The window only knows a Studio Set's name once it has been read from the Integra-7. If you saved a set into one of the user-set numbers from the Integra-7's own front panel, press **Read Names** in the User Studio Sets window (or **Scan Studio Sets** in the main window). Any user-set number whose name isn't INIT STUDIO or USER*n* is then shown as **In use** with its real name.

Creating a user set

1. Click **User Studio Sets** on the toolbar and select an empty user set (for example USER1).
2. Type a **Name** (up to 16 characters).
3. In **Copy from**, choose the Studio Set to start from - its 16 parts, effects and settings are copied. (Copy from an INIT STUDIO set to start empty.)
4. Click **Copy to User Set**, then write it on the Integra-7 as shown, and press OK.
5. Click **Select for Editing Parts**. The window closes and the user set is selected on the Integra-7.
6. Drag tones from the Search Results List onto the parts in the Studio Set panel.
7. When it sounds right, write it on the Integra-7 again to the same number (the name is kept).

Other actions

Button	What it does
Rename	Selects the user set, gives it the new name, then you write it to the same number. The parts are kept.
Select for Editing Parts	Selects the user set on the Integra-7 and closes the window so you can change its parts by drag and drop.
Delete	Frees the user set. It is reset from a factory INIT STUDIO set (if one is known outside the user range) and named **USER*n*** again; then you write it. If no INIT STUDIO set is known, only the name is reset.

Tip: press **Scan Studio Sets** (Studio Set panel) once, so the app knows the real names of all 64 Studio Sets in your Integra-7 - including which ones are INIT STUDIO. Names of user sets you create here are updated automatically, and show in the Search Results List.

Remember: selecting a Studio Set (Copy, Rename, Delete, Select for Editing) replaces the current Studio Set - unsaved edits to it are lost.