#### **Bandwidth**

and Bandwidth Measurement



Prof. Dr.-Eng. habil. Steffen Lochmann






Prof. S. Lochmann

Bandwidth



# Bitrate = Bandwidth?


NRZ:



$$B = \frac{1}{2\tau}$$

$$2B = BR$$

RZ:



$$B = \frac{1}{\tau}$$

$$B = BR$$


Gaussian Impuls:

$$B = \frac{0.2}{\tau_{\sigma}}$$




# Bandwidth?

• ideal and real filters:



• apply rect pulse to ideal LPF:







Prof. S. Lochmann

Bandwidth



#### Bandwidth?













### Principles of Bandwidth Measurement


#### A) Measurement with Spectrum Analyzer





DUT attenuates or amplifies frequencies



#### B) Measurement of Impulse Response










Prof. S. Lochmann

Bandwidth




#### Spectrum Analyzer



Spectrum Analyzer or Vector Netwerk Analyzer




DUT





# Spectrum Analyzer







Prof. S. Lochmann


Bandwidth





# (Vector) Network Analyzer
















# (Vector) Network Analyzer










Prof. S. Lochmann

Bandwidth



### Measurement of Impulse Response










# Measurement of Impulse Response



$$h_{meas}(t) = \delta(t) * h_{DUT}(t)$$

$$FFT$$

$$H_{meas}(f) = 1 \bullet H_{DUT}(f)$$

$$H_{DUT}(f) = H_{meas}(f)$$

$$H_{DUT}(f)[dB] = 20\log(H_{meas}(f))$$




Prof. S. Lochmann

Bandwidth



#### Measurement of Impulse Response



$$h_{meas}(t) = h_{source}(t) * h_{DUT}(t)$$

$$FFT$$

$$H_{meas}(f) \stackrel{\bullet}{=} H_{source}(f) \bullet H_{DUT}(f)$$


$$H_{DUT}(f) = H_{meas}(f) / H_{source}(f)$$

$$H_{DUT}(f)[dB] = 20\log(H_{meas}(f)) - 20\log(H_{source}(f))$$





Bandwidth






Prof. S. Lochmann


Bandwidth















Prof. S. Lochmann


Bandwidth














Prof. S. Lochmann


Bandwidth















Prof. S. Lochmann


Bandwidth




































→ causing late events – low frequency impacts















Prof. S. Lochmann


Bandwidth



# Measurement of Impulse Response













#### MSM-PD Bandwidth





Bandwidth depending of optical power

Bandwidth depending of bias voltage


Real Time Oscilloscope and


**Sampling Oscilloscope** 



Prof. Dr.-Eng. habil. Steffen Lochmann










# Real Time and Sampling Oscilloscopes



Real Time Oscilloscope: Sampling Oscilloscope:

- Suited for single signal recovery
- Internal triggering possible
- Usually lower bandwidth than sampling oscilloscopes
- Less suited for eye diagrams/error measurements
- Needs signal repetition
- Needs trigger
- Very high bandwidths possible
- Higher SNR
- Particularely suited for eye diagrams/error measurements