

Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017		Issuing Date:	23/11/2017

Assembly instruction for CPAP device

		pare the cut outs in the main enclosure		
Step	Instruction	Image		
1.0	Note the Location of Green Square. Make a cut out of 50mm x 40mm at the back side of the enclosure for the power chord & wall plug clearance.	40mm X 50mm cutout for cable entry		
		Fig.0		
1.1	Make a cutout of 20mm X 117mm for Flowmeter mounting	Fig.1		



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017		Issuing Date: 23/11/2017	

1.2 Front side of the assembly



Fig.2

1.3 Cut two PVC tubes of 500mm & 180mm length & connect the elbow connectors to the tubes as shown in the picture.



Fig.3



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Revised	Effective Date: 23/11/2017	7 Issuing Date: 23/11/2017	

1.4 Flowmeter position & mounting.



Fig.4

1.5 The threading is already done by inserting & twisting the L connector to the flow-meter inlet & outlets.



Fig.5



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New		Issuing Date: 23/11/2017	

1.6 Now the assembly should look like this.



Fig.6

.7 Cut two holes 30mm apart, as shown, for PEEP bottle mounting.




Fig.7



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017 Issuing Date: 23/1		: 23/11/2017	

Make four holes in the enclosure 1.8 & the Base plate.



Base Plate size is 130mm X 220mm




Fig.9



Fig.10



Lattice Innovations FYVE S1 SOP		Document No – <i>LI/QM/SOP/AI/CPAP</i>	
Assembly Instructions		Version No.	02
New Revised	Effective Date: 23/11/2017	Issuing Date: 23/11/2017	

9	7	
9 9		
9 0		
	000	0000
	000	0000

Fig.11

1.9 Preparation of the Humidifier

Pump mounted.

Drill two holes of 12mm dia & 110mm apart and place the threaded elbow connector as shown in the image.



Fig.12



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017		Issuing Date:	: 23/11/2017

Some masking tape can be applied for achieving better grip & air-tightness.



Fig.13

1.10 Prepare the rest for humidifier chamber



Fig.14



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017		Issuing Date	: 23/11/2017

1.11 20mm + 85mm + 175mm +85mm + 20mm U-clamp to fix the chamber in position

> 4mm mounting holes required on either side of the humidifier chamber for placing the clamp



Fig.15

1.12 Two seperate chambers for pump & humidifier placement.

Make a 22mmdia hole for air pipe clearence.



Fig.16



Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017 Issuing Date		: 23/11/2017	

1.13 Connect the inlet & outlet of the flowmeter as shown in the picture.



Fig.17

1.14 The outlet tubing from flowmeter to be connected to the humidifier.





Lattice Innovations FYVE S1 SOP		Document No – LI/QM/SOP/AI/CPAP	
Assembly Instructions		Version No.	02
New Effective Date: 23/11/2017		Issuing Date:	23/11/2017

1.15 Connect the nasal cannula & tubing to the wye connector.

Prepare the peep bottle.



Fig.19

1.16 Bottle Placement.



Fig.20



Lattice Innovations FYVE S1 SOP Assembly Instructions		Document No – LI/QM/SOP/AI/CPAP	
		Version No.	02
New Revised	Effective Date: 23/11/2017	Issuing Date: 23/11/2017	

