
# Control System Toolbox

for TI-89



release 1.2.3 ©2002-2003 Loreto Parisi

# The CST Reference Guide

Fourth ediion October 2003

Index	Page
What's Control System Toolbox for TI-89	5
Disclaimer	6
How to get help	7
How to install	8
How to upgrade	10
Examples	26
1. 1 <sup>st</sup> order LPF	26
2. Linearization	30
3. 3 <sup>rd</sup> order LPF	32
4. 2 <sup>nd</sup> order LPF	34
5. 2 <sup>nd</sup> order BPF	37
Current Version	41
New Features	43
Tips	44
Contents	43
Thanks to	44 45
What next?	43
Fun Index	
Systems	11
1. $ss2tf(A,B,C,D,iu)$	11
2. tf(num,den)	11
3. zpk(zeros,poles,gain)	11
4. c2d(sys,Tc)	12
5. d2c(sys,Tc)	12
Analysis	13
1. poly(A)	13
2. pzmap(sys)	13
3. damp(sys)	13
4. dcgain(sys)	13
5. gain(sys)	14
6. tconst(sys)	14
7. peak(sys)	14
8. tmmax(A)	14
Dynamics	15
1. trim(A,B,C,D,u0)	15
2. $\lim_{x \to 0} d(f,y,x,u,x0,u0)$	15
3. bodex()	15

The CST Reference Guide ©2002-2003 Loreto Parisi


	step(sys)		16
5.	pstep(sys)		16
6.	gstep(w_1	(t)	16
Data			17
1.	W(s)		17
2.	W(z)		17
3.	$w_1(t)$		17
	State Spac	ee	17
	$ W(\omega) $		18
6.	$\angle W(\omega)$		18
7.	mag(sys, o	$\omega(0)$	18
8.	phase(sys,	$(\omega 0)$	18
Tools	7		19
	cpoles(Cx)	)	19
	band(sys)	,	19
	polyz2s(C	x)	19
	eigenv(A)		19
	spectre(A)		20
6.	sampler(A	A,B,Tc)	20
	routh(Cx)		20
	poly2cof(e	<del>-</del>	21
9.	rts2poly(re	oots)	21
Othe	r		22
1.	File		22
2.	Settings		24
	Help		24
	About		25
5.	Exit		25
File			22
	Load		22
	1.	Session	22
	2.	State Space	22
	3.	Transfer Function	23
	4.	Step Response	23
	5.	Bode diagram	23

The CST Reference Guide ©2002-2003 Loreto Parisi


Save		23
1.	Session	23
2.	State Space	24
3.	Transfer Function	24
4.	Step Response	24

#### What's Control System Toolbox for TI-89


Control System Toolbox for TI-89 is a suite of specialized functions in Systems Control created for the TI-89 portable calculator by *Loreto Parisi* among June and July 2002. This software incorporates most of functions who cames with Control Toolbox of Matlab® by The MathWorks Inc.



After installing (see *How To Install* on page 8), to run the program on your calculator, types *CST/cst()* from folder *MAIN* and wait few seconds.



This is the main screen of *cst()*. You can see several menus, in which you can find all the function you need to work with state space, linear and non – linear models, etc., grouped in a logical order.



If you have trouble to use any function, you can choose help() from Other menu (F6), to run the useful on-line help tool, which can be used instead of this reference guide to obtain instant help. Note that this is a standalone program so you can recall it typing CST/help() from HOME.



To recall menus you can use *Function-keys* instead of arrow keys. Then to choose a function, simply select it typing the number or the letter on the left, or use the arrow keys to navigate in the menu.

#### **Disclaimer**

Copyright ©2002-2003 Loreto Parisi

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place - Suite 330, Boston, MA 02111-1307, USA.

The Open Source Philosophy

If you have an apple and I have an apple and we exchange apples then you and I will still each have one apple.

But if you have an idea and I have an idea and we exchange these ideas, then each of us will have two ideas.

This is our way of thinkin'...

#### **How To Get Help**

To get more help about CST for TI-89 and/or to send comments, questions and suggestions, you can contact me at

Loreto Parisi Via Antonio Gramsci n°13 Alife(CE) 81011 Italy

or you can send me an e-mail to this address

loretoparisi@libero.it

or visit my website at this URL


http://web.tiscali.it/loretoparisihome

You can send me feedback from here:

http://web.tiscali.it/loretoparisihome/feedback

#### **How To Install**

Use your linking software to send the program *CSTxxx*.89*G* on the calculator. All the files are automatically placed in the folder CST. Once installation has occurred, do not move, delete, or rename any of the functions and programs or pictures in the folder CST. All files included in folder CST are necessary to *cst()* to work right. For a list of files included in this folder, see *Contents*.








Run *CST\install()* from HOME. First *install()* will execute once all functions before archiving them. This tip will quitely increase execution speed.









After archiving all functions, install() will run gstep() once before archiving it, so you have to exit it pressing F7. The it will run cst() once before archiving it, so you have to exit it pressing F6 then 5, or using arrow keys and select exit from Other menu (F6).








The CST Reference Guide ©2002-2003 Loreto Parisi








To exit *help()* press *F6* then *5* or select *exit help()* from *Other* menu (*F6*). After installation you can delete *install()* from *CST* folder. To run CST type *CST\cst()* from HOME.

#### **How to Upgrade**

To upgrade CST, first send the upgrade group file CSTUPxxx.89G to the calculator. A folder named CSTUP will appear in VAR-LINK menu. Please select and load the program *upgrade()* from this folder. This will run the upgrade tool.







The program starts searching previous version of CST on the calculator and show the new upgrading version. If all informations are right, please select ENTER to upgrade.







After upgrading, it it necessary to run once first archiving programs. So follow instruction to run cst(), help() and gstep() – this only for CSTUP123.89G – and exit these programs.








After upgrading, you can delete folder CSTUP and its contents. To run CST simply press ENTER or type  $CST \setminus cst()$  from HOME.

#### **Systems**




The *Systems* menu (F1) contains all the functions to build the model, using state-space or transfer function and to perform conversions from one representation to another, even from continuous time to discrete time model.



ss2tf(A,B,C,D,iu)

Gives transfer function W(s)= $C(sI-A)^{-1}B+D$  from statespace  $\dot{x} = Ax + Bu$ , y = Cx + Du, relating to input iu (it works on MIMO systems, but only one input at time).




tf2ss(SYS)


Convert transfer function SYS in the state-space representation  $\dot{x} = Ax + Bu$ , y = Cx + Du, using the observability canonical form.



tf(NUM,DEN)

Calculates transfer function, where NUM and DEN are LIST of coefficients of numerator's and denominator's polynomial:  $NUM=\{b_0, b_1,...,b_n\}$ ,  $DEN=\{a_0,a_1,...a_n\}$ , so





zpk(zeros,poles,gain)

Calculates transfer function W(s) in the zeros-poles-gain representation, where zeros, poles are LIST of zeros of numerator and denominator (poles), while gain is NUM and represents constant gain K.

Original version: Francesco Orabona


E-mail: bremen79@infinito.it

Homepage: http://web.genie.it/utenti/b/bremen79/



 $c2d(SYS,T_c)$ 

Converts continuous time model SYS to the discrete time model, using sample time T<sub>c</sub> and different methods: ZOH and FOH filters are implemented. Can use function *tconst(SYS)* to determinate sample time T<sub>c</sub>. Use function sampler(A,B,T<sub>c</sub>) to use ZOH method.



 $d2c(SYS,T_c)$ 

Converts discrete time model SYS (in z) to the continuous time model, using sample time  $T_c$  and different methods: ZOH and FOH filters are implemented. Can use function tconst(SYS) to determinate sample time  $T_c$ . Can save the resulting continuous transfer function.

#### **Analysis**




The *Analysis* menu (F2) contains all the tools to analyze the model you have created with *Systems*' tools. You can also analyze different models, using different SYS at time. This will not change current transfer function.




poly(A)

This function calculates characteristic polynomial of matrix A, as p(s) = |sI-A|, where  $|\bullet|$  is determinat of a matrix.




pzmap(SYS)

This function calculates poles and zeros of given transfer function SYS, where poles are zeros of denominator of SYS.



damp(SYS)


Calculate natural frequencies  $\omega_{nh}$  and damping factors  $\zeta_h$  for transfer function SYS, where  $\omega_{nh} = \sqrt{\alpha_h^2 + \omega_h^2}$  and  $\zeta_h = \frac{-\alpha_h}{\omega_{nh}}$  for eigenvalue  $\lambda_h = \alpha_h + j\omega_h$ .



dcgain(SYS)


Calculates d.c. gain G for transfer function SYS, as  $G=\lim_{s\to 0} W(s)$ .

The CST Reference Guide ©2002-2003 Loreto Parisi




#### gain(SYS)

Calculates constant gain K for transfer function SYS, as  $K=\lim_{s\to 0} s^{n_0-m_0}W(s)$ , where  $n_0$  and  $m_0$  are multiplicity of zero roots for denominator and numerator.



#### tconst(SYS)

Calculates sample time  $T_c$  and time constants  $\tau_i,\,\tau_h,$  and  $T_h,$  where  $\tau_i=-\frac{1}{\lambda_i},\,\tau_h=-\frac{1}{\alpha_h}$  and  $T_h=\frac{2\pi}{\omega_h},$  while  $T_c=0.1min\{\tau_i$ ,  $\tau_h$ ,  $T_h\}.$ 



#### peak(SYS)

This function uses a proprietary numerical algorithm to calculate resonance peak  $M_p = \max_{\omega} M(\omega)$ , where  $M(\omega) = |W(s)|_{s=j_{\omega}}$  and relating frequency  $f_r$ , which is  $M(2\pi f_r) = M_P$ .




#### tmmax(A)

Calculates maximum time constant for characteristic polynomial of matrix A, in continuous or discrete time, where  $\tau_{\text{max}} = \frac{1}{\min(-\Re \lambda_i)}$  (continuous time) and  $\tau_{\text{max}} = \frac{1}{\min(\ln |\lambda_i|)}$  (discrete time).

#### **Dynamics**



The *Dynamics* menu (*F3*) contains functions concerning dynamics of system for input, output and linearization of a non-linear model, and frequency analysis yet.



 $trim(A,B,C,D,u_0)$ 

This function calculates the steady state  $x_0$ , relating to input  $u_0$  for state-space  $\dot{x} = Ax + Bu$ , y = Cx + Du.



 $linmod(f, y, x, u, x_0, u_0)$ 

This function calculates linear model for non–linear model assigned in terms of input equations f, such as  $f=\{f_1(x,u),...,f_n(x,u)\}$  and output equations y, such as  $y=\{y_1(x,u),...,y_n(x,u)\}$ , relating to constant input  $u_0$  and steady state  $x_0$ . The jacobian matrixes can be evalutated in  $x_0$ ,  $u_0$  and the state-space can be saved, or can be calculated in a symbolic way, before being evalutated.



bodex(SYS)

This program, made by 92BROTHERS, plots Bode diagrams of phase and magnitude and offers several tools to work with the plottoed diagrams.

Included in the suite CST for TI-89 with permission of 92BROTHER.



BodeX v.2.2.3

Copyright © 2000 92BROTHERS

For contacts please refers to:


e-mail: <u>92brothers@infinito.it</u> URL: http://www.92brothers.net/

The CST Reference Guide ©2002-2003 Loreto Parisi



#### step(SYS)

This tool calculates the step response for SYS, as  $U^*w_{-1}(t) = L^{-1}(W(s)U/s)$ , with amplitude U. It needs the tool DiffEq v. 2.04 or next by *Lars Frederiksen* to perform symbolic calculation of Laplace direct and inverse transformation.



#### DiffEq v. 2.04

Copyright © Lars Frederiksen


To contact please refers to

e-mail: <a href="mailto:ltf@post8.tele.dk">ltf@post8.tele.dk</a>



#### pstep(SYS)


This tool calculates characteristic parameter of step response for transfer function SYS, such as  $T_e$ ,  $T_a$ ,  $T_s$ ,  $T_p$  and s. Step response  $w_{-1}(t)$  can be specified or calculated with step(SYS). It needs DiffEq v. 2.04 or next by Lars Frederiksen (as above).




#### $gstep(w_1(t))$

This tool plots the step response w\_1(t) calculated with step(SYS) or specified directly. Can use pstep(SYS) to evalutate w\_1(t) in its typical parameters. Using parameters it applies the auto-scaling feature to obtain the correct zoom factor for the plot.

#### **Data**




The *Data* menu (F4) gives access to current transfer function W(s), its discrete model W(z), the step response w-1(t), the current state space and magnitude and phase of W(s) or W(z).




W(s)

Displays the current transfer function. SYS refers to it in all calculations of current session of *CST*, once you've calculated it with one of the tools of *Systems* menu.




W(z)

The discrete transfer function W(z), defined with c2d(SYS),Tc) using the current continuos transfer function W(s) or by sampler(A,B,Tc) using the current state space.



 $W_1(t)$ 

Shows the current step response obtained with step(SYS).




State Space

It displays the current state space, as defined from one of tools of *System* menu.




## $| w(\omega) |$

Displays magnitude of transfer function  $W(\bullet)$  in Laplace domain ( for W(s) ) and even in domain Z (for W(z) ).




#### $\angle W(\omega)$

Displays phase of transfer function  $W(\bullet)$  in Laplace domain (for W(s)) and even in domain Z (for W(z)).



 $mag(SYS, \omega_0)$ 

Calculates magnitude of SYS in Laplace domain ( for W(s)) and even in domain Z (for W(z)), relating to  $\omega_0$ .



 $phase(SYS, \omega_0)$ 

Calculates phase of SYS in Laplace domain ( for W(s)) and even in domain Z (for W(z)), relating to  $\omega_0$ .

#### **Tools**




The Tools menu (F5) offers several useful functions to complete the analysis of the model you're working and to give more detailed information about it. Moreover presents different tools for discrete systems and finite state systems.



cpoles(Cx)

It calculates zeros of polinomyal given as LIST of coefficients, Cx.



band(SYS)


This function uses a numerical algorithm and several preexistent formulas to calculate bandwith of system with transfer function SYS. It calculates  $f_i$ ,  $f_s$ , where  $B=[f_i,f_s]$ ,  $f_r$  (resonance frequency ) and  $M_p$  ( resonance peak).



polyz2s(Cx)

This tool calculates the continuous polynomial q(s), relating to discrete polynomial p(z), assigned in terms of its coefficients LIST, Cx, using the formula

$$q(s) = (s-1)^n p(z)\Big|_{z=\frac{s+1}{s-1}}$$



eingev(A)

It calculates eigenvalues and eigenvectors of matrix A.



spectre(A)

This tool calculates the spectral decomposition of matrix A, even in the continuous ( $e^{At}$ ) and in the discrete time ( $A^k$ ), relating to real eigenvalues and complex eigenvalues.

The spectral decomposition of matrix A is

$$e^{At} = \sum_{i=1}^{\mu} u_i e^{\lambda_i t} v_i^T + \sum_{h=1}^{\nu} (u_{ha} \quad u_{hb}) e^{\alpha_h t} \begin{pmatrix} \cos \omega_h t & \sin \omega_h t \\ -\sin \omega_h t & \cos \omega_h t \end{pmatrix} \begin{pmatrix} v_{ha}^T \\ v_{hb}^T \end{pmatrix}$$
(continuous time)

$$A^{k} = \sum_{i=1}^{\mu} u_{i} \lambda_{i}^{k} v_{i}^{T} + \sum_{h=1}^{\upsilon} (u_{ha} \quad u_{hb}) \rho_{h}^{k} \begin{pmatrix} \cos \theta_{h} k & \sin \theta_{h} k \\ -\sin \theta_{h} k & \cos \theta_{h} k \end{pmatrix} \begin{pmatrix} v_{ha}^{T} \\ v_{hb}^{T} \end{pmatrix}$$
(discrete time)

relating to real  $\mu$  eigenvalues  $\lambda_i$  and  $2\nu$  complex eigenvalues  $\lambda_h = \alpha_h \pm j\omega_h = \rho_h e^{\pm j\theta_h}$  and the relating eigenvector  $u_i$  and  $u_h = u_{ha} \pm u_{hb}$ .




 $sampler(A,B,T_c)$ 

This function performs the discrete time conversion of continuous time model with state-space  $\dot{x} = Ax + Bu$  at sample time  $T_c$ , using the ZOH (Zero Order Hold) method. It permits to use sample time  $T_c$  calculated with function tconst(SYS) for current transfer function SYS. It can save the resulting discrete transfer function W(z).



*routh(Cx)* 

It calculates the Routh matrix for polynomial assigned with its coefficients LIST, Cx.



poly2cof(expr,var)

Gives the LIST of coefficients of the polynomial given in *expr* in the variable *var*.

Function *poly2cof(expr,var)* included in *CST for TI-89* with permission of *Francesco Orabona*. For contacts:

E-mail: bremen79@infinito.it

Homepage: <a href="http://web.genie.it/utenti/b/bremen79/">http://web.genie.it/utenti/b/bremen79/</a>




rts2poly(roots)

Builds the polynomial with *roots* assigned as LIST.

Function *rts2poly(roots)* included in *CST for TI-89* with permission of *Chadd L. Easterday*. For contacts:

Email: easterday@mindspring.com

#### Other



The *Other* menu (*F6*) gives tools to manage files, the current working session, the *Settings*, to access to on-line help tool with *help*(), some information about CST, and the way to *exit* CST.



The *File* toolbox gives access to the File & Session Management. Here you can load and save the current working session, the State Space, the Transfer Function, the Step Response and bode diagram obtained with *bodex(SYS)*. There are three menus *Load*, *Save* and *Exit*. *Exit* menu (F3) brings to the previous toolbox.




The *Load* menu (F1) permits to load the current working session, the State Space, Transfer Function, Step Responde and bode diagrams from the specified path.




#### Load session

Loads the current working session (i.e. transfer functions W(s) and W(z),State space, w\_1(t), Tc, step response parameters,ecc.) previously saved. It overwrites all the existing values for the current session. Be carefull.



#### Load State Space

To load state space matrixes A,B,C,D from specified path. Please use absolute path. For example, if your dynamic matrix A is stored in *main* as *dyn*, you have to input *dyn* in A input field and *main* as path. All matrixes should be in the same path.




#### Load Transfer Function

Permits to load Transfer Function from specified path.



#### Load Step Response

Permits to load the Step Response from specified path.




#### Load Bode diagram

This tools permits to load a picture stored in *CST* folder. It's aid is in displaying Bode plots, created with bodex() first, and estimating the diagrams in a assigned frequency  $\omega_0$ .



The *Save* menu (F2) permits to save the current working session, the State Space, Transfer Function, Step Responde into a specified path.




#### Save session

It saves the current working session (i.e. transfer functions W(s) and W(z),State space, w\_1(t), Tc, step response parameters,ecc.).



Save State Space. Permits to save current State Space into the specified path, using given names.



Save Transfer Function. To save current transfer function into the specified path, using given name. The current SYS results from *Data* menu (F4).




Save Step Response. To save current step response into the specified path, using give name. The current step results from *Data* menu (F4).



Settings

It permits to modify some settings of the calculator, such as the *display digits*, the *angle*, and the format of *results*.



help()

The program *help()* loads the on-line help tool, which gives an instant help on all the functions of CST suite.

Note that *help*() is a standalone program also, so you can recall it from HOME, typing *CST/help*().




#### help()

To get help, simply choose a function from one of the menus and you'll get some information about it.




#### About

Gives the current version of CST *for TI-89*, the way to contact the author and to obtain support and upgrades.



#### Exit

Exit Control System Toolbox *for TI-89*. All previous settings of the calculator will be restored.



cst()


Enjoyed the journey? We'll be pleased.

#### **Examples**

Example 1. First order LPF

Considers a sample low pass filter, with transfer function W(s)= $\frac{1}{s+10}$ .


See what can be done in *CST*.



First of all, we'll define the current transfer function. From *Systems* menu (F1) choose CST function tf(NUM,DEN) where NUM=1 and DEN= $\{1,10\}$ .



This stores  $\frac{1}{s+10}$  as the current transfer function SYS.




To get relating state-space, now we'll use function tf2ss(SYS), where SYS is the current transfer function, automatically showned in the input field.




After calculation of all matrixes, they will be the current state space.



If you need to obtain the discrete model of  $\frac{1}{s+10}$ , use  $c2d(SYS,T_c)$  where SYS=w and  $T_c$  the sample time desidered. We'll use tconst(SYS) to get  $T_c$  and 'Tustin' bilinear transformation as method.




Here is the discrete time model with sample time  $T_c$  from tconst(SYS) and 'Tustin' method.




Now, we'll gonna calculate poles and zeros of  $\frac{1}{s+10}$ , considering that it is stored in w. From *Analysis* menu (*F2*) we'll choose pzmap(SYS) where SYS is the current transfer function.



We have one pole at 10 rad/sec and no zeros.




With function dcgain(SYS) we have calculated the d.c. gain of  $\frac{1}{s+10}$ , which results -20 dB.




In the same way, with function peak(SYS) we'll obtain the resonance peak  $M_P$  ( in this case it matches with previous d.c. gain G) and relating resonance frequency  $f_r$  that results .159 Hz.





From *Dynamics* menu (*F3*) we'll going to plot Bode diagrams with function bodex(SYS), courtesy of 92BROTHERS. We'll use w and 0.01 and 100 as transfer function,  $\omega_{min}$  and  $\omega_{max}$ . Current SYS is automatically showned in the W(s) input field.






Now we'll save those plots and exit *bodex()*.







We can calculate the step response using step(SYS), then we could calculate the relating parameters using function pstep(SYS).


To get steady state we'll use function  $trim(A,B,C,D,u_0)$ . Notice that x0 and y0 matches with  $w_{-1}(t)$ .






The CST Reference Guide ©2002-2003 Loreto Parisi





```
fr=undef
Mp=undef
Calculating...
Mp=.1
(Mp)dB=-20. dB
fr=.159 Hz
cst rank man func from the control of the cont
```

We have calculated the bandwith choosing band(SYS) from Tools menu (F5). Notice that  $M_P$  and  $f_r$  results from peak(SYS) when band(SYS) fails.





With *spectre*(A) we'll obtain e<sup>At</sup> and A<sup>K</sup>. Because of real pole, we have not complex expansion.









Here we have obtained discrete model of  $\frac{1}{s+10}$ , using ZOH method. Notice that only if we use tconst(SYS) we need to specify transfer function ( this because we would like to work with a transfer function different from the current one ).








From *Load* menu (F1) we'll choose *Picture* to load previous magnitude Bode plot. Here we can evalutate magnitude ( or phase ) at  $\omega_0$  choosing from *Data* menu (F1) function  $mag(SYS,\omega_0)$ .

The CST Reference Guide ©2002-2003 Loreto Parisi


#### Example 2. Linearization

Now consider a non linear model:  $\begin{cases} \dot{x}_1 = x_2 \\ \dot{x}_2 = x_1 - x_2^2 + u. \text{ To work with it, we need to linearize} \\ y = x_1 \end{cases}$ 


around a steady state  $x_0$  relating to constant input  $u_0$ . First, we have to calculate the steady state  $x_0$ . It results:  $x_0 = \begin{pmatrix} 0 \\ 0 \end{pmatrix}$  for input  $u_0 = 0$ . Now in *CST* we have:





From *Dynamics* menu (*F3*) we choose  $linmod(f,y,x,u,x_0,u_0)$  where we have  $f=\{x_2,x_1-x_2^2+u_1\}, y=\{x_1\}, x=\{x_1,x_2\}, u=\{u_1\}, x_0=\{0,0\}$  and  $u_0=\{0\}$ . We have decided to evalutate jacobian matrixex in  $x_0$  and  $u_0$  to save the state-space of obtained linearized model. Now, we can get transfer function of this new model, that is a approximation of non-linear model above around  $x_0$  and  $u_0$ :




For this linear model, we'll get natural frequencies  $\omega_{nh}$  and damping factors  $\zeta_{nh}$  using function damp(SYS) from Analysis menu (F2). Now we'll use band(SYS):










Now we'll use *spectre(SYS)* from *Tools* menu (*F5*) to calculate the spectral decomposition of matrix A:







To verify if the model is stable we can simply calculate poles of transfer function with pzmap(SYS):







As we can see, there is a positive pole who causes instability of the model.

### Example 3. 3<sup>rd</sup> order LPF

Consider a 3<sup>rd</sup> order low pass filter W(s)=
$$\frac{10000000}{s^3 + 1010s^2 + 30000s + 10100000}$$




The CST Reference Guide ©2002-2003 Loreto Parisi




Example 4. 2<sup>nd</sup> order LPF


Consider a 2<sup>nd</sup> order low pass filter W(s)= $\frac{1}{s^2+s+100}$ ;










First, we'll define transfer function and calculates state-space representation:









Now we'll get the characteristic polynomial, natural frequency and damping factor:






Then we'll calculate maximum time constant, sample time and other time constants, and the discrete model relating to previous sample time with Tustin method:









The CST Reference Guide ©2002-2003 Loreto Parisi


Eigenvalues and eigenvector:




Spectral decomposition of dynamics matrix A:



Discrete model with ZOH method:




Bandwidth, resonance peak and d.c. gain:




Notice that band(SYS) and peak(SYS) sometimes differs in values of  $M_p$  and  $f_r$ , when the first function uses formulas instead of numerical algorithm of peak(SYS).


The CST Reference Guide ©2002-2003 Loreto Parisi

#### Step response:





#### Routh matrix:








#### Bode plots:
















Example 5. 2<sup>nd</sup> order BPF


Consider a 2<sup>nd</sup> order band pass filter W(s)= $\frac{10s}{(s+110)(s+1000)}$ . We can assign this transfer function, using function zpk(zeros, poles, gain) in this way:




Now we need the state-space representation, so we use tf2ss(SYS):




We can get the relating discrete model with  $c2d(SYS,T_c)$ , but we could need to obtain time constants too, so we use tconst(SYS) and  $\tau max(A)$ :




Before plotting Bode diagrams, we could need G and bandwidth of this bpf, so we use dcgain(SYS) and band(SYS). We use peak(SYS) too, because of numerical algorithm, we could find some differences between values of resonance peak and frequency calculated with those two functions:




Notice that G is 0, so we have to use *gain(SYS)* to calculate constant gain K which results of –80dB.






Notice that  $f_i$  and  $f_s$  have two values, relating to defect and excess approximations. In this case band(SYS) has used formulas.

*Peak(SYS)* went to error because of lack of memory. This is due to too far away poles (one decade ). It's our fault! We are working to this trouble and encouraging suggestions. Anyhow, we have obtained the bandwidth and peak. Now let's calculate Bode plots:




As we can see the magnitude at  $2\pi f_r$  is  $M_p$ .


Now we'll calculate the step response with *step(SYS)*:




and the steady state with  $trim(A,B,C,D,u_0)$ :



With spectre(A) we can obtain  $e^{At}$ :




Now we uses  $sampler(A,B,T_c)$  to obtain the discretization of our filter as a digital filter using ZOH method:




Notice that we have let tconst(SYS) to calculate the sample time  $T_c$  used in discretization.

The CST Reference Guide ©2002-2003 Loreto Parisi

Finally, let's verify stability of this linear system. We'll use function routh(Cx), but we need characteristic polynomial coefficients Cx, so we follow this way:






First, get p(s) with poly(A) from *Analysis* menu (F2).





Second, get coefficients using function *poly2cof(expr, var)* from *Tools* menu (*F5*). These will appear in the next dialog window.





Here is Routh matrix. All elements of first column are positive, so stabily is assured.

#### **Current Version**

Current version of Control System Toolbox for TI-89: version 1.2.3

Date of release: October 2003

CST Reference Guide: Fourth release, October 2003

## Improvements:

- Install Tool v. 1.2

- Error management

- Session management
- Data Menu
- c2d(SYS,Tc)
- sampler(A,B,Tc)
- $gstep(w_1(t))$

#### Details:

Install Tool v.1.2

See section *How to Install*.

Error Management

This latest version of CST come with a robust internal error management, that prevents the user to lose all data of the current working session, due to an unspected abort or error.

Session Management

The user can now save the current working session (i.e. the current transfer functions W(s) and W(z), the step response  $w_1(t)$ , the state space, and all related and calculated parameters – Tc, step response parameters, ecc.) from *File* toolbox and *Save* menu. The saved session can be loaded from *Load* menu, simply selecting *Session*. All data of the latest saved working session will be restored. This overwrites the current working session, so it must be used only if you wish to load the last saved session.

- Data Menu

Now it is possible to show even the current discrete transfer function W(z), the current State Space and to obtain Magnitude and Phase for W(s) or W(z) in a simpler way.

-c2d(SYS,Tc)

This function now can save the resulting discrete transfer function as the current W(z) used in the current working session.

- sampler(A,B,Tc)

This function can now save the resulting state space as the current state space to be used in the current working session.

-  $gstep(w_1(t))$ 

This new function plot the step response  $w_1(t)$  obtained with step(SYS) or directly specified in its menu. It can use the step response parameters previously calculated by

The CST Reference Guide ©2002-2003 Loreto Parisi


*pstep(SYS)* to evalutate w\_1(t) on the plot and to use an auto-scaling function to calculate the correct zoom factor to show the plot. If there aren't calculated step response parameters, it will use standard values for the zoom factor. See section *New Feature* for more details.

#### **New Features**


Let see  $gstep(w_1(t))$  in detail. After calculating the step response  $w_1(t)$  using step(SYS), please select  $Dynamics/gstep(w_1(t)) - F3$  and then 6 – to plot the step response. In this case we have not calculated its parameters yet with pstep(SYS).










The lack of parameters do not permit to use the auto-scaling feature to obtain a zoom that matches with the specified step response. Moreover it is not possible to use the *Data* menu to show step response parameters.









It is possible to evalutate w\_1(t) in a point and see this point on the plot. You can trace and zoom the function too.








Suppose now to calculate parameters with pstep(SYS) and run  $gstep(w_1(t))$  selecting YES to use them.










The auto-scaling feature is enabled and the zoom factor now matches with the order of the step response parameters. It is possible to use Data menu to show this parameters.










Now we can use Math - Value to evalutate w\_1(t) in these specific points. Please select a parameter, such as Tr (raise time – as shown). We'll have this point on the plot.









We can *Trace* the step response and zoom it. Use *Regraph* (F4) and *Zoomprev* (from the *Zoom* menu – F2, then 9) to restore the plot.









The CST Reference Guide ©2002-2003 Loreto Parisi

Finally, it is possible to save the plot as a picuture using the *Tools* menu and *Save* option – press F1, then 1.






# **Tips**


Question: How can I get coefficients of characteristic polynomial to calculate poles or Routh matrix?

Solution: From *Analisys* menu (F2) choose poly(A) to get characteristic polynomial, then from Tools (F5) choose poly2cof(EXPR,VAR) and input 's' as variable. Now choose cpoles(Cx) or routh(Cx) from Tools menu. Here are the sequence of operations:
















Question: How can I obtain sampling time  $T_c$  to be used with c2d(SYS,Tc), that performs continuous to discrete time model conversion using bilinear Tustin transformation, or with sampler(A,B,Tc) that generates a discrete time model using ZOH filter?

Solution: From *Analisys* menu (F2) choose tconst(SYS). So you get all time constants of your system. Now choose c2d(SYS,Tc) from *Systems* menu (F1) or sampler(A,B,Tc) from *Tools* menu (F5). Here are the steps:







The CST Reference Guide ©2002-2003 Loreto Parisi



Alternatively, you can directly choose from c2d(SYS, Tc) or sampler(A,B,Tc) menu the option Sampling time with tconst() with Yes. This is useful if you have not calculated  $T_c$  yet, or if you want to input a different sampling time – in this case simply choose No and input that value in Sampling Time text field.

## **Contents**

After installation of *CST*, in the folder CST, you will find the following files:

File name	File type
azeros	FUNC
band	FUNC
bandn	FUNC
bandsub	FUNC
bodex	PRGM
c2d	FUNC
cpoles	FUNC
cst	PRGM
cstse_	LIST
cstver_	STR
d2c	FUNC
damp	FUNC
db	FUNC
degain	FUNC
degzero	FUNC
eigenv	FUNC
gain	FUNC
gstep	PRGM
help	PRGM
install	PRGM
linmod	FUNC
linspace	FUNC
logspace	FUNC
mag	FUNC
magz	FUNC
mreach	FUNC

T:1	
File name	File type
peak	FUNC
phase	FUNC
phasez	FUNC
poly	FUNC
poly2cof	FUNC
polydeg	FUNC
polyz2s	FUNC
pstep	FUNC
pzmap	FUNC
reach	FUNC
routh	FUNC
rts2poly	FUNC
sampler	FUNC
spectre	FUNC
splash	PIC
splhlp	PIC
ss2tf	FUNC
step	FUNC
tconst	FUNC
tf	FUNC
tf2ss	FUNC
trim	FUNC
zpk	FUNC
tmmax	FUNC

All these files are necessary to *cst()* to work properly. Please do not rename,move or delete any of the files above, otherwise the correct working of *cst()* is not guaranteed.

### Thanks to...

Many thanks to all those programmers which gave a hand in making CST for TI-89.

## The programmers:

### - 92BROTHERS

Contribute: bodex()

E-mail: 92brothers@infinito.it

Homepage: <a href="http://www.92brothers.net/">http://www.92brothers.net/</a>

## - Francesco Orabona

Contribute: logspace(), poly2cof(), zpk()

E-mail: bremen79@infinito.it

Homepage: <a href="http://web.genie.it/utenti/b/bremen79/">http://web.genie.it/utenti/b/bremen79/</a>

# - Lars Frederiksen Contribute: DiffEq() E-mail: ltf@post8.tele.dk

- *Chadd L. Easterday* Contribute: rts2poly()

Email: <a href="mailto:easterday@mindspring.com">easterday@mindspring.com</a>

The users

Who help CST to grow up better and faster!

Thanks all folks!

### What next?

Next version of Control System Toolbox *for TI-89 release 1.3* will improve global performances and will introduce some news, such as

- New proprietary function to plot Bode diagrams, *bode(SYS)*
- New function to calculate Root Locus, *rlocus(SYS)*
- Improved function for calculating bandwidth, *band(SYS)*
- Improved function for calculating peak, *peak(SYS)*
- New functions for system interconnections, *series(),parallel(),feedback()*
- New function to calculate time delay, *delay(SYS)*
- More to come...

If you have any question and suggestion or you would like to help me, please let me know, sending e-mail at

loretoparisi@libero.it