
#### NOTICE REGARDING QUALCOMM ATHEROS, INC.

Effective June 2016, Qualcomm Atheros, Inc. (QCA) transferred certain of its assets, including substantially all of its products and services, to its parent corporation, Qualcomm Technologies, Inc. Qualcomm Technologies, Inc. is a wholly-owned subsidiary of Qualcomm Incorporated. Accordingly, references in this document to Qualcomm Atheros, Inc., Qualcomm Atheros, Atheros, QCA or similar references, should properly reference, and shall be read to reference, Qualcomm Technologies, Inc.

2016-10-12 And Barrowas a Com



Qualcomm Atheros, Inc.



# IPQ4018/IPQ4028/IPQ4019/IPQ4029 SOHO Switch UCI Command

**User Guide** 

80-Y9571-10 Rev. B

November 18, 2015

#### Confidential and Proprietary - Qualcomm Atheros, Inc.

**NO PUBLIC DISCLOSURE PERMITTED:** Please report postings of this document on public servers or websites to: DocCtrlAgent@qualcomm.com.

Restricted Distribution: Not to be distributed to anyone who is not an employee of either Qualcomm Atheros, Inc. or its affiliated companies without the express approval of Qualcomm Configuration Management.

Not to be used, copied, reproduced, or modified in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm Atheros, Inc.

For additional information or to submit technical questions go to https://createpoint.qti.qualcomm.com/



Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. All Qualcomm Incorporated trademarks are used with permission. Other product and brand names may be trademarks or registered trademarks of their respective owners.

This technical data may be subject to U.S. and international export, re-export, or transfer ("export") laws. Diversion contrary to U.S. and international law is strictly prohibited.

## **Revision history**

Revision	Date	Description
Α	June 2015	Initial release
В	November 2015	Update 2.11.1 to 2.11.4, 2.11.10 and 2.11.11. Add 2.11.21 to 2.11.32.



# Contents

1 Overview	9
2 Switch UCI Commands	
2.1 ACL commands	
2.1.1 Rule	
2.1.2 udfprofile	
2.2 COSMAP commands	
2.2.1 dscp2pri	
2.2.2 dscp2dp	
2.2.3 up2pri	
2.2.4 up2dp	
2.2.5 dscp2ehpri	
2.2.6 dscp2ehdp	
2.2.7 up2ehpri	
2.2.8 up2ehdp	15
2.2.9 pri2q	15
2.2.10 pri2ehq	15
2.2.11 egRemark	15
2.3 FDB commands	16
2.3.1 Entry	16
2.3.2 portLearn	17
2.3.3 ageCtrl	17
2.3.4 Vlansmode	17
2.3.5 ageTime	
2.3.6 Ptlearnlimit	
2.3.7 ptlearnexceedcmd	
2.3.8 learnlimit	
2.3.9 Learnexceedcmd	
2.3.10 Resventry	
2.3.11 ptLearnstatic	
2.4 IGMP commands	
2.4.1 Mode	
2.4.2 cmd	
2.4.3 portJoin	
2.4.4 portLeave	21
2.4.5 rp 21 2.4.6 createStatus	0.4
2.4.7 Static	
2.4.9 version3	
2.4.10 Queue	
2.4.11 Ptlearnlimit	
2.4.12 Ptlearnexceedcmd	23
2.4.13 Multi	
2.5 IP commands	
2.5.1 Hostentry	
2.5.2 ptarpleran	
2.5.3 arplearn	
2.5.4 Ptipsrcquard	
2.5.5 ptarpsrcguard	
2.5.6 routestatus	

2.5.7 Intfentry	
2.5.8 ipunksrc	
2.5.9 arpunksrc	
2.5.10 ipagetime	
2.5.11 wcmphashmode	
2.5.12 defaultflowcmd	
2.5.13 defaultrtflowcmd	
2.5.14 hostroute	28
2.5.15 defaultroute	
2.5.16 vrfbaseaddr	
2.5.17 vrfbasemask	
2.5.18 Rfsip4	
2.5.19 Rfsip6	29
2.6 LEAKY commands	30
2.6.1 ucMode	30
2.6.2 mcMode	
2.6.3 arpMode	30
2.6.4 ptUcMode	31
2.6.5 ptMcMode	31
2.7 MIB commands	31
2.7.1 Status	31
2.7.2 cpuKeep	31
2.8 MIRROR commands	31
2.8.1 analyPt	32
2.8.2 ntlngress	32
2.8.2 ptIngress 2.8.3 ptEgress	32
2.9 MISC commands	22
2.9 Milot continuation	ےدک
2.9.1 frameMaxSize	
2.9.2 ptUnkUcFilter	33
2.9.3 ptUnkMcFilter	33
2.9.4 ptBcFilter	33
2.9.5 cpuPort	
2.9.6 PppoeCmd	
2.9.7 Pppoe	
2.9.8 ptDhcp	
2.9.9 arpCmd	
2.9.10 eapolCmd	
2.9.11 eapolStatus	
2.9.12 Rip	
2.9.14 Ptarpack	
2.9.15 Extendpppoe	
2.9.16 Glomacaddr	
2.9.17 Framecrcrsv	
2.10 NAT commands	
2.10.1 Natentry	
2.10.2 naptentry	
2.10.3 natstatus	
2.10.4 Nathash	
2.10.5 Naptmode	
2.10.6 Prvbaseaddr	
2.10.7 Prvbasemask	
2.10.8 pubaddr	
2.10.9 natunksess	
2.10.10 natglobal	
2.10.11 flowentry	
2.10.12 flowcookie	
2.10.13 flowrfs	
2.11 PORT commands	
2.11.1 Duplex	
2.11.2 speed	43

2.11.3 autoAdv	43
2.11.4 autoNeg	
2.11.5 txhdr	
2.11.6 rxhdr	
2.11.7 hdrtype	
2.11.8 flowCtrl	
2.11.9 flowCtrlforcemode	
2.11.10 powersave	
2.11.11 hibernate	
2.11.12 txmacstatus	
2.11.14 txfcstatus	
2.11.15 rxfcstatus	46
2.11.16 bpstatus	
2.11.17 linkforcemode	
2.11.18 macLoopback	
2.11.19 congeDrop	47
2.11.20 ringfcthreshold	
2.11.21 leee8023az	
2.11.22 crossover	41
2.11.23 prefermedium	47
2.11.24 tibermode	48
2.11.25 localloopback	48
2.11.26 remoteloopback     2.11.27 magicframemac	48
2.11.27 magicframemac	48
2.11.28 wolstatus	
2.11.29 Interfacemode	49
2.11.30 poweron	49
2.11.31 poweroff	49
2.11.32 reset	50
2.12 PORT_VLAN commands	50
2.12.1 forceVid	50
2.12.2 forceMode	
2.12.3 sVlanTPID	
2.12.4 Invlan	
2.12.5 tlsMode	
2.12.6 priPropagation	51
2.12.7 vlanPropagation	51
2.12.8 translation	
2.12.9 qinqMode	52
2.12.10 qinqRole	52
2.12.11 macvlanxlt	52
2.12.12 netiso	53
2.12.13 Egbypass	53
2.13 QoS commands	53
2.13.1 qTxBufSts	54
2.13.2 qTxBufNr	
2.13.3 ptTxBufSts	
2.13.4 ptRedEn	
2.13.5 ptTxBufNr	
2.13.6 ptRxBufNr	
2.13.7 ptMode	
2.13.8 ptModePri	
2.13.9 ptschMode	
2.13.10 ptDefaultSpri	
2.13.11 ptDefaultCpri	
2.13.12 ptFSpriSts	
2.13.13 ptFCpriSts	
2.13.14 ptQuRemark	
	56
·	56 57
2.14 RATE commands	56 57
·	56 57 57

2.14.3 queueshaper	
2.14.4 aclpolicer	60
2.14.5 ptAddRateByte	60
2.14.6 ptgolflowen	61
2.15 SEC commands	61
2.15.1 mac resv_vid	
2.15.2 mac invalid_src_addr	
2.15.3 ip invalid_ver	
2.15.4 ip set same_addr	
2.15.5 ip ttl_change_status	
2.15.6 ip ttl_val	
2.15.0 ip tit_val	
2.15.8 ip4 hdr_opts	
2.15.9 ip4 invalid_df	
2.15.10 ip4 frag_offset_min_len	
2.15.11 ip4 frag_offset_min_size	
2.15.12 ip4 frag_offset_max_len	
2.15.13 ip4 invalid_frag_offset	
2.15.14 ip4 invalid_sip	65
2.15.15 ip4 invalid_dip	
2.15.16 ip4 invalid_chksum	
2.15.17 ip4 invalid_pl	66
2.15.18 ip4 df_clear_status	66
2.15.19 ip4 ipid_random_status	66
2.15.20 ip6 invalid_dip	66
2.15.21 ip6 invalid_sip	67
2.15.22 ip6 invalid_pl	67
2.15.23 tcp blat	
2.15.24 tcp invalid_hl	67
2.15.25 tcp min_hdr_size	67
2.15.26 tcp invalid_syn	68
2.15.27 tcp su_block	68
2.15.28 tcp sp_block	
2.15.29 tcp sap_block	68
2.15.30 tcp xmas_scan	
2.15.31 tcp null_scan	
2.15.32 tcp sr_block	
2.15.33 tcp sf_block	
2.15.34 tcp sar_block	
2.15.35 tcp rst_scan	
2.15.36 tcp rst_with_data	
2.15.37 tcp fa_block	
2.15.38 tcp pa_block	
2.15.39 tcp ua_block	
2.15.40 tcp invalid_chksum	
2.15.41 tcp invalid_urgptr	
2.15.42 tcp invalid_opts	
2.15.43 udp blat	
2.15.44 udp invalid_len	
2.15.45 udp invalid_chksum	
2.15.46 icmp4 ping_pl_exceed	
2.15.47 icmp4 ping_frag	
2.15.48 icmp4 ping_max_pl	
2.15.49 icmp6 ping_pl_exceed	
2.15.50 icmp6 ping_fr	
2.15.51 icmp6 ping_max_pl	73
2.16 STP commands	
2.16.1 portState	
2.17 TRUNK commands	
2.17.1 Group	
2.17.1 Gloup	74 74
	4

2.18 VLAN commands	74
2.18.1 Entry	75
2.18.2 Member	75
2 18 3 learnets	75



## 1 Overview

This document provides a comprehensive reference for understanding and configuring QCA SOHO switch by UCI (Unified Configuration Interface) format. UCI format is intended to centralize OpenWrt configuration.

Common UCI commands are listed as below:

Setup switch by UCI format as below:

```
config switch_ext
  option device 'switch0'
  option name 'PortSpeed'
  option port_id '1'
  option speed '10'
```

As shown in this example, every switch configuration contains a 'switch\_ext' configuration. Each configuration contains multiple options. 'option name' is made up of module name and feature name.

The following chapters will introduce UCI command format for each module.

NOTE: All configs and options are case-sensitive.

# 2 Switch UCI Commands

#### 2.1 ACL commands

Config	Description	
rule	Add ACL rule	
udfprofile	Configure user defined field offset and length on a particular port.	

#### 2.1.1 Rule

UCI Command	Description
config switch_ext /*MUST have field for one rule*/	<ul> <li>rule_id = 1-95</li> <li>priority = 1-95</li> <li>rule_type = MAC   IPv4   IPv6   UDF</li> <li>dst_mac_address = destination MAC</li> <li>dst_mac_address_mask = destination MAC mask</li> <li>src_mac_address = source MAC</li> <li>src_mac_address_mask = source MAC mask</li> <li>ethernet_type = 0-0xffff</li> <li>vlan_id = 0-4095</li> <li>vlan_priority = 0-7</li> <li>tagged = 0   1</li> <li>cfi = 0   1</li> <li>ctag_vlan_id = 0-4095</li> <li>ctag_vlan_priority = 0-7</li> <li>ctagged = 0   1</li> <li>stag_cfi = 0   1</li> <li>stag_vlan_id = 0-4095</li> <li>stag_vlan_priority = 0-7</li> <li>staged = 0   1</li> <li>stag_vlan_priority = 0-7</li> <li>staged = 0   1</li> <li>stag_vlan_priority = 0-7</li> <li>staged = 0   1</li> <li>stag_cfi = 0   1</li> <li>stag_cfi = 0   1</li> <li>ipv4_src_address = IPv4 source IP address</li> <li>ipv4_dst_address = IPv4 source IP address</li> <li>ipv4_dst_address = IPv4 source IP address</li> </ul>

#### **UCI Command** Description /\*STAG mode, enhanced L2 checking field\*/ ipv6\_dst\_address = IPv4 destination IP option ctagged '1' ipv6\_flow\_label = IPv6 flow label option ctag\_vlan\_id '3' ■ ip protocol = 0-0xff option ctag\_vlan\_id\_mask '0xff' ip\_dscp = 0-63 ip\_dst\_port = IP destination port option ctag\_vlan\_priority '1' option ctag\_vlan\_priority\_mask '1' ip\_src\_port = IP source port option ctag\_cfi '1' icmp\_type = ICMP type option stagged '1' icmp\_code = ICMP code option stag\_vlan\_id '3' tcp\_flag = TCP flag ripv1 = RIP packet option stag\_vlan\_id\_mask '0xff' option stag\_vlan\_priority '1' dhcpv4 = DHCPv4 packet option stag\_vlan\_priority\_mask '1' dhcpv6 = DHCPv6 packet option stag\_dei '1' inverse\_check\_fields = 0 | 1 0 = Do not inverse any field. /\*IPv4 L3 checking field\*/ 1 = Inverse all fields in this rule. option ipv4\_src\_address '1.1.1.1' packet\_drop = yes | no option ipv4\_src\_address\_mask '1.1.1.1' redirect\_to\_cpu = yes | no option ipv4\_dst\_address '1.1.1.1' copy\_to\_cpu = yes | no option ipv4\_dst\_address\_mask '1.1.1.1' redirect\_to\_ports = destination ports bitmap /\*IPv6 L3 checking field\*/ mirror = yes | no dscp\_of\_remark = 0-63 option ipv6\_src\_address 'ff::00' queue\_of\_remark = 0-7 option ipv6 src address mask 'ff::00 port\_bitmap = define into which ports this option ipv6 dst address 'ff::00' rule binds. option ipv6\_dst\_address\_mask 'ff::00' Bit[0] for port 0 option ipv6\_flow\_label '0x12345' Bit[1] for port 1 option ipv6\_flow\_label\_mask '0xfffff' /\*IP L4 checking field\*/ Bit[6] for port 6 option ip\_protocol '1' remark\_lookup\_vid = yes | no stag\_vid\_of\_remark = 0-4095 option ip\_protocol\_mask '1' stag\_priority\_of\_remark = 0-7 option ip\_dscp '1' stag\_dei\_of\_remark = 0 | 1 option ip\_dscp\_mask '1' ctag\_vid\_of\_remark = 0-4095 option ip\_dst\_port '3' ctag\_priority\_of\_remark = 0-7 option ip\_dst\_port\_mask '0xff' ctag\_dei\_of\_remark = 0 | 1 option ip\_src\_port '3' option ip\_src\_port\_mask '0xff' action\_policer\_id = 0-31 action\_arp\_ptr = 0-127 action\_wcmp\_ptr = 0-3 /\*ICMP tcp rip dhcp flag checking field\*/ option icmp\_type '100' action\_snat = yes | no action\_dnat = yes | no option icmp\_type\_mask '0xff' bypass\_egress\_translation = yes | no option icmp\_code '100' interrupt\_trigger = yes | no option icmp code mask '0xff' option tcp\_flag '100' option tcp\_flag\_mask '0xff'

UCI Command	Description
/*RIP, DHCP checking field*/	
option ripv1 '1'	
option dhcpv4 '1'	
option dhcpv6 '1'	
/*rule forward action. if drop is yes, no action is valid.	
redirect_to_cpu and copy_to_cpu can't exist together.*/	
option inverse_check_fields 'no'	
option packet_drop 'no'	
option redirect_to_cpu 'y'	
option copy_to_cpu 'y'	
option redirect_to_ports '0x1e'	
option mirror 'y'	
/*rule vlan change action*/	
option remark_lookup_vid 'y'	
option stag_vid_of_remark '100'	
option stag_priority_of_remark '2'	
option stag_dei_of_remark '1'	all and a second
option ctag_vid_of_remark '100'	ico.
option ctag_priority_of_remark '10'	
option stag_priority_of_remark '2' option stag_dei_of_remark '1' option ctag_vid_of_remark '100' option ctag_priority_of_remark '10' option ctag_dei_of_remark '4'  /*rule dscp change action*/ option dscp_of_remark '1'  /*rule queue change action*/	
/*rule dscp change action*/	
option dscp_of_remark '1'	
option doop_or_remark 1	
/*rule queue change action*/	
option queue_of_remark '1'	
25 mm 4 mm - 2 m / 1 mm - 2 mm	
/*rule rate limit action*/	
option action_policer_id '1'	
/*rule L3 action. arp and wcmp can't exist together; snat	
and dnat can't exist together.*/	
option action_arp_ptr '1'	
option action_wcmp_ptr '1'	
option action_snat 'y'	
option action_dnat 'y'	
/*rule egress qinq bypass action and interrupt trigger	
action*/	
option bypass_egress_translation 'y'	
option interrupt_trigger 'y'	

NOTE: For rule config, below options are mandatory. Other check fields or result items are optional.

```
option device 'switch0'
option name 'AclRule'
option rule_id '1'
option priority '0'
```

```
option rule_type 'ip4'
option port_bitmap '0x1e'
option packet drop 'no'
```

#### 2.1.2 udfprofile

UCI Command	Description
config switch_ext 'acl' option device 'switch0' option name 'AclUdfprofile' option port '2' option user_defined_type 'l2' option user_defined_offset '1' option user_defined_length '4'	Set user defined field offset and length on a particular port.  port = 0-6  user_defined_type = I2/I2snap/I3/I3plus/I4  user_defined_offset = offset value  user_defined_length = 0-15

## 2.2 COSMAP commands

Config	Description
dscp2pri	Configure DSCP to internal priority mapping.
dscp2dp	Configure DSCP to drop precedence mapping.
up2pri	Configure 802.1P to internal priority mapping.
up2dp	Configure 802.1P to drop precedence mapping.
*dscp2ehpri	Configure DSCP to internal priority mapping for port 0, 5, 6.
*dscp2ehdp	Configure DSCP to drop precedence mapping for port 0, 5, 6.
*up2ehpri	Configure 802.1P to internal priority mapping for port 0, 5, 6.
*up2ehdp	Configure 802.1P to drop precedence mapping for port 0, 5, 6.
pri2q	Configure internal priority to queue mapping.
pri2ehq	Configure internal priority to enhanced queue mapping.
egRemark	Configure egress remark table.

<sup>1. \*</sup> Available for ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029 only.

## 2.2.1 dscp2pri

UCI Command	Description
config switch_ext option device 'switch0' option name 'CosmapDscp2Pri' option dscp '7' optoin pri '3'	Set DSCP to internal priority mapping.  dscp = 0-63 pri = 0-7

## 2.2.2 dscp2dp

UCI Command	Description
config switch_ext option device 'switch0' option name 'CosmapDscp2Dp' option dscp '7' optoin cfi '1'	Set DSCP to drop precedence mapping.  dscp = 0-63 cfi = 0-1

#### 2.2.3 up2pri

UCI Command	Description
config switch_ext	Set 802.1P to internal priority mapping.
option device 'switch0'	■ up = 0-7
option name 'CosmapUp2Pri'	■ priority = 0-7
option up '7'	
option pri '3'	

(3)

## 2.2.4 up2dp

UCI Command	Description
config switch_ext	Set 802.1P to drop precedence mapping.
option device 'switch0'	■ up = 0-7
option name 'CosmapUp2Dp'	• cfi = 0-1
option up '7'	The state of the s
option cfi '1'	

## 2.2.5 dscp2ehpri

UCI Command	Description
config switch_ext option device 'switch0' option name 'CosmapDscp2ehPri' option dscp '7' optoin pri '3'	Set DSCP to internal priority mapping for port 0, 5, 6.  dscp = 0-63 pri = 0-7

<sup>1.</sup> Available for ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029 only.

## 2.2.6 dscp2ehdp

UCI Command	Description
config switch_ext option device 'switch0' option name 'CosmapDscp2ehDp' option dscp '7' optoin cfi '1'	Set DSCP to drop precedence mapping for port 0, 5, 6.  dscp = 0-63 cfi = 0-1

<sup>1.</sup> Available for ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029 only.

## 2.2.7 up2ehpri

UCI Command	Description
config switch_ext option device 'switch0' option name 'CosmapUp2ehPri' option up '7' option pri '3'	Set 802.1P to internal priority mapping for port 0, 5, 6.  up = 0-7  priority = 0-7

<sup>1.</sup> Available for ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029 only.

## 2.2.8 up2ehdp

UCI Command	Description
config switch_ext	Set 802.1P to drop precedence mapping for port 0, 5, 6.
option device 'switch0'	■ up = 0-7
option name 'CosmapUp2ehDp'	• cfi = 0-1
option up '7'	
option cfi '1'	

<sup>1.</sup> Available for ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029 only.

## 2.2.9 pri2q

Command	Description
config switch_ext	Set internal priority to queue mapping.
option device 'switch0'	■ pri = 0-7
option name 'CosmapPri2Q'	• queue = 0-3
option pri '3'	
option queue '3'	

## 2.2.10 pri2ehq

Command	Description
config switch_ext	Set internal priority to port 0/5/6 queue mapping.
option device 'switch0'	■ pri = 0-7
option name 'CosmapPri2Ehq'	enhance_queue = 0-5
option pri '3'	
option enhance_queue '5'	

## 2.2.11 egRemark

UCI Command	Description
config switch_ext	Set egress remark table
option device 'switch0'	■ id = 0-15
option name 'CosmapEgRemark'	remark_dscp = enable   disable
option id '1'	<ul><li>remark_up = enable   disable</li></ul>
option remark_dscp 'enable'	<ul><li>green_dscp = 0-63, remark green frame DSCP</li></ul>
option remark_up 'enable'	<ul><li>yellow_dscp = 0-63, remark yellow frame DSCP</li></ul>
option green_dscp '63'	<ul><li>green_up = 0-7, remark green frame 802.1P</li></ul>
option yellow_dscp '7'	<ul><li>yellow_up = 0-7, remark yellow frame 802.1P</li></ul>
option green_up '7'	9
option yellow_up '1'	

## 2.3 FDB commands

Config	Description	
entry	Configure FDB entry.	
portLearn	Configure dynamic address learning status on a particular port.	
ageCtrl	Configure dynamic address aging status on particular device.	
vlansmode	Configure FDB search mode when VLAN invalid.	
ageTime	Configure dynamic address aging time.	
ptlearnlimit	Configure dynamic address learning count limit on a particular port.	
ptlearnexceedcmd	Configure dynamic address learning count exceed command on a particular port.	
learnlimit	Configure dynamic address learning count limit.	
learnexceedcmd	Configure dynamic address learning count exceed command.	
resventry	Configure reserved FDB entry.	
ptLearnstatic	Configure FDB entry learning static status of a particular port.	

## 2.3.1 Entry

UCI Command	Description
config switch_ext option device 'switch0' option name 'FdbEntry' option addr 11-22-33-44-55-66 option fid '600' option dacmd 'forward' option sacmd 'forward' option dest_port '1' option static 'yes' option leaky 'no' option mirror 'no' option clone 'no' option queue_override 'no' option cross_pt_state 'no' option white_list_en 'no' option load_balance_en 'yes' option load_balance '2'	Add a FDB entry.  addr = xx-xx-xx-xx-xx-xx  fid = 0-65535  dacmd  forward = packets are normally forwarded  drop = packets are dropped  cpycpu = packets are copied to CPU  rdtcpu = packets are redirected to CPU  sacmd  forward = packets are normally forwarded  drop = packets are dropped  cpycpu = packets are copied to CPU  rdtcpu = packets are copied to CPU  rdtcpu = packets are redirected to CPU  dest port = 0-6  static = yes   no  leaky = yes   no  mirror = yes   no  clone = yes   no  queue override = yes   no  white_list_en = yes   no  load_balance_en = yes   no, available for IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only
3 0.2	■ load_balance = 0-3, available for IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only

#### 2.3.2 portLearn

UCI Command	Description
config switch_ext	Set dynamic address learning status on a particular port.
option device 'switch0'	port_id = 0-6
option name 'FdbPortLearn'	<ul><li>learn_status = enable   disable</li></ul>
option port_id '1'	
option learn_status 'enable'	

## 2.3.3 ageCtrl

UCI Command	Description
config switch_ext	Set dynamic address aging status on particular device.
option device 'switch0'	<ul><li>aging_status = enable   disable</li></ul>
option name 'FdbAgeCtrl'	
option aging_status 'enable'	

#### 2.3.4 Vlansmode

UCI Command	Description
config switch_ext option device 'switch0' option name 'FdbVlansmode' option vlan_searching_mode 'ivl'	Set FDB search mode when VLAN is invalid.  • vlan_searching_mode = ivl   svl

## 2.3.5 ageTime

UCI Command	Description
config switch_ext	Set dynamic address aging time.
option device 'switch0'	<ul><li>aging_time = 7-458745, in second</li></ul>
option name 'FdbAgeTime'	
option aging_time '100'	

#### 2.3.6 Ptlearnlimit

UCI Command	Description
config switch_ext option device 'switch0' option name 'FdbPtlearnlimit' option port_id '1' option learn_limit_status 'enable' option learn_limit_counter '10'	Set dynamic address learning count limit on a particular port.  port_id = 0-6  learn_limit_status = enable   disable  learn_limit_counter = 0-1024

# 2.3.7 ptlearnexceedcmd

UCI Command	Description
config switch_ext option device 'switch0' option name 'FdbPtlearnexceedcmd' option port_id '1' option learn_exceed_cmd 'drop'	Set dynamic address learning count exceed command on a particular port.  port_id = 0-6  learn_exceed_cmd  forward = packets are normally forwarded  drop = packets are dropped  cpycpu = packets are copied to CPU  rdtcpu = packets are redirected to CPU

#### 2.3.8 learnlimit

UCI Command	Description
config switch_ext	Set dynamic address learning count limit.
option device 'switch0'	<ul><li>learn_limit_status = enable   disable</li></ul>
option name 'FdbLearnlimit'	learn_limit_counter = 0-2048
option learn_limit_status 'enable'	
option learn_limit_counter '100'	

#### 2.3.9 Learnexceedcmd

UCI Command	Description
config switch_ext option device 'switch0' option name 'FdbLearnexceedcmd' option learn_exceed_cmd 'drop'	Set dynamic address learning count exceed command.  learn_exceed_cmd  forward = packets are normally forwarded  drop = packets are dropped  cpycpu = packets are copied to CPU  rdtcpu = packets are redirected to CPU

## 2.3.10 Resventry

UCI Command	Description
config switch_ext	Add a reserved FDB entry.
option device 'switch0'	addr = xx-xx-xx-xx-xx
option name 'FdbResventry'	• fid = 0-65535
option addr '11-22-33-44-ee-66'	<ul><li>dacmd = forward   drop   cpycpu   rdtcpu</li></ul>
option fid '100'	<ul><li>sacmd = forward   drop   cpycpu   rdtcpu</li></ul>
option dacmd 'forward'	<ul><li>dest port = 0-6</li></ul>
option sacmd 'forward'	■ static = yes   no
option dest_port '1'	leaky = yes   no
option static 'yes'	<ul><li>mirror = yes   no</li></ul>
option leaky 'no' clone = yes   no	
option mirror 'no' queue override = yes   no	
option clone 'no'	<pre>cross_pt_state = yes   no</pre>
option queue_override 'no'	white_list_en = yes   no
option cross_pt_state 'no'	
option white_list_en 'no'	

## 2.3.11 ptLearnstatic

Command	Description	
config switch_ext	Set FDB entry learning static status of a particular port.	
option device 'switch0'	port_id = 0-6	
option name 'FdbPtLearnstatic'	<ul><li>learn_static_status = enable   disable</li></ul>	
option port_id '1'		
option learn_static_status 'enable'		

#### 2.4 IGMP commands

Config	Description
mode	Configure IGMP /MLD packets snooping status on a particular port.
cmd	Configure IGMP / MLD packets forwarding command.
portJoin	Configure IGMP / MLD join packets hardware acknowledgement status on particular port.

Config	Description
portLeave	Configure IGMP / MLD leave packets hardware acknowledgement status on a particular port.
rp	Configure IGMP / MLD router ports.
createStatus	Configure the status of creating multicast entry during IGMP/MLD Join/leave procedure.
static	Configure the static status of multicast entry which learned by hardware.
leaky	Configure the leaky status of multicast entry which learned by hardware.
version3	Configure IGMP v3/ MLD v2 packets hardware acknowledgement status.
queue	Configure the queue status of multicast entry which learned by hardware.
ptlearnlimit	Configure IGMP hardware learning count limit on a particular port.
ptlearnexceedcmd	Configure IGMP hardware learning count exceed command on a particular port.
multi	Configure IGMP / MLD entry.

#### 2.4.1 Mode

UCI Command	Description
config switch_ext	Set IGMP / MLD packets snooping status on a particular port.
option device 'switch0'	port_id = 0-6
option name 'IgmpMode'	igmp_mode = enable   disable
option port_id '1'	19. Meso
option igmp_mode 'enable'	V (600

#### 2.4.2 cmd

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpCmd' option igmp_command 'cpycpu'	Set IGMP / MLD packets forwarding command. This operation will take effect only after enabling IGMP / MLD snooping  igmp_command  forward = packets are normally forwarded  drop = packets are dropped  cpycpu = packets are copied to CPU  rdtcpu = packets are redirected to CPU

## 2.4.3 portJoin

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpPortJoin' option port_id '1' option join_status 'enable'	Set IGMP / MLD join packets hardware acknowledgement status on particular port.  port_id = 0-6  join_status  enable = hardware will learn or change multicast entry dynamically.  disable = hardware will not learn or change multicast entry dynamically.

## 2.4.4 portLeave

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpPortLeave' option port_id '1' option leave_status 'enable'	Set IGMP / MLD leave packets hardware acknowledgement status on a particular port.  port_id = 0-6  leave_status  enable = hardware will delete or change multicast entry dynamically.  disable = hardware will not delete or change multicast entry dynamically.

## 2.4.5 rp

UCI Command	Description
config switch_ext option device 'switch0' option name 'lgmpRp' option route_port_bitmap '0x40'	Set IGMP / MLD router ports. After enabling IGMP / MLD join/leave feature on a particular port, IGMP / MLD join/leave packets received on this port will be forwarded to router ports.  I route_port_bitmap  BIT[0] = port 0  BIT[1] = port 1  BIT[2] = port 2  BIT[3] = port 3  BIT[4] = port 4  BIT[5] = port 5  BIT[6] = port 6

#### 2.4.6 createStatus

UCI Command	Description
config switch_ext option device 'switch0'	Set the status of creating multicast entry during IGMP / MLD join/leave procedure.  • create status
option name 'IgmpCreateStatus' option create_status 'enable'	<ul> <li>enable = hardware will create and delete multicast entry dynamically.</li> </ul>
	<ul> <li>disable = hardware only can change destination ports of existing multicast entry.</li> </ul>

#### 2.4.7 Static

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpStatic'	Set the static status of multicast entry which learned by hardware.  static_status
option static_status 'enable'	<ul> <li>enable = hardware will not age out multicast entry which learned by hardware.</li> </ul>
	<ul> <li>disable = hardware will age out multicast entry which learned by hardware.</li> </ul>

## 2.4.8 Leaky

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpLeaky' option leaky_status 'enable'	Set the leaky status of multicast entry which learned by hardware.  leaky_status enable = hardware will set leaky flag of multicast entry which learned by hardware.
	<ul> <li>disable = hardware will not set leaky flag of multicast entry which learned by hardware.</li> </ul>

#### **2.4.9 version3**

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpVersion3' option version3_status 'enable'	Set IGMPv3/MLDv2 packets hardware acknowledgement status.  • version3_status  • enable = hardware will create or change multicast entry after receiving IGMPv3/MLDv2 packets dynamically.  • disable = hardware will not create or change multicast entry after receiving ICMPv3/MLDv2 packets.
	entry after receiving IGMPv3/MLDv2 packets dynamically.

#### 2.4.10 Queue

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpQueue' option status 'enable' option queue_id '0'	Set the queue status of multicast entry which learned by hardware.  status  enable = hardware will set queue flag of multicast entry which learned by hardware.  disable = hardware will not set queue flag of multicast entry which learned by hardware.  queue_id = 0-7

#### 2.4.11 Ptlearnlimit

UCI Command	Description
config switch_ext option device 'switch0' option name 'IgmpPtlearnlimit' option port_id '1' option learn_limit_status 'enable' option learn_limit_counter '10'	Set IGMP hardware learning count limit on a particular port.  port_id = 0-6  learn_limit_status = enable   disable  learn_limit_counter = 0-1024

#### 2.4.12 Ptlearnexceedcmd

UCI Command	Description
config switch_ext option device 'switch0' option name 'lgmpPtlearnexceedcmd' option port_id '1' option learn_exceed_cmd 'cpycpu'	Set IGMP hardware learning count exceed command on a particular port.  port_id = 0-6  learn_exceed_cmd  forward = packets are normally forwarded  drop = packets are dropped  cpycpu = packets are copied to CPU  rdtcpu = packets are redirected to CPU

#### 2.4.13 Multi

UCI Command	Description
config switch_ext	Set IGMP/MLD entry.
option device 'switch0'	<ul><li>group_type</li></ul>
option name 'IgmpMulti'	□ 0 = IPv4
option group_type '0'	Other = IPv6
option group_ip_addr '224.0.0.1'	<ul><li>group_addr = IPv4 or IPv6 address</li></ul>
option source_type '0'	<ul><li>source_type</li></ul>
option source_ip_addr '0.0.0.0'	□ 0 = IPv4
option portmap '0x14'	Other = IPv6
	<ul><li>source_addr = IPv4 or IPv6 address</li></ul>
	<ul><li>portmap</li></ul>
	<ul><li>BIT[0] = port 0</li></ul>
	<ul><li>BIT[1] = port 1</li></ul>
	<ul><li>BIT[2] = port 2</li></ul>
	<ul><li>BIT[3] = port 3</li></ul>
	<ul><li>BIT[4] = port 4</li></ul>
	<ul><li>BIT[5] = port 5</li></ul>
	<ul><li>BIT[6] = port 6</li></ul>

#### 2.5 IP commands

Config	Description
hostentry	Add a host entry.

Config	Description
ptarplearn	Set/get port based ARP learn flag.
arplearn	Set/get ARP learn mode.
ptipsrcguard	Set/get port based IP source guard.
ptarpsrcguard	Set/get port based ARP source guard.
routestatus	Set/get routing status.
intfentry	Add, delete and next interface entry.
ipunksrc	Set/get IP source unknown forwarding command.
arpunksrc	Set/get ARP source unknown forwarding command.
ipagetime	Set/get IP aging time.
wcmphashmode	Set/get WCMP hash mode.
* defaultflowcmd	Set default flow command.
* defaultrtflowcmd	Set default RT flow command.
* hostroute	Set host route entry.
* defaultroute	Set default route entry.
* vrfbaseaddr	Set VRF base address.
* vrfbasemask	Set VRF base address mask.
* Rfsip4	Set IP4 load balance.
* Rfsip6	Set IP6 load balance.

<sup>1. \*</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

## 2.5.1 Hostentry

UCI Command	Description
config switch_ext option device 'switch0' option name 'lpHostentry' option entry_id '0' option entry_flags '1'	Add a host entry with below parameter:  entryid = 0-1023  entryflags  #define FAL_IP_IP4_ADDR  #define FAL_IP_IP6_ADDR  0x2
option entry_status '0xf' option ip_addr '1.1.1.1' option mac_addr '00-00-00-00-011' option interface_id '0' opton load_balance_num '0' option vrf_id '0' option port_id '4' option action 'forward' option mirror 'no'	<ul> <li>#define FAL_IP_CPU_ADDR</li></ul>
option counter 'no'	<ul> <li>mac addr = MAC address</li> <li>interface id = 0-4094</li> <li>load_balance_num = 0-3 (available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only)</li> <li>vrf_id = 0-7 (available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only)</li> <li>port id = 0-6</li> <li>action = forward</li> <li>mirror = yes   no</li> <li>counter = yes   no</li> </ul>

## 2.5.2 ptarpleran

UCI Command	Description
config switch_ext	Set port based ARP learn flag.
option device 'switch0'	■ port = 0-6
option name 'IpPtarplearn'	• status
option port '2'	□ BIT 0 = ARP REQ
option status '3'	BIT 1 = ARP ACK

## 2.5.3 arplearn

UCI Command	Description
config switch_ext	Set ARP learn mode.
option device 'switch0'	mode = <learnlocal learnall></learnlocal learnall>
option name 'IpArplearn'	
option mode 'learnall'	

## 2.5.4 Ptipsrcguard

UCI Command	Description
config switch_ext option device 'switch0' option name 'IpPtipsrcguard' option port '2' option source_guard_mode 'mac_ip_port_vlan'	Set port based IP source guard.  • port = 0-6  • source_guard_mode = <mac_ip mac_ip_port mac_ip_vlan mac_ip_port_vlan no_guard></mac_ip mac_ip_port mac_ip_vlan mac_ip_port_vlan no_guard>

#### 2.5.5 ptarpsrcguard

UCI Command	Description
config switch_ext option device 'switch0' option name 'lpPtarpsrcguard' option port '2' option source_guard_mode	Set port based ARP source guard.  port = 0-6 source_guard_mode = <mac_ip mac_ip_port mac_ip_vlan mac_ip_port_vlan no_guard></mac_ip mac_ip_port mac_ip_vlan mac_ip_port_vlan no_guard>
'mac_ip_port_vlan'	

#### 2.5.6 routestatus

UCI Command	Description
config switch_ext option device 'switch0' option name 'IpRoutestatus' option status 'enable'	Set routing status.  status = <enable disable></enable disable>

## 2.5.7 Intfentry

UCI Command	Description
config switch_ext	Add interface entry.
option device 'switch0'	<ul><li>entry_id = 0-7</li></ul>
option name 'IpIntfentry'	<ul><li>vrf_id = 0-7 (available in</li></ul>
option entry_id '0'	IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only)
option vrf_id '0'	
option vlan_low '1'	
option vlan_high '1'	
option mac_addr '00-00-00-00-011'	
option ipv4_route 'yes'	
option ipv6_route 'yes'	

## 2.5.8 ipunksrc

UCI Command	Description
config switch_ext option device 'switch0' option name 'lplpunksrc' option action 'rdtcpu'	Set IP source unknown forwarding command.  action = <forward drop cpycpu rdtcpu></forward drop cpycpu rdtcpu>

## 2.5.9 arpunksrc

UCI Command	Description
config switch_ext	Set ARP source unknown forwarding command.
option device 'switch0'	<ul><li>action = <forward drop cpycpu rdtcpu></forward drop cpycpu rdtcpu></li></ul>
option name 'IpArpunksrc'	
option action 'forward'	

## 2.5.10 ipagetime

UCI Command	Description
config switch_ext	Set IP aging time.
option device 'switch0'	age_time = 0-255
option name 'lplpAgetime'	<ul> <li>6s*N. 0 means aging disable.</li> </ul>
option age_time '10'	

## 2.5.11 wcmphashmode

UCI Command	Description	
config switch_ext option device 'switch0' option name 'lpWcmphashmode' option wcmp_hash_mode '3'	Set/get WCMP hash mode.  wcmp_hash_mode  #define FAL_WCMP_HASH_KEY_SIP  #define FAL_WCMP_HASH_KEY_DIP  #define FAL_WCMP_HASH_KEY_SPORT	0x1 0x2 0x4
	#define FAL_WCMP_HASH_KEY_DPORT	0x8

#### 2.5.12 defaultflowcmd

UCI Command	Description
config switch_ext option device 'switch0' option name 'IpDefaultflowcmd' option vrf_id '0' option flow_type 'lan2wan' option flow_cmd 'forward'	<ul> <li>Set default flow command.</li> <li>Flow_type</li> <li>FAL_FLOW_LAN_TO_LAN = 0</li> <li>FAL_FLOW_WAN_TO_LAN</li> <li>FAL_FLOW_LAN_TO_WAN</li> <li>FAL_FLOW_WAN_TO_WAN</li> </ul>
	<ul> <li>Flow_cmd</li> <li>FAL_DEFAULT_FLOW_FORWARD = 0</li> <li>FAL_DEFAULT_FLOW_DROP</li> <li>FAL_DEFAULT_FLOW_RDT_TO_CPU</li> <li>FAL_DEFAULT_FLOW_ADMIT_ALL</li> </ul>

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

#### 2.5.13 defaultrtflowcmd

UCI Command	Description
config switch_ext	Set default RT flow command.
option device 'switch0'	<ul><li>Flow_type</li></ul>
option name 'lpDefaultrtflowcmd'	FAL_FLOW_LAN_TO_LAN = 0
option vrf_id '0'	□ FAL_FLOW_WAN_TO_LAN
option flow_type 'lan2wan'	□ FAL_FLOW_LAN_TO_WAN
option flow_cmd 'forward'	□ FAL_FLOW_WAN_TO_WAN
0 .0	■ Flow_cmd
	FAL_DEFAULT_FLOW_FORWARD = 0
O'TO Wall.	FAL_DEFAULT_FLOW_DROP
S. 11211	FAL_DEFAULT_FLOW_RDT_TO_CPU
0,0	□ FAL_DEFAULT_FLOW_ADMIT_ALL

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

## 2.5.14 hostroute

UCI Command	Description
config switch_ext option device 'switch0' option name 'lpHostRoute' option entry_id '0' option entry_valid '1' option vrf_id '0'	<ul> <li>Set host route entry.</li> <li>Entry_id = 0-15</li> <li>Entry_valid = 0-1</li> <li>Vrf_id = 0-7</li> <li>Ip_version = 0-1</li> <li>Prefix_length = 0-127</li> </ul>
option ip_version '0' option ip_addr '0.0.0.0' option prefix_length '15'	

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

#### 2.5.15 defaultroute

UCI Command	Description
config switch_ext option device 'switch0' option name 'lpDefaultRoute' option entry_id '0' option entry_valid '1' option vrf_id '0' option route_type '0' option index '0'	Set default route entry.  Entry_id = 0-15  Entry_valid = 0-1  Vrf_id = 0-7  Route_type = 0-1  index = 0-127

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

#### 2.5.16 vrfbaseaddr

UCI Command	Description
config switch_ext	Set VRF base IP address.
option device 'switch0' option name 'lpVrfbaseaddr'	Vrf_id = 0-7
option vrf_id '0' option base_addr '0.0.0.0'	and our

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

#### 2.5.17 vrfbasemask

UCI Command	Description
config switch_ext	Set VRF base IP address mask.
option device 'switch0' option name 'lpVrfbasemask' option vrf_id '0' option base_mask '255.0.0.0'	■ Vrf_id = 0-7

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

## 2.5.18 Rfsip4

UCI Command	Description
config switch_ext option device 'switch0' option name 'lpRfsip4' option mac_addr '00-00-00-00-01' option ip4_addr '0.0.0.0' option vlan_id '1' option load_balance '1'	Set IP4 load balance value.

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

## 2.5.19 Rfsip6

UCI Command	Description
config switch_ext option device 'switch0' option name 'lpRfsip6' option mac_addr '00-00-00-00-01' option ip6_addr '0.0.0.0' option vlan_id '1' opton load_balance '1'	Set IP6 load balance value.

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

#### 2.6 LEAKY commands

Config	Description	
ucMode	Configure unicast packets leaky mode.	
mcMode	Configure multicast packets leaky mode.	
arpMode	Mode Configure ARP packets leaky mode.	
ptUcMode	Set/get port based unicast packets leaky mode.	
ptMcMode	Set/get port based multicast packets leaky mode.	

#### 2.6.1 ucMode

UCI Command	Description
config switch_ext	Configure unicast packets leaky mode.
option device 'switch0'	unicast_leaky_mode = <port fdb></port fdb>
option name 'LeakyUcMode'	
option unicast_leaky_mode 'port'	
leaky ucMode set <port fdb></port fdb>	

#### 2.6.2 mcMode

UCI Command	Description
config switch_ext	Configure multicast packets leaky mode.
option device 'switch0'	multicast_leaky_mode = <port fdb></port fdb>
option name 'LeakyMcMode'	
option multicast_leaky_mode 'port'	

## 2.6.3 arpMode

UCI Command	Description
config switch_ext option device 'switch0' option name 'LeakyArpMode' option port '2' option status 'enable'	Configure ARP packets leaky mode.  status = <enable disable></enable disable>

## 2.6.4 ptUcMode

UCI Command	Description
config switch_ext option device 'switch0' option name 'LeakyPtUcMode' option port '2' option status 'enable'	Set port based unicast packets leaky mode.  status = <enable disable></enable disable>

#### 2.6.5 ptMcMode

UCI Command	Description
config switch_ext	Set port based multicast packets leaky mode.
option device 'switch0' option name 'LeakyPtMcMode' option port '2'	status = <enable disable></enable disable>
option status 'enable'	

# 2.7 MIB commands

Command	Description	
status	Configure MIB engine status.	
cpuKeep	Configure CPU keep mode.	

#### **2.7.1 Status**

UCI Command	Description
config switch_ext option device 'switch0' option name 'MibStatus' option status 'enable'	Configure MIB engine status.  status = <enable disable></enable disable>

#### 2.7.2 cpuKeep

UCI Command	Description
config switch_ext option device 'switch0' option name 'MibCpuKeep' option status 'enable'	Configure CPU keep mode.  status = <enable disable></enable disable>

## 2.8 MIRROR commands

Config	Description	
analyPt	Set/get analyzer port in switch chip for mirror.	
ptIngress	Configure ingress mirror status.	
ptEgress	Configure egress mirror status.	

## 2.8.1 analyPt

UCI Command	Description	
config switch_ext	Set analyzer port in switch chip for mirror.	
option device 'switch0'	<ul><li>analyst_port = 0-6</li></ul>	
option name 'MirrorAnalyPt'		
option analyst_port '2'		

## 2.8.2 ptIngress

UCI Command	Description
config switch_ext	Configure ingress mirror status.
option device 'switch0'	status = <enable disable></enable disable>
option name 'MirrorPtIngress'	ingress_port = 0-6
option ingress_port '2'	0. 7. 0 <sup>th</sup>
option status 'enable'	J. M.

## 2.8.3 ptEgress

Command	Description
config switch_ext	Configure ingress mirror status.
option device 'switch0'	status = <enable disable></enable disable>
option name 'MirrorPtEgress'	<pre>egress_port = 0-6</pre>
option egress_port '2'	
option status 'enable'	

## 2.9 MISC commands

Config	Description
frameMaxSize	Configure MAX frame size.
ptUnkUcFilter	Configure forwarding command for unknown source address unicast packets on one port.
ptUnkMcFilter	Configure forwarding command for unknown source address multicast packets on one port.
ptBcFilter	Configure forwarding command for unknown source address broadcast packets on one port.
cpuPort	Configure CPU port status.
PppoeCmd	Configure PPPoE frames forwarding command on switch chip.

Config	Description
Pppoe	Configure PPPoE frames hardware identification status on switch chip.
ptDhcp	Configure DHCP frames hardware identification status.
arpcmd	Configure ARP packets forwarding command on switch chip.
eapolcmd	Configure EAPOL (802.1x) packets forwarding command on switch chip.
eapolstatus	Configure EAPOL (802.1x) packets hardware acknowledgement status on one port.
rip	Configure RIP v1 packets hardware acknowledgement status on one port.
ptarpreq	Configure ARP request packet hardware acknowledgement status on switch chip.
ptarpack	Configure ARP ACK packet hardware acknowledgement status on switch chip.
extendpppoe	Add, delete and get PPPoE entries in extend mode.
* glomacaddr	Configure global MAC address.
* framecrcrsv	Configure frame CRC reserve status.

<sup>1. \*</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

#### 2.9.1 frameMaxSize

UCI Command	Description
config switch_ext	Configure MAX frame size.
option device 'switch0'	frame_max_size = 1508-9000
option name 'MiscFrameMaxSize'	1. 10 M
option frame_max_size '9000'	(a)

## 2.9.2 ptUnkUcFilter

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscPtUnkUcFilter' option port '2' option status 'enable'	Set forwarding command for unknown source address unicast packets on one port.  port = 0-6 status = <enable disable></enable disable>

## 2.9.3 ptUnkMcFilter

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscPtUnkMcFilter' option port '2' option status 'enable'	Set forwarding command for unknown source address multicast packets on one port.  port = 0-6 status = <enable disable></enable disable>

## 2.9.4 ptBcFilter

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscPtBcFilter' option port '2' option status 'enable'	Set forwarding command for broadcast packets on one port.  port = 0-6 status = <enable disable></enable disable>

#### 2.9.5 cpuPort

UCI Command	Description
config switch_ext	Configure CPU port status.
option device 'switch0'	status = <enable disable></enable disable>
option name 'MiscCpuPort'	
option status 'enable'	

## 2.9.6 PppoeCmd

UCI Command	Description
config switch_ext	Set PPPoE frames forwarding command.
option device 'switch0'	action = < forward  rdtcpu>
option name 'MiscPppoeCmd'	-alico
option action 'forward'	

## 2.9.7 Pppoe

Description
Set PPPoE frames hardware identification status. status = <enable disable></enable disable>

## 2.9.8 ptDhcp

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscPtDhcp' option port '2' option status 'enable'	Set DHCP frames hardware identification status on one port  port = 0-6  status = <enable disable></enable disable>

## 2.9.9 arpCmd

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscArpcmd' option action 'rdtcpu'	Set ARP packets forwarding command.  action = <forward cpycpu rdtcpu></forward cpycpu rdtcpu>

## 2.9.10 eapolCmd

UCI Command	Description
config switch_ext	Set EAPOL packets forwarding command.
option device 'switch0'	<ul><li>action = <cpycpu rdtcpu></cpycpu rdtcpu></li></ul>
option name 'MiscEapolcmd'	
option action 'rdtcpu'	

#### 2.9.11 eapolStatus

UCI Command	Description
config switch_ext	Set EAPOL frames hardware identification status on one port.
option device 'switch0'	• port = 0-6
option name 'MiscEapolstatus'	status = <enable disable></enable disable>
option port '2'	23. Mg
option status 'enable'	

## 2.9.12 Rip

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscRip' option status 'enable'	Set RIP v1 frames hardware identification status on one port.  status = <enable disable></enable disable>

## 2.9.13 Ptarpreq

UCI Command	Description
config switch_ext	Set ARP request packets hardware identification status.
option device 'switch0'	■ port = 0-6
option name 'MiscPtarpreq'	status = <enable disable></enable disable>
option port '2'	
option status 'enable'	

## 2.9.14 Ptarpack

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscPtarpack' option port '2' option status 'enable'	ARP request packets hardware identification status on one port.  • port = 0-6  • status = <enable disable></enable disable>

### 2.9.15 Extendpppoe

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscExtendpppoe' option entry_id '0' option session_id '1' option multicast_session 'yes' option unicast_seesion 'yes'	Add a PPPoE session entry.  entry_id = 0-31  session_id = 1-31  multicast_session = <yes no>  unicast_seesion = <yes no></yes no></yes no>

# 2.9.16 Glomacaddr

UCI Command	Description
config switch_ext	Set global MAC address.
option device 'switch0'	
option name 'MiscGloMacAddr'	
option macaddr '00-00-00-00-01'	

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.9.17 Framecrcrsv

UCI Command	Description
config switch_ext option device 'switch0' option name 'MiscFramecrc' option status 'enable'	Set frame CRC reserve status.  status = <enable disable></enable disable>

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.10 NAT commands

Config	Description	
natentry	Add, delete, get and next NAT entry.	
naptentry	Add, delete, get and next NAPT entry.	
natstatus	Set and get NAT status.	
nathash	Set and get NAT hash flag.	

Config	Description	
naptmode	Set and get NAT hash mode.	
prvbaseaddr	Set and get NAT private base address.	
pubaddr	Add, delete and next public address.	
natunksess	Set and get NAT unknown session command.	
prvbasemask	Set and get NAT private base address.	
natglobal	Set global NAT function.	
* flowentry	Add, delete, get and next flow entry.	
* flowcookie	Set flowcookie entry.	
* flowrfs	Set flowrfs entry.	

<sup>1. \*</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.10.1 Natentry

UCI Command	Description
config switch_ext option device 'switch0' option name 'NatNatentry' option entry_id '0' option entry_flags '2' option entry_status '0xf' option select_index '1' option vrf_id '0' option src_addr '1.1.1.1' option translate_addr '2.2.2.2' option port_number '0' option port_range '0' option action 'forward' option mirror 'no' option counter 'no'	Add a NAT entry.  entry_id = 0-31  entry_flags  "#define FAL_NAT_ENTRY_PORT_CHECK 0x20  entry_status = Unused  select_index = 0-7  vrf_id = 0-7 (Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.)  src_addr  When do SNAT, used to change frame SIP.  When do DNAT, compare with frame DIP  translate_addr  When do SNAT, compare with frame SIP.  When do DNAT, used to change frame DIP.  port_number  Port num start value  When do SNAT, compare with frame SP.  When do DNAT, compare with frame DP.  port_range  Port number range  Port number range  port num start<= port num <port action="&lt;forward cpycpu rdtcpu" num="" start+range="">  counter = 0-31or no  Bind to counter. Total 32.</port>

# 2.10.2 naptentry

UCI Command	Description
config switch_ext     option device 'switch0'     option name 'NatNaptentry'     option entry_id '0'     option entry_flags '0x12'     option entry_status '0xf'     option flow_cookie '0'     option load_balance '0'     option src_addr '1.1.1.1'     option dst_addr '3.3.3.3'     option translate_addr '2.2.2.2'     option src_port '10'     option dst_port '20'     option action 'forward'     option counter 'no'     option priority 'no'	Add a NAPT entry.  entry_id = 0-1023  entry_flags  define FAL_NAT_ENTRY_PROTOCOL_TCP
20 Highly	<ul> <li>When do SNAT, frame SIP should be change to IP.</li> <li>src_port</li> <li>When do SNAT, compare with frame SP.</li> <li>When do DNAT, frame DP should be change to these bits.</li> <li>dst_port</li> <li>When do SNAT, compare with frame DP.</li> </ul>

### 2.10.3 natstatus

UCI Command	Description
config switch_ext option device 'switch0' option name 'NatNatstatus' option status 'enable'	Set NAT status.  status = <enable disable></enable disable>

### 2.10.4 Nathash

UCI Command	Description	
config switch_ext option device 'switch0'	Set NAT hash mode.  • hash flag	
option name 'NatNathash'	<ul> <li>#define FAL_NAT_HASH_KEY_PORT</li> </ul>	0x40
option hash_flag '0'	#define FAL_NAT_HASH_KEY_IPADDR	08x0

# 2.10.5 Naptmode

UCI Command	Description
config switch_ext option device 'switch0' option name 'NatNaptmode' option napt_mode 'strictcone'	Set NAPT mode.  • napt_mode = <fullcone strictcone portstrict synmatric></fullcone strictcone portstrict synmatric>

### 2.10.6 Prvbaseaddr

UCI Command	Description
config switch_ext	Set NAT PRV base address.
option device 'switch0'	<ul><li>base_addr = base IP address</li></ul>
option name 'NatPrvbaseaddr'	
option base_addr '255.255.255.0'	

### 2.10.7 Prvbasemask

Description
PRV base mask.

### 2.10.8 pubaddr

UCI Command	Description
config switch_ext	Add PUB address.
option device 'switch0'	entry_id = 0-7
option name 'NatPubaddr'	
option entry_id '0'	
option pub_addr '1.1.1.1'	

### 2.10.9 natunksess

UCI Command	Description
config switch_ext	Set NAT unknown session command.
option device 'switch0'	action = <forward drop cpycpu rdtcpu></forward drop cpycpu rdtcpu>
option name 'NatNatunksess'	
option action 'drop'	

(3)

# 2.10.10 natglobal

UCI Command		Description
config switch_ext option device 'switch0' option name 'NatGlobal' option status 'enable' option sync 'disable'	10-12-19-15-3	Set global nat function.  status = <enable disable> sync = <enable disable></enable disable></enable disable>

# **2.10.11 flowentry**

config switch_ext     option device 'switch0'     option name 'NatFlowentry'     option entry_id '0'     option entry_flags '0x12'     option entry_status '0xf'     option vrf_id '0'     option flow_cookie '0'  Add a NAPT entry.  entry_id = 0-1023  entry_flags  #define FAL_NAT_ENTRY_PROTOCOL_TCP 0x1  #define FAL_NAT_ENTRY_PROTOCOL_UDP 0x2  #define FAL_NAT_ENTRY_PROTOCOL_PPTP 0x4  #define FAL_NAT_ENTRY_TRANS_IPADDR_INDEX  0x10	UCI Command	Description
option load_balance '0' option src_addr '1.1.1.1' option dst_addr '3.3.3.3' option src_port '10' option dst_port '20' option action 'forward' option mirror 'no' option counter 'no' option priority 'no'  • entry_status = 0-15  □ 15 = static □ 14-1 = dynamic □ 0 = entry invalid • vrf_id = 0-7 • flow_cookie = 0-2047 • load_balance = 0-3 • src_addr □ Source IP • dst_addr □ Destination IP • src_port □ Source port • dst_port □ Destination port • action= <forward cpycpu rdtcpu> • counter = 0-31 □ Bind to counter. Total 32.</forward cpycpu rdtcpu>	config switch_ext option device 'switch0' option name 'NatFlowentry' option entry_id '0' option entry_flags '0x12' option entry_status '0xf' option vrf_id '0' option flow_cookie '0' option load_balance '0' option src_addr '1.1.1.1' option dst_addr '3.3.3.3' option src_port '10' option dst_port '20' option action 'forward' option mirror 'no' option counter 'no'	Add a NAPT entry.  entry_id = 0-1023  entry_flags  define FAL_NAT_ENTRY_PROTOCOL_TCP

1. Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.10.12 flowcookie

UCI Command	Description
config switch_ext option device 'switch0' option name 'NatFlowcookie' option proto '1' option src_addr '1.1.1.1' option dst_addr '3.3.3.3' option src_port '10' option dst_port '20' option flow_cookie '0'	Set a flow cookie entry.  proto  #define FAL_NAT_ENTRY_PROTOCOL_TCP

1. Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.10.13 flowrfs

UCI Command	Description
config switch_ext option device 'switch0' option name 'NatFlowrfs' option action '1' option proto '1' option src_addr '1.1.1.1' option dst_addr '3.3.3.3' option src_port '10' option dst_port '20' option flow_rfs '0'	Set a flow cookie entry.  action  define FLOW_RFS_ADD

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11 PORT commands

Config	Description
duplex	Configure duplex mode on a particular port.
speed	Configure speed on a particular port.
autoAdv	Configure auto negotiation advisement ability on a particular port.
autoNeg	Configure auto negotiation on a particular port.
txhdr	Configure status of Atheros header packets parsed on a particular port.
rxhdr	Configure status of Atheros header packets parsed on a particular port.
hdrtype	Configure Atheros header type status and value on a particular device.
flowCtrl	Configure flow control status on a particular port.
flowCtrlforcemode	Configure flow control force mode on a particular port.
powersave	Configure power saving status on a particular port.
hibernate	Configure hibernate status on a particular port.
txmacstatus	Configure status of Tx MAC on a particular port.
rxmacstatus	Configure status of Rx MAC on a particular port.
txfcstatus	Configure status of Tx flow control on a particular port.
rxfcstatus	Configure status of Rx flow control on a particular port.
bpstatus	Configure status of back pressure on a particular port.
linkforcemode	Configure link force mode on a particular port.
macLoopback	Configure loopback on a particular port.
* congeDrop	Configure congestion drop status on port queue.
* ringfcthreshold	Configure flow control threshold on ring.

<sup>1. \*</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

# 2.11.1 **Duplex**

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortDuplex'	Set duplex mode on a particular port.  port_id = 0-5  duplex = half   full
option port_id '1' option duplex 'half'	

### 2.11.2 speed

UCI Command	Description
config switch_ext	Set speed on a particular port.
option device 'switch0'	■ port_id = 0-5
option name 'PortSpeed'	speed =10   100   1000 = 10M, 100M, 1000M
option port_id '1'	
option speed '10'	

### 2.11.3 autoAdv

UCI Command	Description
config switch_ext	Set auto negotiation advisement ability on a particular port.
option device 'switch0'	<ul><li>port_id = 0-5</li></ul>
option name 'PortAutoAdv'	<ul><li>auto_adv</li></ul>
option port_id '1'	<ul><li>BIT[0] = 10M half</li></ul>
option auto_adv '0x23F'	<ul><li>BIT[1] = 10M full</li></ul>
<u></u>	<ul> <li>BIT[2] = 100M half</li> </ul>
	<ul> <li>BIT[3] = 100M full</li> </ul>
	<ul> <li>BIT[4] = pause</li> </ul>
	<ul><li>BIT[5] = async pause</li></ul>
	<ul><li>BIT[9] = 1000M full</li></ul>

## 2.11.4 autoNeg

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortAutoNegEnable' option port_id '1'	Get auto negotiation status on a particular port.  • port_id = 0-5
config switch_ext option device 'switch0' option name 'PortAutoNegRestart' option port_id '1'	Restart auto negotiation procedure on a particular port.  • port_id = 0-5

### 2.11.5 txhdr

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortTxHdr' option port_id '1' option tx_frame_atheros_header_tag_status 'noheader'	Set status of Atheros header packets parsed on a particular port.  port_id = 0-6  tx_frame_atheros_header_tag_status  noheader = frames should be send out without header
	<ul> <li>onlymanagement = only management frame should be send out with header, normal packet without header</li> <li>allframe = all frames should be send out with header</li> </ul>

### 2.11.6 rxhdr

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortRxHdr' option port_id '1' option rx_frame_atheros_header_tag_status 'noheader'	Set status of Atheros header packets parsed on a particular port.  port_id = 0-6  rx_frame_atheros_header_tag_status noheader = frame should be received without header  onlymanagement = only management frame should be received with header  allframe = all frame with header

# 2.11.7 hdrtype

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortHdrType' option atheros_header_tag_status 'enable' option atheros_header_tag_type '0x10'	Set Atheros header type status and value on a particular device.  atheros_header_tag_status = enable   disable  atheros_header_tag_type = 0x0-0xffff

### 2.11.8 flowCtrl

UCI Command	Description
config switch_ext	Set flow control status on a particular port.
option device 'switch0'	port_id = 0-6
option name 'PortFlowCtrl'	flow_control_status = enable   disable
option port_id '1'	
option flow_control_status 'enable'	

### 2.11.9 flowCtrlforcemode

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortFlowCtrlForceMode' option port_id '1' option flow_control_force_mode_status 'enable'	Set flow control force mode on a particular port.  port_id = 0-6  flow_control_force_mode_status = enable   disable

### **2.11.10** powersave

UCI Command	Description
config switch_ext	Set power saving status on a particular port.
option device 'switch0'	port_id = 1-5
option name 'PortPowerSave'	power_save_status = enable   disable
option port_id '1'	
option power_save_status 'enable'	<

### **2.11.11** hibernate

UCI Command	Description
config switch_ext	Set hibernate status on a particular port.
option device 'switch0'	<ul><li>port_id = 1-5</li></ul>
option name 'PortHibernate'	hibernate_status = enable   disable
option port_id '1'	
option hibernate_status 'enable'	

### 2.11.12 txmacstatus

UCI Command	Description
config switch_ext	Set status of Tx MAC on a particular port.
option device 'switch0'	port_id = 0-6
option name 'PortTxMacStatus'	<ul><li>tx_mac_status = enable   disable</li></ul>
option port_id '1'	
option tx_mac_status 'enable'	

### 2.11.13 rxmacstatus

UCI Command	Description
config switch_ext	Set status of Rx MAC on a particular port.
option device 'switch0'	port_id = 0-6
option name 'PortRxMacStatus' option port_id '1'	rx_mac_status = enable   disable
option rx_mac_status 'enable'	

### 2.11.14 txfcstatus

UCI Command	Description
config switch_ext	Set status of Tx flow control on a particular port.
option device 'switch0'	port_id = 0-6
option name 'PortTxFcStatus'	tx_flow_control_status = enable   disable
option port_id '1'	
option tx_flow_control_status 'enable'	

### 2.11.15 rxfcstatus

UCI Command	Description
config switch_ext	Set status of Rx flow control on a particular port.
option device 'switch0'	■ port_id = 0-6
option name 'PortRxFcStatus'	rx_flow_control_status = enable   disable
option port_id '1'	
option rx_flow_control_status 'enable'	

### **2.11.16 bpstatus**

UCI Command	Description
config switch_ext	Set status of back pressure on a particular port.
option device 'switch0'	port_id = 0-6
option name 'PortBpStatus'	<ul><li>back_presure_status = enable   disable</li></ul>
option port_id '1'	
option back_presure_status 'enable'	

### 2.11.17 linkforcemode

UCI Command	Description
config switch_ext	Set link force mode on a particular port.
option device 'switch0'	■ port_id = 0-6
option name 'PortLinkForceMode'	<ul><li>link_force_mode_status = enable   disable</li></ul>
option port_id '1'	
option link_force_mode_status 'enable'	

### 2.11.18 macLoopback

UCI Command	Description
config switch_ext	Set loopback on a particular port.
option device 'switch0'	<ul><li>port_id = 0-6</li></ul>
option name 'PortMacLoopback'	<ul><li>mac_loopback_status = enable   disable</li></ul>
option port_id '1'	
option mac_loopback_status 'enable'	

### 2.11.19 congeDrop

UCI Command	Description
config switch_ext	Set congestion drop on port queue.
option device 'switch0'	<ul><li>port_id = 0-5</li></ul>
option name 'PortCongeDrop'	queue_id = 0-5
option port_id '1'	<ul><li>status = enable   disable</li></ul>
option queue_id '1'	
option status 'enable'	(h)

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11.20 ringfcthreshold

UCI Command	Description
config switch_ext	Set flow control threshold on ring.
option device 'switch0'	ring_id = 0-7
option name 'PortRingFcThresh'	
option ring_id '1'	A A
option on_thresh '0x10'	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
option off_thresh '0x20'	40

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11.21 leee8023az

UCI Command	Description
config switch_ext option device 'switch0' option name 'Portleee8023az' option port_id '1' option mode 'disable'	Set az mode on port.  port_id = 1-5  mode = enable   disable

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11.22 crossover

UCI Command	Description
config switch_ext	Set crossover mode on port.
option device 'switch0' option name 'PortCrossover'	<ul><li>port_id = 1-5</li><li>mode = mdi   auto  mdix</li></ul>
option port_id '1' option mode 'mdi'	

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11.23 prefermedium

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortPreferMedium' option port_id '5' option mode 'copper'	Set prefer medium type mode on port.  port_id = 5  mode = copper   fiber

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### **2.11.24** fibermode

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortFiberMode' option port_id '5' option mode '1000bx'	Set fiber mode on port.  port_id = 5  mode = 100fx   1000bx

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

# 2.11.25 localloopback

UCI Command	Description
config switch_ext	Set local mode on port.
option device 'switch0'	port_id = 1-5
option name 'PortLocalLoopback'	mode = enable   disable
option port_id '1'	
option mode 'enable'	

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11.26 remoteloopback

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortRemoteLoopback' option port_id '1' option mode 'enable'	Set remote loopback mode on port.  port_id = 1-5  mode = enable   disable

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

# 2.11.27 magicframemac

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortMagicFrameMac' option port_id '1' option macaddr '00-00-00-11-22'	Set magic frame MAC address on port.  port_id = 1-5  macaddr = xx-xx-xx-xx-xx

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### **2.11.28 wolstatus**

UCI Command		Description
config switch_ext option device 'switch0' option name 'PortWolstatus' option port_id '1' option mode 'enable'	Ò.	Set WOL mode on port.  port_id = 1-5  mode = enable   disable

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

# 2.11.29 Interfacemode

UCI Command	Description
config switch_ext	Set interface mode on port.
option device 'switch0'	port_id = 5
option name 'PortInterfaceMode'	■ mode =
option port_id '5'	psgmii_baset psgmii_bx1000 psgmii_fx100
option mode 'psgmii_baset'	psgmii_amdet sgmii_baset

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

# 2.11.30 poweron

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortPoweron' option port_id '1'	Set power on on port.  port_id = 1-5

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

## **2.11.31 poweroff**

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortPoweroff' option port_id '1'	Set power off on port.  • port_id = 1-5

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

### 2.11.32 reset

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortReset' option port_id '1'	Set reset on port.  port_id = 1-5

<sup>1.</sup> Available in IPQ4018/IPQ4019/IPQ4028/IPQ4029 ESS only.

# 2.12 PORT\_VLAN commands

Config	Description	
forceVid	Configure force default VLAN ID status on a particular port.	
forceMode	Configure force port based VLAN status on a particular port.	
sVlanTPID	Configure nest VLAN TPID on a particular device.	
invlan	Configure ingress VLAN mode on a particular port.	
tlsMode	Configure TLS status on a particular port.	
priPropagation	Configure priority propagation status on a particular port.	
vlanPropagation	Configure VLAN propagation status on a particular port.	
translation	Configure VLAN translation entry on a particular port.	
qinqMode	Configure switch QINQ work mode.	
qinqRole	Configure QINQ role on a particular port.	
macvlanxlt	Configure egress MAC based VLAN enable status on a particular port.	
netiso	Configure net isolation function.	
egbypass	Configure egress translation filter bypass status.	

### 2.12.1 forceVid

UCI Command	Description
config switch_ext	Set force default VLAN ID status on a particular port.
option device 'switch0'	<ul><li>port_id = 0-6</li></ul>
option name 'PortvlanForceVid'	<ul><li>force_vid_status = enable   disable</li></ul>
option port_id '1'	
option force_vid_status 'enable'	

### 2.12.2 forceMode

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortvlanForceMode' option port_id '1' option force_mode 'enable'	Set force port based VLAN status on a particular port.  port_id = 0-6  force_mode = enable   disable

### 2.12.3 sVlanTPID

UCI Command	Description
config switch_ext	Set nest VLAN TPID on a particular device.
option device 'switch0'	stag_tpid = 0x0-0xffff
option name 'PortvlanSVlanTPID'	
option stag_tpid '0x88a8'	

### 2.12.4 Invlan

UCI Command	Description
config switch_ext	Set ingress VLAN mode on a particular port.
option device 'switch0'	<ul><li>port_id = 0-6</li></ul>
option name 'PortvlanInVlan'	<ul><li>ingress_tag_mode</li></ul>
option port_id '1' option ingress_tag_mode 'admit_all'	<ul> <li>admit_all = receive all packets including tagged and untagged</li> </ul>
	admit_tagged = only receive tagged packets
	<ul> <li>admit_untagged = only receive untagged packets including priority tagged</li> </ul>

### 2.12.5 tlsMode

UCI Command	Description
config switch_ext	Set TLS status on a particular port.
option device 'switch0'	■ port_id = 0-6
option name 'PortvlanTlsMode'	<ul><li>tls_mode</li></ul>
option port_id '1'	<ul> <li>enable = port work at TLS mode</li> </ul>
option tls_mode 'enable'	<ul> <li>disable = port work at NON-TLS mode</li> </ul>

### 2.12.6 priPropagation

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortvlanPriPropagation' option port_id '1' option vlan_priority_propagation_status 'enable'	Set priority propagation status on a particular port.  port_id = 0-6  vlan_priority_propagation_status = enable   disable

## 2.12.7 vlanPropagation

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortvlanVlanPropagation' option port_id '1' option vlan_propagation_mode 'replace'	Set VLAN propagation status on a particular port.  port_id = 0-6  vlan_propagation_mode  disable = VLAN propagation disable  clone = VLAN propagation mode is clone  replace = VLAN propagation mode is replace

### 2.12.8 translation

UCI Command	Description
config switch_ext	Add a VLAN translation entry to a particular port.
option device 'switch0'	<ul><li>port_id = 0-6</li></ul>
option name 'PortVlanTranslation'	<ul><li>original_vid = 0-4095</li></ul>
option port_id '1'	<ul><li>bi_direction = yes   no</li></ul>
option original_vid '100'	<ul><li>forward_direction = yes   no</li></ul>
option bi_direction 'yes'	<ul><li>reverse_direction = yes   no</li></ul>
option forward_direction 'yes'	■ svid = 0-4095
option reverse_direction 'yes'	• cvid = 0-4095
option svid '10'	<ul><li>original_vid_is_cvid = yes   no</li></ul>
option cvid '1000'	svid_enable = yes   no
option original_vid_is_cvid 'yes'	<ul><li>cvid_enable = yes   no</li></ul>
option svid_enable 'yes'	<ul><li>one_2_one_vlan = yes   no</li></ul>
option cvid_enable 'yes'	
option one_2_one_vlan 'no'	

# 2.12.9 qinqMode

UCI Command	Description
config switch_ext	Set switch QINQ work mode.
option device 'switch0'	qinq_mode = ctag   stag
option name 'PortvlanQinqMode'	
option port_id '1'	
option qinq_mode 'ctag'	

# 2.12.10 qinqRole

UCI Command	Description
config switch_ext	Set QINQ role on a particular port.
option device 'switch0'	<ul><li>port_id = 0-6</li></ul>
option name 'PortvlanQinqRole'	qinq_role = edge   core
option port_id '1'	
option qinq_role 'edge'	

### 2.12.11 macvlanxlt

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortvlanMacVlanXlt' option port_id '1' option egress_mac_based_vlan 'enable'	Set egress MAC based VLAN enable status on a particular port.  port_id = 0-6 egress_mac_based_vlan = enable   disable

### 2.12.12 netiso

UCI Command	Description
config switch_ext	Set NET isolation function.
option device 'switch0'	<ul><li>net_isolate</li></ul>
option name 'PortvlanNetiso'	enable = isolate private net and public net
option net_isolate 'enable'	<ul> <li>disable = not isolate private net and public net</li> </ul>

# **2.12.13 Egbypass**

UCI Command	Description
config switch_ext option device 'switch0' option name 'PortvlanEgBypass' option egress_translation_filter_bypass	Set egress translation filter bypass status.  • egress_translation_filter_bypass = enable   disable
'enable'	

# 2.13 QoS commands

Command	Description
qTxBufSts	Configure buffer assignment status of transmitting queue on one particular port.
qTxBufNr	Configure max occupied buffer number of transmitting queue on one particular port.
ptTxBufSts	Configure buffer assignment status of transmitting port on one particular port.
ptRedEn	Configure RED status on one particular port.
ptTxBufNr	Configure max occupied buffer number of transmitting port on one particular port.
ptRxBufNr	Configure max reserved buffer number of receiving port on one particular port.
ptMode	Configure port QoS mode status on one particular port.
ptModePri	Configure priority of one particular QoS mode on one particular port.
ptschMode	Configure traffic scheduling mode on particular one port.
ptDefaultSpri	Configure default STAG priority on one particular port.
ptDefaultCpri	Configure default CTAG priority on one particular port.
ptFSpriSts	Configure force STAG priority flag on one particular port.
ptFCpriSts	Configure force CTAG priority flag on one particular port.
ptQuRemark	Configure egress queue based CoS remark on one particular port.

# 2.13.1 qTxBufSts

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosQTxBufSts' option port_id '1' option buffer_limit 'enable'	Set buffer assignment status of transmitting queue on one particular port.  port_id = 0-6  buffer_limit = enable   disable  If enable queue Tx buffer on one port, it means each queue of this port will have fixed number buffers when transmitting packets. Otherwise they will share the whole buffers with other queues in device.

### 2.13.2 qTxBufNr

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosQTxBufNr' option port_id '1' option queue_id '3' option number '120'	Set max occupied buffer number of transmitting queue on one particular port.  port_id = 0-6  queue_id = 0-3  number = 0-120

### 2.13.3 ptTxBufSts

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtTxBufSts'	Set buffer assignment status of transmitting port on one particular port.  port_id = 0-6
option port_id '1'	<ul><li>buffer_limit = enable   disable</li></ul>
option buffer_limit 'enable'	If enable Tx buffer on one port, it means this port will have fixed number buffers when transmitting packets. Otherwise they will share the whole buffers with other ports in device.

### 2.13.4 ptRedEn

UCI Command	Description
config switch_ext	Set RED status on one particular port.
option device 'switch0'	■ port_id = 0-6
option name 'QosPtRedEn'	<ul><li>red_status = enable   disable</li></ul>
option port_id '1'	The status is to enable or disable Random Early Detection on
option red_status 'enable'	a port.

# 2.13.5 ptTxBufNr

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtTxBufNr' option port_id '1' option number '504'	Set max occupied buffer number of transmitting port on one particular port.  port_id = 0-6  number = 0-504

### 2.13.6 ptRxBufNr

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtRxBufNr' option port_id '1' option number '120'	Set max reserved buffer number of receiving port on one particular port.  port_id = 0-6  number = 0-120

### 2.13.7 ptMode

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtMode' option port_id '1' option mode 'up' option status 'enable'	Set port QoS mode status on one particular port.  port_id = 0-6  mode = da   up   dscp   flow status = enable   disable

<sup>1.</sup> Flow is available in ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029.

### 2.13.8 ptModePri

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtModePri' option port_id '1' option mode 'up' option priority '3'	Set priority of one particular QoS mode on one particular port.  port_id = 0-6  mode = da   up   dscp   flow priority = 0-3  Smaller value indicates higher priority.

<sup>2.</sup> Flow is available in ESS of IPQ4018/IPQ4019/IPQ4028/IPQ4029.

# 2.13.9 ptschMode

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtschMode' option port_id '1' option mode 'wrr' option weight '1,2,4,8,0,0'	Set traffic scheduling mode on particular one port.  port_id = 0-6  mode  sp   wrr   mix   mixplus  sp = strict priority scheduling mode  wrr = weight round robin scheduling mode  mix = SP and WRR mixed scheduling mode  mixplus = SP and WRR mixed plus scheduling mode  weight  q0,q1,q2,q3,q4,q5  Weight value (0-31) for each queue when in WRR mode.

# 2.13.10 ptDefaultSpri

UCI Command	Description
config switch_ext	Set default stag priority on one particular port.
option device 'switch0'	port_id = 0-6
option name 'QosPtDefaultSpri'	■ stag_pri = 0-7
option port_id '1'	72. N. W.
option stag_pri '7'	0, 1,000

# 2.13.11 ptDefaultCpri

UCI Command	Description
config switch_ext	Set default CTAG priority on one particular port.
option device 'switch0'	port_id = 0-6
option name 'QosPtDefaultCpri'	ctag_pri = 0-7
option port_id '1'	
option ctag_pri '7'	

### 2.13.12 ptFSpriSts

UCI Command	Description
config switch_ext	Set force stag priority flag on one particular port.
option device 'switch0'	port_id = 0-6
option name 'QosPtFSpriSts'	<ul><li>force_stag_pri_status = enable   disable</li></ul>
option port_id '1'	
option force_stag_pri_status 'enable'	

# 2.13.13 ptFCpriSts

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtFCpriSts' option port_id '1' option force_ctag_pri_status 'enable'	Set force CTAG priority flag on one particular port.  port_id = 0-6  force_ctag_pri_status = enable   disable

# 2.13.14 ptQuRemark

UCI Command	Description
config switch_ext option device 'switch0' option name 'QosPtQuRemark' option port_id '1' option queue_id '3' option table_id '1'	Set egress queue based CoS remark on one particular port.  port_id = 0-6  queue_id = 0-3  table_id = 0-15  status = enable   disable
option status 'enable'	

# 2.14 RATE commands

Config	Description	
portpolicer	Configure port ingress policer parameters on one particular port.	
portshaper	Configure port egress shaper parameters on one particular port.	
queueshaper	Configure queue egress shaper parameters on one particular port.	
aclpolicer	Configure ACL ingress policer parameters.	
ptAddRateByte	Configure byte number should be added to frame when calculate rate limit.	
ptgolflowen	Configure status of port global flow control when global threshold is reached.	

# 2.14.1 Portpolicer

#### **UCI Command** Description config switch\_ext Set port ingress policer parameters on one particular port. option device 'switch0' port\_id = 0-6 option name 'RatePortPolicer' combine\_enable = yes | no option port\_id '1' byte\_based = yes | no Yes means byte based. option combine\_enable 'no' option byte\_based 'yes' No means packet based. option couple\_flag 'no' couple\_flag = yes | no option color\_aware 'no' color\_aware = yes | no option deficit\_flag 'yes' deficit\_flag = yes | no option c\_bucket\_enable 'yes' c\_bucket\_enable = yes | no option cir '1000' • cir = 0-1048544 option cbs '10000' Committed Information Rate, kbps for byte based mode or PPS for packet mode. option c\_rate\_flag '0xfe' option c\_meter\_interval '1ms' cbs = 0-524288 option e bucket enable 'yes' Committed Burst Size, bytes for byte based mode or packets for packet mode. option eir '10000' option ebs '10000' c rate flag BIT[0] = MIRROR\_RATE\_EN, Ingress mirror frame rate option e\_rate\_flag '0xfe' limit enable for C bucket option e\_meter\_interval '1ms' BIT[1] = TCP\_CTRL\_RATE\_EN, Ingress TCP control frame rate limit enable for C bucket BIT[2] = MANAGE\_RATE\_EN, Ingress management frame rate limit enable for C bucket BIT[3] = BROAD\_RATE\_EN, Ingress broadcast frame rate limit enable for C bucket BIT[4] = UNK\_UNI\_RATE\_EN, Ingress unknown unicast frame rate limit enable for C bucket BIT[5] = UNK\_MULTI\_RATE\_EN, Ingress unknown frame multicast rate limit enable for C bucket BIT[6] = UNI\_RATE\_EN, Ingress unicast frame rate limit enable for C bucket BIT[7] = MULTI\_RATE\_EN, Ingress multicast frame rate limit enable for C bucket c\_meter\_interval = 100us/1ms/10ms/100ms e\_bucket\_enable = yes | no eir = 0-1048544 Excess Information Rate, kbps for byte based mode or PPS for packet mode. ebs = 0-524288 Excess Burst Size, bytes for byte based mode or packets for packet mode.

UCI Command	Description
	e_rate_flag
	<ul> <li>BIT[0] = MIRROR_RATE_EN, Ingress mirror frame rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[1] = TCP_CTRL_RATE_EN, Ingress TCP control frame rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[2] = MANAGE_RATE_EN, Ingress management frame rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[3] = BROAD_RATE_EN, Ingress broadcast frame rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[4] = UNK_UNI_RATE_EN, Ingress unknown unicast frame rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[5] = UNK_MULTI_RATE_EN, Ingress unknown frame multicast rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[6] = UNI_RATE_EN, Ingress unicast frame rate limit enable for E bucket</li> </ul>
	<ul> <li>BIT[7] = MULTI_RATE_EN, Ingress multicast frame rate limit enable for E bucket</li> </ul>
	<ul><li>e_meter_interval = 100us/1ms/10ms/100ms</li></ul>

### 2.14.2 portshaper

UCI Command	Description
config switch_ext option device 'switch0' option name 'RatePortShaper' option port_id '1' option status 'enable' option byte_based 'yes' option cir '1000' option cbs '10000' option eir '10000' option ebs '10000'	Set port egress shaper parameters on one particular port.  port_id = 0-6  status = enable   disable  byte_based = yes   no  Yes = byte based  No = packet based  cir = 0-1048544.  Committed Information Rate, kbps for byte based mode or PPS for packet mode.  cbs = 0-524288.  Committed Burst Size, bytes for byte based mode or packets for packet mode.  eir = 0-1048544  Excess Information Rate, kbps for byte based mode or PPS for packet mode.  ebs = 0-524288  Excess Burst Size, bytes for byte based mode or packets for packet mode.

# 2.14.3 queueshaper

UCI Command	Description
config switch_ext option device 'switch0' option name 'RateQueueShaper' option port_id '1' option queue_id '1' option status 'enable' option byte_based 'yes' option cir '1000' option cbs '10000' option eir '10000' option ebs '10000'	Set queue egress shaper parameters on one particular port.  port_id = 0-6 queue_id = 0-3 status = enable   disable byte_based = yes   no Yes = byte based No = packet based cir = 0-1048544 Committed Information Rate, kbps for byte based mode or PPS for packet mode.  cbs = 0-524288 Committed Burst Size, bytes for byte based mode or packets for packet mode.  eir = 0-1048544 Excess Information Rate, kbps for byte based mode or PPS for packet mode.  ebs = 0-524288 Excess Burst Size, bytes for byte based mode or PPS for packet mode.

# 2.14.4 aclpolicer

UCI Command	Description
config switch_ext option device 'switch0' option name 'RateAclPolicer' option policer_id '1' option counter_mode 'no' option byte_based 'yes' option couple_flag 'no' option color_aware 'no' option deficit_flag 'yes' option cir '1000' option cbs '10000' option eir '10000' option ebs '10000' option meter_interval '1ms'	Set ACL ingress policer parameters.  counter_mode = yes   no byte_based = yes   no Yes = byte based No = packet based couple_flag = yes   no color_aware = yes   no deficit_flag = yes   no cir = 0-1048544 Committed Information Rate, kbps for byte based mode or PPS for packet mode.  cbs = 0-524288 Committed Burst Size, bytes for byte based mode or packets for packet mode.  eir = 0-1048544 Excess Information Rate, kbps for byte based mode or PPS for packet mode.  eir = 0-524288 Excess Burst Size, bytes for byte based mode or PPS for packet mode.  ebs = 0-524288 Excess Burst Size, bytes for byte based mode or packets for packet mode.

### 2.14.5 ptAddRateByte

UCI Command	Description
config switch_ext option device 'switch0' option name 'RatePtAddRateByte' option port_id '1' option add_rate_bytes '24'	Set the byte number which can be added to frame when calculate rate limit.  port_id = 0-6  add_rate_bytes = 0-255

# 2.14.6 ptgolflowen

UCI Command	Description
config switch_ext option device 'switch0' option name 'RatePtGolflowen' option port_id '1' option golbal_flow_control_status 'enable'	Set status of port global flow control when global threshold is reached.  port_id = 0-6  golbal_flow_control_status = enable   disable

### 2.15 SEC commands

Config	Description
mac resv_vid	Configure security status of frame with reserved VID.
mac invalid_src_addr	Configure security status of frame with invalid source MAC address.
ip invalid_ver	Configure security status of frame with invalid IP version.
ip set same_addr	Configure security status of frame with same source and destination IP address.
ip ttl_change_status	Configure security status of frame TTL change.
ip ttl_val	Configure TTL value.
ip4 invalid_hl	Configure security status of frame with invalid IPv4 header.
ip4 hdr_opts	Configure security status of frame with IPv4 header option.
ip4 invalid_df	Configure security status of frame with DF=1 and offset or MF not zero.
ip4 frag_offset_min_len	Configure security status of frame with offset length less than MIN size.
ip4 frag_offset_min_size	Configure frame offset length MIN size.
ip4 frag_offset_max_len	Configure security status of frame with offset length more than max.
ip4 invalid_frag_offset	Configure security status of frame with invalid fragment offset.
ip4 invalid_sip	Configure security status of frame with invalid SIP.
ip4 invalid_dip	Configure security status of frame with invalid DIP.
ip4 invalid_chksum	Configure security status of frame with invalid checksum.
ip4 invalid_pl	Configure security status of frame with short length.
ip4 df_clear_status	Configure security status of clear IPv4 DF field.
ip4 ipid_random_status	Configure security status of sent frame (not fragment) with random ID.
ip6 invalid_dip	Configure security status of frame with invalid destination IPv6 address.
ip6 invalid_sip	Configure security status of frame with invalid source IPv6 address.
ip6 invalid_pl	Configure security status of IPv6 frame with short length.
tcp blat	Configure security status of TCP frame with same source port and destination port.

Config	Description
tcp invalid_hl	Configure security status of TCP frame with invalid header length.
tcp min_hdr_size	Configure TCP frame header length min size.
tcp invalid_syn	Configure security status of TCP frame with invalid SYN.
tcp su_block	Configure security status of TCP frame with SYN=1 & URG=1.
tcp sp_block	Configure security status of TCP frame with SYN=1 & PSH=1.
tcp sap_block	Configure security status of TCP frame with SYN=1 & ACK=1 & PSH=1.
tcp xmas_scan	Configure security status of TCP frame with FIN=1 & URG=1 & PSH=1.
tcp null_scan	Configure security status of TCP frame with all TCP FLAG zero.
tcp sr_block	Configure security status of TCP frame with SYN=1 & RST=1.
tcp sf_block	Configure security status of TCP frame with SYN=1 & FIN=1.
tcp sar_block	Configure security status of TCP frame with SYN=0 & ACK=0 & RST=0.
tcp rst_scan	Configure security status of TCP frame with RST=1.
tcp rst_with_data	Configure security status of TCP frame with RST=1 & IP payload LEN > TCP header length.
tcp fa_block	Configure security status of TCP frame with FIN=1 & ACK=0.
tcp pa_block	Configure security status of TCP frame with PUSH=1 & ACK=0.
tcp ua_block	Configure security status of TCP frame with URG=1 & ACK=0.
tcp invalid_chksum	Configure security status of TCP frame with invalid checksum.
tcp invalid_urgptr	Configure security status of TCP frame with URG=0 but pointer not zero.
tcp invalid_opts	Configure security status of TCP frame with SYN=0 and IP header larger than 20.
udp blat	Configure security status of UDP frame with SP equal to DP.
udp invalid_len	Configure security status of UDP frame with invalid length.
udp invalid_chksum	Configure security status of UDP frame with invalid checksum.
icmp4 ping_pl_exceed	Configure security status of ICMP4 frame with IP payload length larger than max.
icmp4 ping_frag	Configure security status of ICMP4 frame with fragment.
icmp4 ping_max_pl	Configure ICMP4 frame IP payload length MAX.
icmp6 ping_pl_exceed	Configure security status of ICMP6 frame with IP payload length larger than MAX.
icmp6 ping_fr	Configure security status of ICMP6 frame with fragment.
icmp6 ping_max_pl	Configure ICMP6 frame IP payload length MAX. It is available when set command "sec icmp4 set ping_pl_exceed 1"

### 2.15.1 mac resv\_vid

UCI Command	Description
config switch_ext	Set security status of frame with reserved VID.
option device 'switch0'	■ value = 0-1
option name 'SecMac'	<ul> <li>1 = frame with VID 4095 is dropped by switch.</li> </ul>
option item 'resv_vid'	<ul> <li>0 = frame with VID 4095 is forwarded by switch.</li> </ul>
option value '0'	

# 2.15.2 mac invalid\_src\_addr

UCI Command	Description
config switch_ext	Set security status of frame with invalid source MAC address.
option device 'switch0'	■ value = 0-1
option name 'SecMac'	<ul> <li>1 = frame with SA is multicast or broadcast is dropped.</li> </ul>
option item 'invalid_src_addr' option value '1'	<ul> <li>0 = frame with SA is multicast or broadcast is forwarded by switch.</li> </ul>

### 2.15.3 ip invalid\_ver

UCI Command	Description
config switch_ext	Set security status of frame with invalid IP version.
option device 'switch0'	<ul><li>value = 0-1</li></ul>
option name 'Seclp'	1 = frame isn't IPv4 or IPv6 is dropped.
option item 'invalid_ver'	0 = frame isn't IPv4 or IPv6 is forwarded by switch.
option value '1'	

# 2.15.4 ip set same\_addr

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of frame with same source and destination IP address.
option name 'Seclp'	• value = 0-1
option item 'same_addr'	<ul> <li>1 = frame with SIP equal to DIP is dropped.</li> </ul>
option value '1'	<ul> <li>0 = frame with SIP equal to DIP is forwarded by switch.</li> </ul>

### 2.15.5 ip ttl\_change\_status

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of frame TTL change.  • value = 0-1
option name 'SecIp' option item 'ttl_change_status' option value '1'	<ul><li>1 = enable frame TTL change to IP_TTL</li><li>0 = disable frame TTL change to IP_TTL</li></ul>

### 2.15.6 ip ttl\_val

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIp' option item 'ttl_val' option value '1'	Set TTL value. If security status of frame TTL change is set to 1, TTL will be changed to this value.  • value = TTL value, 8 bits

### 2.15.7 ip4 invalid\_hl

UCI Command	Description
config switch_ext	Set security status of frame with invalid IPv4 header.
option device 'switch0'	■ value = 0-1
option name 'SecIp4'	<ul> <li>1 = frame with IPv4 header length less than 20 byte is dropped</li> </ul>
option item 'invalid_hl' option value '1'	<ul> <li>0 = frame with IPv4 header length less than 20 byte is forwarded by switch.</li> </ul>

### 2.15.8 ip4 hdr\_opts

UCI Command	Description
config switch_ext	Set security status of frame with IPv4 header option.
option device 'switch0'	■ value = 0-1
option name 'Seclp4'	<ul> <li>1 = frame with IPv4 header option is dropped.</li> </ul>
option item 'hdr_opts'	<ul> <li>0 = frame with IPv4 header option is sent to CPU port.</li> </ul>
option value '1'	

# 2.15.9 ip4 invalid\_df

UCI Command	Description
config switch_ext	Set security status of frame with DF=1 and offset or MF not zero.
option device 'switch0'	■ value = 0-1
option name 'SecIp4'	1 = frame with DF=1 and offset or MF not zero is dropped.
option item 'invalid_df'	<ul> <li>0 = frame with DF=1 and offset or MF not zero is forwarded by</li> </ul>
option value '1'	switch.

## 2.15.10 ip4 frag\_offset\_min\_len

UCI Command	Description
config switch_ext option device 'switch0' option name 'Seclp4' option item 'frag_offset_min_len' option value '1'	Set security status of frame with offset length less than MIN size.  • value = 0-1  • 1 = frame with offset length less than min is dropped  • 0 = frame with offset length less than min is forwarded by switch.

### 2.15.11 ip4 frag\_offset\_min\_size

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIp4' option item 'frag_offset_min_size' option value '1'	Set frame offset length MIN size.  • value = offset length min, 8 bits

# 2.15.12 ip4 frag\_offset\_max\_len

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIp4' option item 'frag_offset_max_len'	Set security status of frame with offset length more than max.  value = 0-1  1 = frame with offset length more than max (Offset (13bits) ×8+ IP TOTAL LEN (16bits) >= 64KB) is dropped.  0 = frame with offset length more than max is forwarded by switch.

### 2.15.13 ip4 invalid\_frag\_offset

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of frame with invalid fragment offset.  • value = 0-1
option name 'SecIp4' option item 'invalid_frag_offset' option value '1'	<ul> <li>1 = frame with ipv4 fragment (not the last fragment, mf =1) and length check error ((IP len (LENGTH FIELD) - Header Len) % 8 ! = 0) is dropped.</li> <li>0 = forwarded by switch.</li> </ul>

# 2.15.14 ip4 invalid\_sip

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of frame with invalid SIP.  • value = 0-1
option name 'Seclp4' option item 'invalid_sip' option value '1'	<ul> <li>1 = frame with SIP[31:24] more than 0xE0 and less than 0xF0, or equal to 0x7F, or SIP[31:0] is 32'hFFFFFFFF, is dropped.</li> </ul>
Sp. 13.135 1	<ul> <li>0 = frame with SIP[31:24] more than 0xE0 and less than 0xF0, or equal to 0x7F, or SIP[31:0] is 32'hFFFFFFFF, is forwarded by switch.</li> </ul>

# 2.15.15 ip4 invalid\_dip

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of frame with invalid DIP.  • value = 0-1
option name 'Seclp4' option item 'invalid_dip'	<ul> <li>1 = frame is dropped if with DIP all zero or DIP[31:24] is 0x7F.</li> </ul>
option value '1'	<ul> <li>0 = frame with DIP all zero or DIP[31:24] is 0x7F is forwarded by switch.</li> </ul>

### 2.15.16 ip4 invalid\_chksum

UCI Command	Description
config switch_ext	Set security status of frame with invalid checksum.
option device 'switch0'	■ value = 0-1
option name 'Seclp4'	<ul> <li>1 = frame with IPv4 checksum error is dropped.</li> </ul>
option item 'invalid_chksum'	<ul> <li>0 = frame with IPv4 checksum error is forwarded by</li> </ul>
option value '1'	switch.

# 2.15.17 ip4 invalid\_pl

UCI Command	Description
config switch_ext option device 'switch0' option name 'Seclp4' option item 'invalid_pl' option value '1'	Set security status of frame with short length.  value = 0-1  1 = frame with short length (20(Min IPv6 Header Length) + 18 + VLAN + SNAP + PPPOE > FRAME LENGTH) is dropped.  0 = frame with short length is forwarded by switch

# 2.15.18 ip4 df\_clear\_status

UCI Command	Description
config switch_ext	Set security status of clear IPv4 DF field.
option device 'switch0'	• value = 0-1
option name 'SecIp4'	1 = enable IPv4 DF field cleared to zero
option item 'df_clear_status'	<ul> <li>0 = disable IPv4 DF field cleared to zero</li> </ul>
option value '1'	, "

### 2.15.19 ip4 ipid\_random\_status

UCI Command	Description
config switch_ext option device 'switch0' option name 'Seclp4'	Set security status of sent frame (not fragment) with random ID.  • value = 0-1
option item 'ipid_random_status' option value '1'	<ul> <li>1 = enable sent frame (not fragment) with random ID.</li> <li>0 = disable sent frame (not fragment) with random ID.</li> </ul>

### 2.15.20 ip6 invalid\_dip

UCI Command	Description
config switch_ext option device 'switch0' option name 'Seclp6' option item 'nvalid_dip' option value '1'	Set security status of frame with invalid destination IPv6 address.  value = 0-1  1 = IPv6 with DIP is 1 or zero is dropped.  0 = IPv6 with DIP is 1 or zero is forwarded by switch.

# 2.15.21 ip6 invalid\_sip

UCI Command	Description
config switch_ext	Set security status of frame with invalid source IPv6 address.
option device 'switch0'	■ value = 0-1
option name 'Seclp6'	1 = IPv6 with SIP is 1 or ff00::/8 is dropped.
option item 'invalid_sip' option value '1'	□ 0 = IPv6 with SIP is 1 or ff00::/8 is forwarded by switch.

### 2.15.22 ip6 invalid\_pl

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of IPv6 frame with short length.  • value = 0-1
option name 'Seclp6' option item 'invalid_pl' option value '1'	<ul> <li>1 = frame with short length (40(Min IPv6 Header Length) + 18 + VLAN + SNAP + PPPOE &gt; FRAME LENGTH) is dropped.</li> <li>0 = frame with short length is forwarded by switch</li> </ul>

### 2.15.23 tcp blat

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'blat' option value '1'	Set security status of TCP frame with same source port and destination port.  value = 0-1  1 = TCP frame with SP equal to DP is dropped.  0 = TCP frame with SP equal to DP is forwarded by switch.

### 2.15.24 tcp invalid\_hl

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'invalid_hl'	Set security status of TCP frame with invalid header length.  value = 0-1  1 = if frame with TCP header length less than min size but not first of fragment, is dropped
option value '1'	<ul> <li>0 = frame with TCP header length less than min size but not first of fragment, is forwarded by switch.</li> </ul>

### 2.15.25 tcp min\_hdr\_size

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'min_hdr_size' option value '1'	Set TCP frame header length min size.  • value = TCP header length, 4 bits.

### 2.15.26 tcp invalid\_syn

UCI Command	Description
config switch_ext	Set security status of TCP frame with invalid SYN.
option device 'switch0'	■ value = 0-1
option name 'SecTcp'	1 = frame with SYN=1 & ACK=0 & SP<1024 is dropped.
option item 'invalid_syn'	0 = frame with SYN=1 & ACK=0 & SP<1024 is forwarded
option value '1'	by switch.

# 2.15.27 tcp su\_block

UCI Command	Description
config switch_ext	Set security status of TCP frame with SYN=1 & URG=1.
option device 'switch0'	■ value = 0-1
option name 'SecTcp'	1 = frame with SYN=1 & URG=1 is dropped.
option item 'su_block'	<ul> <li>0 = frame with SYN=1 &amp; URG=1 is forwarded by switch.</li> </ul>
option value '1'	170

# 2.15.28 tcp sp\_block

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'sp_block' option value '1'	Set security status of TCP frame with SYN=1 & PSH=1.  value = 0-1  1 = frame with SYN=1 & PSH=1 is dropped.  0 = frame with SYN=1 & PSH=1 is forwarded by switch.

## 2.15.29 tcp sap\_block

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'sap_block' option value '1'	Set security status of TCP frame with SYN=1 & ACK=1 & PSH=1.  value = 0-1  1 = frame with SYN=1 & ACK=1 & PSH=1 is dropped.  0 = frame with SYN=1 & ACK=1 & PSH=1 is forwarded by switch.

### 2.15.30 tcp xmas\_scan

UCI Command	Description
config switch_ext	Set security status of TCP frame with FIN=1 & URG=1 & PSH=1.
option device 'switch0' option name 'SecTcp' option item 'xmas_scan' option value '1'	<ul> <li>value = 0-1</li> <li>1 = frame with FIN=1 &amp; URG=1 &amp; PSH=1 is dropped</li> <li>0 = frame with FIN=1 &amp; URG=1 &amp; PSH=1 is forwarded by switch.</li> </ul>

### 2.15.31 tcp null\_scan

UCI Command	Description
config switch_ext	Set security status of TCP frame with all TCP FLAG zero.
option device 'switch0'	■ value = 0-1
option name 'SecTcp'	1 = frame with all TCP FLAG zero is dropped.
option item 'null_scan'	<ul> <li>0 = frame with all TCP FLAG zero is forwarded by switch.</li> </ul>
option value '1'	

# 2.15.32 tcp sr\_block

UCI Command	Description
config switch_ext	Set security status of TCP frame with SYN=1 & RST=1.
option device 'switch0'	• value = 0-1
option name 'SecTcp'	□ 1 = frame with SYN=1 & RST=1 is dropped.
option item 'sr_block'	<ul> <li>0 = frame with SYN=1 &amp; RST=1 is forwarded by switch.</li> </ul>
option value '1'	V .

# 2.15.33 tcp sf\_block

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'sf_block' option value '1'	Set security status of TCP frame with SYN=1 & FIN=1.  value = 0-1  1 = frame with SYN=1 & FIN=1 is dropped.  0 = frame with SYN=1 & FIN=1 is forwarded by switch.

### 2.15.34 tcp sar\_block

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of TCP frame with SYN=0 & ACK=0 & RST=0.  value = 0-1
option admic distribution option name 'SecTcp' option item 'sar_block' option value '1'	<ul> <li>1 = frame with SYN=0 &amp; ACK=0 &amp; RST=0 is dropped.</li> <li>0 = frame with SYN=0 &amp; ACK=0 &amp; RST=0 is forwarded by switch.</li> </ul>

### 2.15.35 tcp rst\_scan

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of TCP frame with RST=1.  value = 0-1
option name 'SecTcp'	□ 1 = frame with RST=1 is dropped.
option item 'rst_scan' option value '1'	<ul> <li>0 = frame with RST=1 is forwarded by switch.</li> </ul>

### 2.15.36 tcp rst\_with\_data

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'rst_with_data' option value '1'	Set security status of TCP frame with RST=1 & IP payload len > TCP header length.  value = 0-1  1 = TCP frame with RST=1 & IP payload len > TCP header length is dropped.  0 = TCP frame with RST=1 & IP payload len > TCP header length is forwarded by switch.

# 2.15.37 tcp fa\_block

UCI Command	Description
config switch_ext	Set security status of TCP frame with FIN=1 & ACK=0.
option device 'switch0'	value = 0-1
option name 'SecTcp'	1 = frame with FIN=1 & ACK=0 is dropped.
option item 'fa_block'	<ul> <li>0 = frame with FIN=1 &amp; ACK=0 is forwarded by switch.</li> </ul>
option value '1'	

### 2.15.38 tcp pa\_block

UCI Command	Description
config switch_ext	Set security status of TCP frame with PUSH=1 & ACK=0.
option device 'switch0' option name 'SecTcp'	<ul><li>value = 0-1</li><li>1 = frame with PUSH=1 &amp; ACK=0 is dropped.</li></ul>
option item 'pa_block' option value '1'	<ul> <li>0 = frame with PUSH=1 &amp; ACK=0 is forwarded by switch.</li> </ul>

# 2.15.39 tcp ua\_block

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'ua_block' option value '1'	Set security status of TCP frame with URG=1 & ACK=0.  value = 0-1  1 = frame with URG=1 & ACK=0 is dropped.  1 = forwarded by switch

### 2.15.40 tcp invalid\_chksum

UCI Command	Description
config switch_ext	Set security status of TCP frame with invalid checksum.
option device 'switch0'	■ value = 0-1
option name 'SecTcp'	<ul> <li>1 = frame with TCP checksum error is dropped.</li> </ul>
option item 'invalid_chksum' option value '1'	<ul> <li>0 = frame with TCP checksum error is forwarded by switch.</li> </ul>

# 2.15.41 tcp invalid\_urgptr

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'invalid_urgptr' option value '1'	Set security status of TCP frame with URG=0 but pointer not zero.  value = 0-1  1 = frame with URG=0 but pointer not zero is dropped.  0 = frame with URG=0 but pointer not zero is forwarded by switch.

### 2.15.42 tcp invalid\_opts

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecTcp' option item 'invalid_opts' option value '1'	Set security status of TCP frame with SYN=0 and IP header larger than 20.  value = 0-1
	<ul> <li>1 = frame with SYN=0 and IP header larger than 20 byte is dropped.</li> </ul>
	<ul> <li>0 = frame with SYN=0 and IP header larger than 20 byte is forwarded by switch.</li> </ul>

### 2.15.43 udp blat

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of UDP frame with SP equal to DP.  value = 0-1
option name 'SecUdp' option item 'blat' option value '1'	<ul> <li>1 = UDP frame with SP equal to DP is dropped.</li> <li>0 = UDP frame with SP equal to DP is forwarded by switch.</li> </ul>

# 2.15.44 udp invalid\_len

UCI Command	Description
config switch_ext option device 'switch0'	Set security status of UDP frame with invalid length.  • value = 0-1
option name 'SecUdp' option item 'invalid_len'	<ul> <li>1 = frame with UDP length check error (UDP LEN + IP HDR != IP LEN) is dropped.</li> </ul>
option value '1'	<ul> <li>0 = frame with UDP length check error (UDP LEN + IP HDR != IP LEN) is forwarded by switch.</li> </ul>

### 2.15.45 udp invalid\_chksum

UCI Command	Description
config switch_ext	Set security status of UDP frame with invalid checksum.
option device 'switch0'	■ value = 0-1
option name 'SecUdp'	<ul> <li>1 = frame with UDP checksum error is dropped.</li> </ul>
option item 'invalid_chksum'	<ul> <li>0 = frame with UDP checksum error is forwarded by</li> </ul>
option value '1'	switch.

# 2.15.46 icmp4 ping\_pl\_exceed

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIcmp4' option item 'ping_pl_exceed' option value '1'	Set security status of ICMP4 frame with IP payload length larger than max.  value = 0-1  1 = Ping frame with IP payload length larger than max is dropped.  0 = Ping frame with IP payload length larger than max is forwarded by switch.

### 2.15.47 icmp4 ping\_frag

UCI Command	Description
config switch_ext	Set security status of ICMP4 frame with fragment.
option device 'switch0'	■ value = 0-1
option name 'SecIcmp4'	<ul> <li>1 = ICMPv4 frame with fragment is dropped.</li> </ul>
option item 'ping_frag'	<ul> <li>0 = ICMPv4 frame with fragment is forwarded by switch.</li> </ul>
option value '1'	

# 2.15.48 icmp4 ping\_max\_pl

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIcmp4' option item 'ping_max_pl' option value '1'	Set ICMP4 frame IP payload length MAX. It is available when set command "sec icmp4 set ping_pl_exceed 1".  • value = IP payload length, 14 bits

### 2.15.49 icmp6 ping\_pl\_exceed

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIcmp6' option item 'ping_pl_exceed' option value '1'	Set security status of ICMP6 frame with IP payload length larger than MAX.  value = 0-1  1 = ICMPV6 ping frame with IP payload length larger than MAX is dropped.  0 = ICMPV6 ping frame with IP payload length larger than MAX is forwarded by switch.

# 2.15.50 icmp6 ping\_fr

UCI Command	Description
config switch_ext	Set security status of ICMP6 frame with fragment.
option device 'switch0'	■ value = 0-1
option name 'Seclcmp6'	<ul> <li>1 = ICMPv6 frame with fragment is dropped.</li> </ul>
option item 'ping_frag'	<ul> <li>0 = ICMPv6 frame with fragment is forwarded by switch.</li> </ul>
option value '1'	

## 2.15.51 icmp6 ping\_max\_pl

UCI Command	Description
config switch_ext option device 'switch0' option name 'SecIcmp6' option item 'ping_max_pl' option value '1'	Set ICMP6 frame IP payload length MAX. It is available when set command "sec icmp4 set ping_pl_exceed 1".  • value = IP payload length, 14 bits

## 2.16 STP commands

Config	Description	
portState	Configure STP state on a particular port.	

# 2.16.1 portState

UCI Command	Description
config switch_ext option device 'switch0' option name 'StpPortState' option stp_id '0' option port_id '2' option stp_status 'forward'	Configure STP state on a particular port.  stp_id = 0  port_id = 0-6  stp_status = <disable block listen learn forward></disable block listen learn forward>

# 2.17 TRUNK commands

Config	Description	
group	Configure trunk group port member information.	
hashmode	Configure trunk hash mode.	

### 2.17.1 Group

UCI Command	Description
config switch_ext	Configure trunk group port member information.
option device 'switch0'	trunk_id = 0-3
option name 'TrunkGroup'	status = <enable disable></enable disable>
option trunk_id '1'	<ul><li>trunk_port_bitmap</li></ul>
option status 'enable'	<ul><li>BIT[0] = port 0</li></ul>
option trunk_port_bitmap '0x6'	<ul><li>BIT[1] = port 1</li></ul>
16, 21,	<ul><li>BIT[2] = port 2</li></ul>
20, 3111	<ul><li>BIT[3] = port 3</li></ul>
dille	<ul><li>BIT[4] = port 4</li></ul>
	<ul><li>BIT[5] = port 5</li></ul>
	<ul><li>BIT[6] = port 6</li></ul>

### 2.17.2 Hashmode

UCI Command	Description	
config switch_ext option device 'switch0'	Configure trunk hash mode.  • trunk hash mode	
option name 'TrunkHashmode' option trunk_hash_mode '0xf'	#define FAL_TRUNK_HASH_KEY_DA	0x1
option trunk_nash_mode oxi	<ul><li>#define FAL_TRUNK_HASH_KEY_SA</li><li>#define FAL_TRUNK_HASH_KEY_DIP</li></ul>	0x2 0x4
	#define FAL_TRUNK_HASH_KEY_SIP	0x8

### 2.18 VLAN commands

	Config	Description
entry Configure VLAN entry on a particular device.		

Config	Description
member	Configure port member on a particular VLAN entry.
learnsts	Configure FDB learning status of a particular VLAN entry.

# 2.18.1 Entry

UCI Command	Description
config switch_ext option device 'switch0' option name 'VlanEntry' option vlan_id '100'	Create a VLAN entry by VLAN ID. After this operation the member ports of the created VLAN entry are null.  • vlan_id = 0-4095

### 2.18.2 **Member**

UCI Command	Description
config switch_ext	Add a port member to a particular VLAN entry.
option device 'switch0'	■ vlan_id = 0-4095
option name 'VlanMember'	port_id = 0-6
option vlan_id '100'	<ul><li>tag_mode</li></ul>
option port_id '1'	unmodified = egress transmit packets unmodified
option tag_mode 'untagged'	<ul> <li>untagged = egress transmit packets without VLAN tag</li> </ul>
	tagged = egress transmit packets with VLAN tag

### **2.18.3 learnsts**

UCI Command	Description
config switch_ext option device 'switch0' option name 'VlanLearnSts' option vlan_id '100' option learn_status 'enable'	Set FDB learning status of a particular VLAN entry.  vlan_id = 0-4095  learn_status  enable = indicates normal operation about learn and final DP  disable = indicates no learn and not use ARL table DP calculate final DP, but use UNI flood DP as ARL DP to calculate DP