

19:19 Sat, 19 Jul

35



Fully Factory Kiosk Solutions

Fully Kiosk Browser & Lockdown



4.2★

899 reviews ⓘ

500K+

Downloads



PEGI 3 ⓘ

Update

Deactivate

In-app purchases

What's new •

Last updated 16 Jul 2025

Bugfixes

New KNOX Options

New JS APIs

...

Available on more devices

✓ Tablet • 4.3★

Phone • 4.1★

TV • 2.7★

Chromebook • 3.8★

Rate this app

Tell others what you think

Sponsored • Suggested for you



Fieldwire - Construction App

Fieldwire • Business • Workforce management

4.2★ ± 1M+



Gaia GPS: Offline Trail Maps

Outside, Inc. • Maps & Navigation • Travel & local • Hiking

4.1★ ± 1M+



MaintainX Work Order CMMS

MaintainX Inc. • Productivity • Business

4.7★ ± 1M+



Xero Accounting & Invoices

Xero Accounting • Business • Accounting

4.6★ ± 1M+

More by Fully Factory Kiosk Solutions



Fully Single App Kiosk

Fully Factory Kiosk Solutions • Business

4.3★ ± 50K+



Fully Exam Kiosk

Fully Factory Kiosk Solutions

Lazy TECH Geek



Don't install these variants



Fully Single App Kiosk

Fully Factory Kiosk Solutions • Business

4.3★ ⬇ 50K+



Fully Exam Kiosk

Fully Factory Kiosk Solutions • Education

3.8★ ⬇ 100K+



Fully Kiosk Provisioner

Fully Factory Kiosk Solutions • Business

⬇ 500+



Fully Kiosk for Work

Fully Factory Kiosk Solutions • Communication

⬇ 1K+

Lazy**TECH**Geek

Search in Settings

- ⚠ Motion detection can fail with Android 14+ when other apps in foreground or screen is off. [Check FAQ!](#)
- ⚠ Consider enabling the **Keep Screen On** option when using **Screen Off** or **Screensaver Timer** otherwise Android screen off will be messing things up
- ⚠ Consider enabling the **Prevent from Sleep while Screen Off** option if the screen may turn off when using Remote Admin, Cloud service or Motion detection

Web Content Settings

Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.

Web Browsing Settings

Pull-to-refresh, navigation options, click sound, back button, swipe tab, NFC tags etc.

Web Zoom and Scaling

Enable zooming, initial page/text scaling, overview mode, wide viewport, desktop mode

Web Auto Reload

Reload Start URL or current page on idle, page error, screen on, network/internet reconnect, purge cookies etc.

Advanced Web Settings

Web automation, JavaScript

Universal Launcher

Start other apps and

Toolbars and Appearance

Fullscreen mode, customize action bar, address bar, progress bar, tabs, select colors for the web browser and launcher

Screensaver (PLUS)

Warning about motion detect failing
if using installing app via Google Play

22:56 Sat, 19 Jul

www.fully-kiosk.com

Fully Kiosk Help

[ABOUT](#)

[CONFIGURATION](#)

[PRICING](#)

[FAQS](#)

[MORE ▾](#)

[CONTACT](#)

— Why the motion detection doesn't work reliably in Android 14+?

Starting Android 14 Google/Android enforces a privacy concept for restricting apps from using the camera and microphone when the app is not in use. Our kiosk apps will comply with this enforcement in Google Play editions. Good news: The restrictions only apply to Android 14+ and only if you install our apps from Google Play. If you install the latest [APK files](#) from our website the restrictions will be **not active** and the motion detection should work stable even if another app is in foreground or the screen is off.

Also check that the camera isn't used by other apps or websites. Disable Face Unlock feature in your Android settings.

+ How can I save bookmarks/favorites in Fully Kiosk ?

+ Can I wake up the screen by tapping it?

Warning about motion detect failing
if using installing app via Google Play continued...



Fully Kiosk Help

[ABOUT](#)[CONFIGURATION](#)[PRICING](#)[FAQS](#)[MORE ▾](#)[CONTACT](#)

Fully Video Kiosk is our app for playing video, image and websites shows on Android devices with full kiosk protection. Also available on [Google Play](#) and as [APK file](#).

Fully Exam Kiosk is our app for device lockdown to the exam website during online examination. Fully Exam Kiosk browser supports all learning management systems (LMS) that

With **Fully Cloud EMM** you can organize, monitor and remote configure your Kiosk devices from everywhere. You can also make fast [Device Provisioning](#) and manage apps with [Enterprises](#).

WHERE TO USE THE KIOSK MODE

The intent of most people setting up kiosk mode is to prevent the user from running anything other than the browser based content in the full screen browser window or running the device as a dedicated kiosk. Fully Kiosk locks a device to intended use while preventing personal use by employees or customers. You can use the Kiosk mode on smartphones, tablets and other Android devices.

Some good examples of using devices in Android Kiosk mode:

- Touchscreen corporate devices for ordering menu items at a restaurant
- Entertainment, service and advertising panel in the taxi, bus, train or other public

Download APK Files

⚠ BREAKING CHANGES ⚠
READ FAQ BEFORE UPGRADE!

	Fully Kiosk Browser APK ver. 1.57.1 (regular edition)
	Fully Kiosk Browser APK ver. 1.58.3 (regular edition)
	Fully Kiosk Browser APK ver. 1.57.1 (EMM edition)
	Fully Kiosk Browser APK ver. 1.58.3 (EMM edition)
	Fully Single App Kiosk APK ver. 1.17.1
	Fully Single App Kiosk APK ver. 1.18.3
	Fully Video Kiosk APK ver. 1.17.1
	Fully Video Kiosk APK ver. 1.18.3

Installing APK file

22:57 Sat, 19 Jul

www.fully-kiosk.com

Fully Kiosk Browser ...

Fully Kiosk Help

[ABOUT](#)

[CONFIGURATION](#)

[PRICING](#)

[FAQS](#)

[MORE ▾](#)

[CONTACT](#)

limited examination. Fully Exam Kiosk browser supports all learning management systems (LMS) that support [Safe Exam Browser \(SEB\)](#) including Moodle.

With [Fully Kiosk and EMM](#) you can organize, monitor and remote configure your Fully Kiosk devices anywhere. You can also make fast [Device Provisioning](#) and manage apps with [Enterprise](#).

WHERE TO USE THE KIOSK MODE

The intent of most people setting kiosk mode is to prevent the user from running anything other than the browser based apps. Fully Kiosk app runs the selected apps. Fully Kiosk app or apps in the kiosk mode. Users will also have access to device settings. On many devices the administrator keys like the volume, power and home button are disabled in kiosk mode. Fully Kiosk locks a device to intended employees or customers. You can use the kiosk mode on other Android devices.

Some good examples of using devices in kiosk mode are:

- Touchscreen corporate devices for information display
- Entertainment, service and advertising panel in the taxi, bus, train or other public transport

Download file?

This type of file may harm your tablet. Only download this file if you trust its source.

Fully-Kiosk-Browser-v1.57.1.apk

Source : fully-kiosk.com

Cancel

Download

F

Fully Kiosk Browser APK
ver. 1.57.1 (regular edition)

F

Fully Kiosk Browser APK
ver. 1.58.3 (regular edition)

F

Fully Kiosk Browser APK
ver. 1.57.1 (EMM edition)

F

Fully Kiosk Browser APK
ver. 1.58.3 (EMM edition)

F

Fully Single App Kiosk APK
ver. 1.17.1

F

Fully Single App Kiosk APK
ver. 1.18.3

F

Fully Video Kiosk APK
ver. 1.17.1

F

Fully Video Kiosk APK
ver. 1.18.3

Lazy **TECH** Geek

Fully Kiosk Help

[ABOUT](#)[CONFIGURATION](#)[PRICING](#)[FAQS](#)[MORE ▾](#)[CONTACT](#)

line examination. Fully Exam Kiosk browser supports all learning management systems (LMS) that support [Safe Exam Browser \(SEB\)](#) including Moodle.

With [Fully Cloud EMM](#) you can organize, monitor and remote configure your Fully Kiosk devices from everywhere. You can also make fast [Device Provisioning](#) and manage apps with [Enterprises](#).

WHERE TO USE THE KIOSK MODE

The intent of most people setting up kiosk mode is to prevent the user from running anything other than the browser based content in the full screen browser window or running the selected apps. Fully Kiosk app will help you to run selected websites or apps in the kiosk mode. Users will also be restricted from making changes to any device settings. On many devices the admin can even restrict hardware keys like the volume, power and home buttons on the Android device in kiosk mode. Fully Kiosk locks a device to intended use while preventing personal use by employees or customers. You can also use Fully Kiosk on other Android devices.

Some good examples of using devices in Android Kiosk mode:

- Touchscreen corporate devices for ordering menu items at a restaurant
- Entertainment, service and advertising panel in the taxi, bus, train or other pub-

PLEASE READ BEFORE UPGRADING!

f	Fully Kiosk Browser APK ver. 1.57.1 (regular edition)
f	Fully Kiosk Browser APK ver. 1.58.3 (regular edition)
f	Fully Kiosk Browser APK ver. 1.57.1 (EMM edition)
f	Fully Kiosk Browser APK ver. 1.58.3 (EMM edition)
f	Fully Single App Kiosk APK ver. 1.17.1
f	Fully Single App Kiosk APK ver. 1.18.3
f	Fully Video Kiosk APK ver. 1.17.1
f	Fully Video Kiosk APK ver. 1.18.3

Fully-Kiosk-Browser-v1.57.1-1.apk downloaded.

[Open file](#)

The intent of most people setting up kiosk mode is to run anything other than the browser based operating system, running the selected apps. Fully Kiosk mode locks a device to only run the selected apps or apps in the kiosk mode. Users will also be able to access device settings. On many devices the app will lock the device keys like the volume, power and home button. Fully Kiosk mode. Fully Kiosk locks a device to internet only. Fully Kiosk mode employees or customers. You can use the kiosk mode on smartphones, tablets and

This app normally receives updates from **Google Play Store**. By updating from a different source you may receive future updates from any source on your tablet. App functionality may change.

Cancel | **Update anyway**

Update anyway

Fully Kiosk Help

[ABOUT](#)[CONFIGURATION](#)[PRICING](#)[FAQS](#)[MORE ▾](#)[CONTACT](#)

box.

Fully Video Kiosk is our app for playing video, image and websites shows on Android devices with full kiosk protection. Also available on [Google Play](#) and as [APK file](#).

Fully Exam Kiosk is our app for device lockdown to the exam website during the on-line examination. Fully Exam Kiosk browser supports all learning management systems (LMS) that support [Safe Exam Browser \(SEB\)](#) including [Moodle](#).

With **Fully Cloud EMM** you can organize, monitor and remote configure your Fully Kiosk devices from everywhere. You can also make fast [Device Provisioning](#) and manage apps with [Enterprises](#).

WHERE TO USE THE KIOSK MODE

The intent of most people setting up kiosk mode is to prevent the user from running anything other than the browser based or running the selected apps. Fully Kiosk a or apps in the kiosk mode. Users will also device settings. On many devices the ac keys like the volume, power and home b mode. Fully Kiosk locks a device to inter employees or customers. You can use the kiosk mode on smartphones, tablets and

Download APK Files

⚠ BREAKING CHANGES ⚠
READ FAQ BEFORE UPGRADE!

-  Fully Kiosk Browser APK ver. 1.57.1 (regular edition)
-  Fully Kiosk Browser APK ver. 1.58.3 (regular edition)
-  Fully Kiosk Browser APK ver. 1.57.1 (EMM edition)
-  Fully Kiosk Browser APK ver. 1.58.3 (EMM edition)
-  Fully Single App Kiosk APK ver. 1.17.1
-  Fully Single App Kiosk APK ver. 1.18.3
-  Fully Video Kiosk APK

 **Fully Kiosk Browser**

Installing...

Cancel

Fully updated to version 1.57.1

What's new in Version 1.57?

- Local Files Alert and Migration

What's new in Version 1.56?

- Better Android 15 Support
- New Features for Provisioned Devices
- Remote Admin Rebrush
- Load URL by Web Automation
- Use App-Specific Storage

Permissions required

Fully requires some additional permissions in order to make its job properly:

- Read Device Storage
- Write Device Storage
- Install Apps from APK Files

Please press OK and grant permissions in subsequent dialogs.

CANCEL

OK

- New Tab URL

- Android 14 Support
- Some Bugfixes

What's new in Version 1.53?

- Remove X-Frame and CORS protection
- Clear App Data from App Management
- Introduce \$customVariable
- Custom Look for App

SHOW LATER GOT IT (54)

Loading ...

Lazy **TECH** Geek

< Install unknown apps

 Fully Kiosk Browser
Version 1.57.1

Allow permission



Installing apps from this source may put your tablet and data at risk.

To keep your tablet and data safe, turn on Auto Blocker to prevent the installation of unknown apps in Settings > Security and privacy > Auto Blocker.



Allow **Fully Kiosk Browser** to access **photos, videos, music and audio** on this device?

Allow

Don't allow



< Install unknown apps

 Fully Kiosk Browser
Version 1.57.1

Allow permission



Installing apps from this source may put your tablet and data at risk.

To keep your tablet and data safe, turn on Auto Blocker to prevent the installation of unknown apps in Settings > Security and privacy > Auto Blocker.





Lounge

Upcoming Buses

(Rainbow Field)

Horsham (23)

No more buses today

Horsham (200)

23:41 (43 minutes)

Crawley (23)

No more buses today

Gatwick (10)

23:01 (3 minutes)

Gatwick (10)

23:38 (40 minutes)

Fully updated to version 1.57.1

What's new in Version 1.57?

- Local Files Alert and Migration

What's new in Version 1.56?

- Better Android 15 Support
- New Features for Provisioned Devices
- Remote Admin Rebrush
- Load URL by Web Automation
- Use App-Specific Storage
- Clear Apps (provisioned devices only)
- Some Bugfixes

What's new in Version 1.55?

- Show popups in dialog boxes
- Improve IP address display
- Confidence threshold for face detection
- New JS APIs
- Turn roaming data on/off by KNOX
- Some Bugfixes

What's new in Version 1.54?

- Use CameraX for Motion Detection
- Enable/disable Hotspot
- Web Console
- New Tab URL
- Android 14 Support
- Some Bugfixes

What's new in Version 1.53?

- Remove X-Frame and CORS protection
- Clear App Data from App Management
- Introduce \$customVariable
- Custom Layouts for App

SHOW LATER

GOT IT (17)

Lazy **TECH** Geek



Start Workout

Front Door

At a launch you will be continuously prompted to enter a valid Start URL

Quick Start Settings

Start URL

Fullscreen Mode ☒



Show Action Bar ☐


Show Address Bar ☐

Kiosk Mode, Remote Admin, Motion Detection, Launcher, Screensaver and 300+ other options can be configured in the Settings Menu (swipe from left or press and HOLD the back button)

START USING FULLY

Alternatively, you can swipe left to reveal menu and settings and enable remote administration to apply changes via a web portal (preferred)





Full

Quick
Settings

Start URL

Fullscreen

Show /

Show /

Kiosk Mode
Detection
300+ otel
in the Se
or press



Fully Kiosk Browser

Version 1.57.1



Settings

Change your preferences



Goto Start URL

Reload Start URL now



Add to Home Screen

Create link to current page



Privacy Check

Select web items to delete



Get a PLUS License

Check or obtain the license



Happy with Fully?

Give ★★★★★ at Google Play



Exit Fully

Close website and exit app

Device ID: 92798e4e-ee8b3267

IP Address: 192.168.1.230



Lounge



Kitchen



Dining room



Center Curtain



Guest Mode

Upcoming Buses

(Rainbow Field)

Horsham (23)

No more buses today

Horsham (200)

23:41 (42 minutes)

Crawley (23)

No more buses today

Gatwick (10)

23:01 (2 minutes)

Gatwick (10)

23:38 (39 minutes)



Cloudy, 17°C

22:59

19/07/2025

Sat	Cloudy	17°C		17°C
Sun	Rain	15°C		19°C
Mon	Rain	14°C		21°C
Tue	Rain	14°C		21°C
Wed	Rain	16°C		20°C

Lazy **TECH** Geek

Home Assistant

HOME MAP DEV ITEMS SECTIONS MASONRY SIDEBAR PANEL

Overview

Map

MDI Icon Index

Energy

Logbook

Hi

M

Zi

Zi

Notifications 2

Kiosk

Mailbox Sensor Unknown

Dave Home

Sun Above horizon

Dark Theme

Override Theme

Dave's S23 Mobile not_home

PLUS Features Activated

When using pro features without a licence, you will see the following text overlayed

Please Get a License

LazyTECHGeek

**Fully Kiosk Browser**
Version 1.58.1-play

**Settings**
Change your preferences

**Goto Start URL**
Reload Start URL now

**Add to Home Screen**
Create link to current page

**Privacy Check**
Select web items to delete

**Get a PLUS License**
Check or obtain the license

**Happy with Fully?**
Give ★★★★★ at Google Play

**Exit Fully**
Close website and exit app


Lounge


Kitchen


Dining room


Center Curtain


Guest Mode

Upcoming Buses

(Rainbow Field)

Horsham (23)
No more buses today

Horsham (200)
19:42 (48 minutes)

Gatwick (10)
No more buses today

Gatwick (10)
19:01 (7 minutes)

Gatwick (10)
19:37 (43 minutes)



Rainy, 22°C

18:55

19/07/2025

Sat		17°C		22°C
Sun		15°C		19°C
Mon		14°C		20°C
Tue		15°C		20°C
Wed		16°C		20°C

Purchase a licence to remove the text

Device ID: 92798e4e-ee8b3267
IP Address: 192.168.1.230

Lazy**TECH**Geek

Configuring Fully Kiosk Settings



Fully Kiosk Browser

Version 1.58.1-play



Settings

Change your preferences



Goto Start URL

Reload Start URL now



Add to Home Screen

Create link to current page



Privacy Check

Select web items to delete



Get a PLUS License

Check or obtain the license



Happy with Fully?

Give ★★★★★ at Google Play



Exit Fully

Close website and exit app

Device ID: 92798e4e-ee8b3267

IP Address: 192.168.1.230











Coming Buses

(Rainbow Field)

Horsham (23)
No more buses today

Horsham (200)
19:42 (48 minutes)

Crawley (23)
No more buses today

Gatwick (10)
19:01 (7 minutes)

Gatwick (10)
19:37 (43 minutes)



Rainy, 22°C

18:55

19/07/2025

Sat 17°C 22°C

Sun 15°C 19°C

Mon 14°C 20°C

Tue 15°C 20°C

Wed 16°C 20°C

Search in Settings

Motion detection can fail with Android 14+ when other apps in foreground or screen is off. [Check FAQ!](#)

Kiosk Mode (PLUS)

Lockdown device, prevent from accessing other apps, settings or buttons, set PIN, single app mode

Motion Detection (PLUS)

Detect motion by front cam or microphone and turn screen on or stop screensaver

Device Movement Detection (PLUS)

Detect device movement and turn screen on or make anti-theft alarm

Remote Administration (PLUS)

Access Fully Kiosk remotely from web browser in local network

Root Settings (PLUS)

Advanced settings for rooted devices only

Device Owner Settings (PLUS)

Lock task mode, advanced device policy settings and app install for provisioned devices only

KNOX Settings (PLUS)

Advanced settings for KNOX capable Samsung devices only

Other Settings

Usage stats, barcode scanner, MQTT, sensors, app recovery, export/import settings, permissions, licensing, device info etc.

Remote Administration (PLUS)

Enable Remote Administration

Show info, configure and control Fully app remotely



Remote Admin Password

Password needed for remote admin site

Remote Admin from Local Network

Enable remote admin and REST interface in your local network, currently at http://192.168.1.230:2323



Enable File Management on Remote Admin

Allow listing and downloading local files using remote admin



Enable Screenshot on Remote Admin

Allow getting a screenshot on remote admin



Enable Camshot on Remote Admin

Allow getting a camshot on remote admin (requires Motion Detection)



Remote Admin from Fully Cloud

Manage the device in Fully Cloud




Transmit Device Location to Fully Cloud

Switch off if device location is sensible/protected data



Add Device to Fully Cloud

Add this device to your Fully Cloud account



Remote Administration (PLUS)

Enable Remote Administration

Show info, configure and control Fully app remotely

Remote Admin Password

Password needed for remote admin site

Remote Admin from Local Network

Enable remote admin and REST interface

Enable File Management on Remote Admin

Allow listing and downloading local files using remote admin

Enable Screenshot on Remote Admin

Remote Admin Password

.....

UNHIDE INPUT

CANCEL

OK

1

2

3

4

5

6

7

8

9

0

Del

q

w

e

r

t

y

u

i

o

p

⌫

a

s

d

f

g

h

j

k

l

Done

⌵

z

x

c

v

b

n

m

,

!

.

?


⌵


Ctrl


!#1

English (UK)


Make note of the web address to access your tablet via Remote Administration







Sign in with password you set earlier



Fully Remote Admin

Send Command to Device

Select Admin Command ▾

Go!

App Info

Fully Device ID	92798e4e-ee8b3267
App package	de.ozerov.fully
App version	1.57.1 (101361/1394)
PLUS licensed	yes (App ID: 1)
Start URL	http://192.168.1.113:8123/lovelace/kiosk-section
Current page	http://192.168.1.113:8123/lovelace/kiosk-section HTML
Maintenance mode	off
Kiosk mode	off
Motion detection	on

Fully Kiosk Browser

Lazy **TECH** Geek

The screenshot shows a web browser window with the address bar displaying "192.168.1.230:2323/listSettings?cat=%2FmainScreen%2FsettingsWebContent". The page title is "Fully Remote Admin". On the left sidebar, the "Export/Import" menu item is highlighted with a red circle and a mouse cursor. The main content area is titled "Settings" and contains "Web Content Settings" with a description: "Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.". Below this is a "Start URL" section with a text input field containing "http://192.168.1.112:8123/". Further down, there are three toggle switches: "Enable Fullscreen Videos" (disabled), "Autoplay Videos" (disabled), and "Autoplay Audio" (disabled). A "Logout" link is visible at the bottom of the sidebar. A "LazyTECHGeek" watermark is present in the bottom right corner.

Home

Settings

Export/Import

Manage Apps

Settings

Web Content Settings

Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.

Start URL

URLs to open on app startup, can specify multiple URLs one by line

http://192.168.1.112:8123/

Enable Fullscreen Videos

Allow embedded videos to go fullscreen

Autoplay Videos

Start playing embedded videos when page loaded

Autoplay Audio

Start playing embedded audio files when page loaded

Logout

LazyTECHGeek

The next slides show you the menus and options to Export/Import settings to another device



Export/Import Settings

/storage/emulated/0 in

No settings files found here

[View/Edit Settings](#)

[Export Settings](#)



Fully Kiack Browser

Fully Remote Admin

Export/Import Settings

/storage/emulated/0 in Shared Storage **Go!**

No settings files found here

View/Edit Settings

Export Settings

192.168.1.230:2323 says

Settings file name:

fully-settings.json

OK

Cancel

Fully Remote Admin

Export/Import Settings

Settings successfully saved to /storage/emulated/0/fully-settings.json

/storage/emulated/0 in [Go!](#)



Name	Date	Import	Download	Delete
fully-settings.json	2025-07-20 22:01	Import	Download	Delete

[View/Edit Settings](#)[Export Settings](#)

Fully Kiack Browser

Lazy **TECH** Geek

Fully Remote Admin

Send Command to Device

Select Admin Command


App Info

Fully De
App pac
App ver
PLUS li
Start URL <http://192.168.1.113:8123/lovelace/kiosk-section>
Current page <http://192.168.1.113:8123/lovelace/kiosk-section>
Maintenance mode off
Kiosk mode off
Motion detection on
Acoustic detection off
Movement detection off
Device admin on
Device owner off

Fully

Browser

The next slides show you how to Import/Export settings before making any changes



On a separate browser tab, go to your Home Assistant URL (e.g. 192.168.1.113:8123).

Choose the view you want to load on your kiosk tablet, and copy the address.

Browser tabs: Fully Remote Admin

Address bar: Not secure 192.168.1.230:2323/home

Fully Remote Admin

- Home
- Settings**
- Export/Import
- Manage Apps
- Manage Files
- Fully Log
- Web Console
- Logout

Send Command to Device

Select Admin Command

Back onto the Remote Admin tab

Go to Settings

App version	1.57.1 (101361/1394)
PLUS licensed	yes (App ID: 1)
Start URL	http://192.168.1.113:8123/lovelace/kiosk-section
Current page	http://192.168.1.113:8123/lovelace/kiosk-section HTML
Maintenance mode	off
Kiosk mode	off
Motion detection	on

Lazy **TECH** Geek

Fully Remote Admin

192.168.1.230:2323/listSettings

Settings

- Web Content Settings**
Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.
- Web Browsing Settings**
Pull-to-refresh, navigation options, click sound, back button, swipe tabs, search provider, NFC tags etc.
- Web Zoom and Scaling**
Enable zooming, initial page/text scaling, overview mode, wide viewport, desktop mode
- Web Auto Reload**
Reload Start URL or current page on idle, page error, screen on, network/internet reconnect, purge cache, cookies etc.
- Advanced Web Settings**
Web automation, JavaScript interface, QR scanner, keyboard, cookies, localhost, HTTP header, web filter, SSL, client CA, caching, debugging, user agent etc.
- Universal Launcher**
Start other apps and give them full kiosk protection, seamlessly mix apps, files and web bookmarks, start apps on Fully start
- Toolbars and Appearance**

Fully Kiosk Browser

Lazy **TECH** Geek



Fully Remote Admin

Settings

Web Content Settings

Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.

Start URL

URLs to open on app startup, can specify multiple URLs one by line

http://192.168.1.113:8123/lovelace/kiosk-section

Username

Username

Password

Password for basic HTTP auth (optional)

Enable Fullscreen Videos

Allow embedded videos to go fullscreen

Autoplay Videos

Start playing embedded videos when page loaded

Paste the address into the Start URL

Fully Kiosk Browser

Lazy **TECH** Geek

Device Management (APK)

Apply these setting if you installed
Full Kiosk Browser via downloaded APK



Fully Kiosk Browser
Version 1.58.1-play



Settings
Change your preferences



Goto Start URL
Reload Start URL now



Add to Home Screen
Create link to current page



Privacy Check
Select web items to delete



Get a PLUS License
Check or obtain the license



Happy with Fully?
Give ★★★★★ at Google Play



Exit Fully
Close website and exit app

Device ID: 92798e4e-ee8b3267
IP Address: 192.168.1.230



Kitchen



Dining room



Center Curtain Curtain



Guest Mode

Coming Buses

(Rainbow Field)

Horsham (23)

No more buses today

Horsham (200)

19:42 (48 minutes)

Crawley (23)

No more buses today

Gatwick (10)

19:01 (7 minutes)

Gatwick (10)

19:37 (43 minutes)



Rainy, 22°C

18:55

19/07/2025

Sat	17°C		22°C
Sun	15°C		19°C
Mon	14°C		20°C
Tue	15°C		20°C
Wed	16°C		20°C

LazyTECHGeek

Search in Settings

⚠ Motion detection can fail with Android 14+ when other apps in foreground or screen is off. [Check FAQ!](#)

Universal Launcher

Start other apps and give them full kiosk protection, seamlessly mix apps, files and web bookmarks, start apps on Fully start

Toolbars and Appearance

Fullscreen mode, customize action bar, address bar, progress bar, tabs, select colors for the web browser and launcher

Screensaver (PLUS)

Play videos, slideshows or websites when device is idle or run Android Screen Saver

Device Management

Keep screen on, turn off on timer, unlock screen, screen orientation and brightness, start on boot, BT/Wifi, content sync

Power Settings

Scheduled sleep/wakeup, sleep on power connect/disconnect, screen locks, battery warning

Kiosk Mode (PLUS)

Lockdown device, prevent from accessing other apps, settings or boot PIN, single app mode

Motion Detection (PLUS)

Detect motion by front cam or microphone and turn screen on or stop screensaver

Device Movement Detection (PLUS)

Detect device movement and turn screen on or make anti-theft alarm

Device Management

Keep Screen On

Prevent the display from dimming and switching off by Android after some time



Keep Screen On (Advanced)

Use this if the previous option doesn't help to avoid screen offs when using other apps



Screen Brightness

Set screen brightness 0-255, set empty for system default, current: 124

Screen Orientation

Select the orientation for Fully (doesn't force other apps)

Force Screen Orientation Globally

Try to force screen orientation for all apps (experimental)



Unlock Screen

Show Fully above the screen lock (doesn't work for other apps or in single app mode)



Unlock Swipe Screen Lock

Try to unlock swipe screen lock automatically (experimental)



Screen Off Timer (PLUS)

Turn screen off after some idle seconds, set 0 for disabled, current: 15

System Wallpaper

Load system wallpaper image from this URI (or file)

Device Management

Keep Screen On

Prevent the display from dimming and switching off by Android after some time



Keep Screen On (Advanced)

Use this if the previous option doesn't help



Screen Brightness

Set screen brightness 0-255, set empty for default

Screen Brightness

124

CANCEL

OK

Screen Orientation

Select the orientation for Fully (doesn't force other apps)

Force Screen Orientation Globally



1

2

3



4

5

6

Done

7

8

9

.-

0

,

Device Management

Keep Screen On

Prevent the display from dimming and switching off by Android after some time

Keep Screen On (Advanced)

Use this if the previous option doesn't help

Screen Brightness

Set screen brightness 0-255, set empty for default

Screen Orientation

Select the orientation for Fully (doesn't force other apps)

Force Screen Orientation Globally

Screen Off Timer (PLUS)

15

seconds

CANCEL

OK

1

2

3

✕

4

5

6

Done

7

8

9

.-

0

,

Device Management (Google Play)

Apply these setting if you installed
Full Kiosk Browser via Google Play



Fully Kiosk Browser
Version 1.58.1-play



Settings
Change your preferences



Goto Start URL
Reload Start URL now



Add to Home Screen
Create link to current page



Privacy Check
Select web items to delete



Get a PLUS License
Check or obtain the license



Happy with Fully?
Give ★★★★★ at Google Play



Exit Fully
Close website and exit app

Device ID: 92798e4e-ee8b3267
IP Address: 192.168.1.230



Kitchen



Dining room



Center Curtain Curtain



Guest Mode

Coming Buses

(Rainbow Field)

Horsham (23)
No more buses today

Horsham (200)
19:42 (48 minutes)

Crawley (23)
No more buses today

Gatwick (10)
19:01 (7 minutes)

Gatwick (10)
19:37 (43 minutes)



Rainy, 22°C

18:55

19/07/2025

Sat	17°C		22°C
Sun	15°C		19°C
Mon	14°C		20°C
Tue	15°C		20°C
Wed	16°C		20°C

Search in Settings

⚠ Motion detection can fail with Android 14+ when other apps in foreground or screen is off. [Check FAQ!](#)

Universal Launcher

Start other apps and give them full kiosk protection, seamlessly mix apps, files and web bookmarks, start apps on Fully start

Toolbars and Appearance

Fullscreen mode, customize action bar, address bar, progress bar, tabs, select colors for the web browser and launcher

Screensaver (PLUS)

Play videos, slideshows or websites when device is idle or run Android Screen Saver

Device Management

Keep screen on, turn off on timer, unlock screen, screen orientation and brightness, start on boot, BT/Wifi, content sync

Power Settings

Scheduled sleep/wakeup, sleep on power connect/disconnect, screen locks, battery warning

Kiosk Mode (PLUS)

Lockdown device, prevent from accessing other apps, settings or boot PIN, single app mode

Motion Detection (PLUS)

Detect motion by front cam or microphone and turn screen on or stop screensaver

Device Movement Detection (PLUS)

Detect device movement and turn screen on or make anti-theft alarm

Device Management

Keep Screen On

Prevent the display from dimming and switching off by Android after some time



Keep Screen On (Advanced)

Use this if the previous option doesn't help to avoid screen offs when using other apps



Screen Brightness

Set screen brightness 0-255, set empty for system default, current: 124

Screen Orientation

Select the orientation for Fully (doesn't force other apps)

Force Screen Orientation Globally

Try to force screen orientation for all apps (experimental)



Unlock Screen

Show Fully above the screen lock (doesn't work for other apps or in single app mode)



Unlock Swipe Screen Lock

Try to unlock swipe screen lock automatically (experimental)



Screen Off Timer (PLUS)

Turn screen off after some idle seconds, set 0 for disabled, current: 0

System Wallpaper

Load system wallpaper image from this URL (or file)



Device Management

Keep Screen On

Prevent the display from dimming and switching off by Android after some time



Keep Screen On (Advanced)

Use this if the previous option doesn't help



Screen Brightness

Set screen brightness 0-255, set empty for auto

Screen Brightness

124

CANCEL

OK

Screen Orientation

Select the orientation for Fully (doesn't force other apps)

Force Screen Orientation Globally



1

2

3



4

5

6

Done

7

8

9

.-

0

,

Device Management

Keep Screen On

Prevent the display from dimming and switching off by Android after some time



Keep Screen On (Advanced)

Use this if the previous option doesn't help



Screen Brightness

Set screen brightness 0-255, set empty for auto

Screen Orientation

Select the orientation for Fully (doesn't force other apps)

Force Screen Orientation Globally

Screen Off Timer (PLUS)

0

seconds

CANCEL

OK

1

2

3



4

5

6

Done

7

8

9

.-

0

,

Screensaver (Plus) (Google Play)



Fully Kiosk Browser
Version 1.58.1-play



Settings
Change your preferences



Goto Start URL
Reload Start URL now



Add to Home Screen
Create link to current page



Privacy Check
Select web items to delete



Get a PLUS License
Check or obtain the license



Happy with Fully?
Give ★★★★★ at Google Play



Exit Fully
Close website and exit app

Device ID: 92798e4e-ee8b3267
IP Address: 192.168.1.230



Kitchen



Dining room



Center Curtain Curtain



Guest Mode

Coming Buses

(Rainbow Field)

Horsham (23)
No more buses today

Horsham (200)
19:42 (48 minutes)

Crawley (23)
No more buses today

Gatwick (10)
19:01 (7 minutes)

Gatwick (10)
19:37 (43 minutes)

Rainy, 22°C

18:55

19/07/2025

Sat 17°C 22°C

Sun 15°C 19°C

Mon 14°C 20°C

Tue 15°C 20°C

Wed 16°C 20°C

LazyTECHGeek

Search in Settings

Motion detection can fail with Android 14+ when other apps in foreground or screen is off. [Check FAQ!](#)

Web Content Settings

Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.

Web Browsing Settings

Pull-to-refresh, navigation options, click and hold, back button, swipe tabs, search provider, NFC tags etc.

Web Zoom and Scaling

Enable zooming, initial page/text scaling, overview mode, wide viewport, desktop mode

Web Auto Reload

Reload Start URL or current page on idle page error, screen on, network/internet reconnect, purge cache, cookies etc.

Advanced Web Settings

Web automation, JavaScript interface, scanner, keyboard, cookies, localhost, HTTP header, web filter, SSL, client CA, caching, debugging, user agent etc.

Universal Launcher

Start other apps and give them full keyboard selection, seamlessly mix apps, files and web bookmarks, start apps on Fully start

Toolbars and Appearance

Fullscreen mode, customize action bar, address bar, progress bar, tabs, select colors for the web browser and launcher

Screensaver (PLUS)

Play videos, slideshows or websites when device is idle or run Android Screen Saver

Screensaver (PLUS)

Screensaver Timer

Show screensaver URL after some idle seconds, set 0 for disabled, current: 15



Screensaver Playlist

Select media files, folders or web sites to show on the screensaver

Screensaver Wallpaper URL

fully://color#000000

Screensaver Brightness

Set screen brightness for screensaver 0-255, set empty for default, current: 0



Fade In/Out Duration

Set playlist image fade in/out duration in milliseconds, set 0 for no fading, current: 200ms

Image Scaling Type

Choose a way to scale the images when playing the playlist

Ignore Motion Detection when Screensaver goes on/off

Don't detect motion while screensaver is starting or stopping



Cache Images

Enable caching of network images on the playlist



Use Android Screen Saver

Start Android Screen Saver (Screensaver) on timer instead of Fully's playlist (not possible in Android 13+)

Screensaver (PLUS)

Screensaver Timer

Show screensaver URL after some idle seconds, set 0 for disabled, current: 15

Screensaver Playlist

Select media files, folders or web sites to

Screensaver Wallpaper URL

fully://color#000000

Screensaver Brightness

Set screen brightness for screensaver 0-255, set empty for default, current: 0

Fade In/Out Duration

Screensaver Timer

15

seconds

CANCEL

OK

1

2

3

✕

4

5

6

Done

7

8

9

.-

0

,

Screensaver (PLUS)

Screensaver Timer

Show screensaver URL after some idle seconds, set 0 for disabled, current: 15

Screensaver Playlist

Select media files, folders or web sites to

Screensaver Wallpaper URL

fully://color#000000

Screensaver Brightness

Set screen brightness for screensaver 0-255, set empty for default, current: 0

Fade In/Out Duration

Screensaver Brightness

0

CANCEL

OK

1

2

3

✕

4

5

6

Done

7

8

9

.-

0

,

Motion Detection (Plus)
Apply these setting whether
Installed Full Kiosk Browser
via APK or Google Play



Fully Kiosk Browser

Version 1.58.1-play



Settings

Change your preferences



Goto Start URL

Reload Start URL now



Add to Home Screen

Create link to current page



Privacy Check

Select web items to delete



Get a PLUS License

Check or obtain the license



Happy with Fully?

Give ★★★★★ at Google Play



Exit Fully

Close website and exit app

Device ID: 92798e4e-ee8b3267

IP Address: 192.168.1.230











Coming Buses

(Rainbow Field)

Horsham (23)
No more buses today

Horsham (200)
19:42 (48 minutes)

Crawley (23)
No more buses today

Gatwick (10)
19:01 (7 minutes)

Gatwick (10)
19:37 (43 minutes)

Rainy, 22°C

18:55

19/07/2025

Sat 17°C 22°C

Sun 15°C 19°C

Mon 14°C 20°C

Tue 15°C 20°C

Wed 16°C 20°C

Search in Settings

Screensaver (PLUS)

Play videos, slideshows or websites when device is idle or run Android Screen Saver

Device Management

Keep screen on, turn off on timer, unlock screen, screen orientation and brightness, start on boot, BT/Wifi, content

Power Settings

Scheduled sleep/wakeup, sleep on power connect/disconnect, wakelocks, battery warning

Kiosk Mode (PLUS)

Lockdown device, prevent from accessing other apps, settings or buttons, set PIN, single app mode

Motion Detection (PLUS)

Detect motion by front cam or microphone and turn screen on or stop screensaver

Device Movement Detection (PLUS)

Detect device movement and turn screen on or make anti-theft alarm

Remote Administration (PLUS)

Access Fully remotely from web browser in local network or worldwide using Fully Cloud

Root Settings (PLUS)

Advanced settings for rooted devices only

Device Owner Settings (PLUS)

Lock task mode, advanced device policy settings and app install for provisioned devices only



Motion Detection (PLUS)

Enable Visual Motion Detection

Use front camera for motion detection



Detector Sensitivity

Motion detector sensitivity (0-100%), current: 80

Detector Frame Rate

Frames per second to analyse (1-25), current: 5

Select Camera

Select the camera to use for motion detection

Show Cam Preview

Show a small cam preview on screen



Camera API

Select the camera API used for motion detection. App restart will be required to apply (EXPERIMENTAL)

Detect Faces

Enable face detection



Face Detection Confidence

Face detection required confidence threshold (0-100%), current: 30

Trigger Motion only when Faces Detected

Trigger Motion Detection (only!) when faces found on the camera image



Motion Detection (PLUS)

Enable Visual Motion Detection
Use front camera for motion detection

Detector Sensitivity
Motion detector sensitivity (0-100%), current

Detector Frame Rate
Frames per second to analyse (1-25), current

Select Camera
Select the camera to use for motion detection

Show Cam Preview

Detector Sensitivity

80

%

CANCEL

OK

1

2

3

✕

4

5

6

Done

7

8

9

.-

0

,

Motion Detection (PLUS)

Enable Visual Motion Detection
Use front camera for motion detection



Detector Sensitivity
Motion detector sensitivity (0-100%), current: 80

Detector Frame Rate
Frames per second to analyse (1-25), current: 10

Select Camera
Select the camera to use for motion detection

Show Cam Preview
Show a small cam preview on screen



Camera API
Select the camera API used for motion detection

CANCEL

Detect Faces
Enable face detection



Face Detection Confidence
Face detection required confidence threshold (0-100%), current: 30

Trigger Motion only when Faces Detected
Trigger Motion Detection (only) when faces found on the camera image

Select Camera

- ☒ Default Camera (Front)
- ☐ Camera #0 (Back)
- ☐ Camera #1 (Front)

Turn screen On on Motion If installed via APK
Exit Screensaver on Motion: Installed via Google Play
(If unsure just leave both on)

Darkness Threshold

Darkness Threshold Level for darkness detection (0-100%), current: 10

Enable Acoustic Motion Detection

Use device microphone for motion detection



Acoustic Detector Sensitivity

Microphone sensitivity (0-100%), current: 90

Turn Screen On on Motion

Turn screen on when motion detected, look in Device Management for Screen Off Timer



Exit Screensaver on Motion

Stop screensaver when motion detected, look in Screensaver Settings for screensaver options



Stop Web Reload on Motion

Reset reload timer when motion detected, look in Web Auto Reload Settings for Auto Reload on Idle Timer

